

[Manuals.plus](#) /

> [Yechen](#) /

> Yechen Full Black Rattan Cabinet (Model: B0FPDZWSDY) Instruction Manual

Yechen B0FPDZWSDY

Yechen Full Black Rattan Cabinet (Model: B0FPDZWSDY) Instruction Manual

Brand: Yechen | Model: B0FPDZWSDY

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your Yechen Full Black Rattan Cabinet. Please read this manual thoroughly before assembly and use to ensure proper function and longevity of your product.

The Yechen Full Black Rattan Cabinet is a versatile furniture piece designed for various uses, including as a buffet sideboard, console table, TV stand, entryway cabinet, shoe cabinet, kitchen pantry storage cabinet, or coffee bar cabinet. It features a stable and sturdy structure with metal legs and an aesthetic design incorporating natural rattan decorated doors.

2. SAFETY INFORMATION

Always follow these safety guidelines to prevent injury or damage to the product:

- Ensure all parts are present and undamaged before assembly.
- Assemble on a soft, clean surface to prevent scratches.
- Do not overtighten screws during assembly.
- Place the cabinet on a level surface to ensure stability.
- Do not exceed the maximum weight capacity of 100 pounds for the top surface.
- Keep small parts away from children during assembly.

3. SETUP AND ASSEMBLY

The Yechen Rattan Cabinet is designed for easy assembly. Clear and easy-to-read instructions are provided with all spare parts marked for convenience.

3.1 Unpacking

Carefully unpack all components from the box. Verify that all parts listed in the assembly instructions are present. If any parts are missing or damaged, contact customer service.

3.2 Assembly Steps

1. Attach the metal legs to the base of the cabinet using the provided hardware. Ensure they are securely fastened but do not overtighten.
2. Assemble the main cabinet frame according to the step-by-step diagrams in the included manual.
3. Install the adjustable shelves at your desired height.
4. Attach the natural rattan decorated doors. Ensure the magnetic clasps align for proper closure.
5. Place the assembled cabinet in its desired location. The adjustable feet allow for leveling on uneven surfaces.



Figure 1: Product Dimensions and Load Capacities. The cabinet measures 15.75"D x 31.5"W x 31.5"H. The top surface can hold up to 100 lbs, and internal shelves can hold up to 20 lbs each. The space below the cabinet is 7" high.



Figure 2: Adjustable Leveler Legs. The cabinet features adjustable feet to ensure stability on various floor types and to allow for easy cleaning underneath.

4. OPERATING INSTRUCTIONS

The Yechen Rattan Cabinet is designed for versatile storage and display. Its two-tier internal space and spacious tabletop provide ample room for various items.

4.1 Storage and Organization

- Utilize the spacious tabletop for decorative items, lamps, or media devices.
- The internal shelves are ideal for organizing books, toys, dishes, or other household necessities.
- The natural rattan doors conceal contents, helping to maintain a tidy appearance in your room.

Living Room Cabinet

Can be used as a tv stand, console cabinet, credenza, accent cabinet, buffet table



Figure 3: Living Room Cabinet Use. The cabinet can function as a TV stand, console cabinet, credenza, accent cabinet, or buffet table.



Figure 4: Buffet and Sideboard Configuration. Multiple units can be combined to create a longer buffet or sideboard for dining rooms or kitchens.

4.2 Door Operation

The doors are equipped with magnetic clasps for smooth and secure closing. To open, gently pull the knob. To close, push the door until the magnet engages.

5. MAINTENANCE AND CARE

To keep your Yechen Rattan Cabinet in optimal condition, follow these simple care instructions:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish and natural rattan.
- **Dusting:** Regularly dust the cabinet with a dry, soft cloth.
- **Rattan Care:** The natural rattan is durable but should be kept away from excessive moisture and direct prolonged sunlight to prevent drying or fading.

- **Stability Check:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.

6. TROUBLESHOOTING

If you encounter any issues with your Yechen Rattan Cabinet, refer to the following common solutions:

- **Wobbly Cabinet:** Ensure the cabinet is placed on a level surface. Adjust the leveler feet on the bottom of the metal legs until the cabinet is stable. Check all assembly screws for tightness.
- **Doors Not Closing Properly:** Verify that the magnetic clasps are correctly aligned. Adjust the door hinges if necessary to ensure proper closure.
- **Damaged Rattan:** Minor fraying of natural rattan can be carefully trimmed with small scissors. For significant damage, contact customer service.

If problems persist, please contact Yechen customer service for further assistance.

7. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Yechen
Model (ASIN)	B0FPDZWSDY
Color	Full Black
Material	Rattan, Engineered Wood, Metal
Product Dimensions (D x W x H)	15.75"D x 31.5"W x 31.5"H
Weight Capacity (Top)	100 Pounds
Number of Doors	2
Number of Shelves	3 (Adjustable)
Assembly Required	Yes
Additional Features	Adjustable Feet, Natural Rattan Doors

8. WARRANTY AND SUPPORT

Yechen is committed to providing high-quality products. If you have any problems about the rattan storage cabinet, please do not hesitate to contact our professional seller customer service, we will assist you to solve the problem. For customer service inquiries, please refer to the contact information provided with your purchase or visit the official Yechen store on Amazon: [Yechen Store](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FPDZWSDY>

More documents and user manuals: **<https://manuals.plus/>**