Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VASAGLE KKS013YA02

VASAGLE KKS013YA02 Kitchen Shelf with Power Outlet

Instruction Manual

1. Introduction

Thank you for choosing the VASAGLE KKS013YA02 Kitchen Shelf. This manual provides essential information for the safe assembly, operation, and maintenance of your new kitchen storage unit. Please read these instructions carefully before assembly and retain them for future reference.

Important Safety Information

- Always follow the assembly instructions step-by-step.
- Ensure all parts are securely fastened before use.
- Do not exceed the maximum weight capacity for each shelf.
- Keep children away from the product during assembly.
- Install the anti-tip device to prevent accidental tipping, especially in households with children or pets.
- Only use the integrated power outlet for appliances within its specified voltage and wattage limits.

2. Product Overview

The VASAGLE KKS013YA02 Kitchen Shelf is a versatile storage solution designed for your kitchen. It features multiple shelves, a convenient power outlet, S-hooks, and a paper towel holder to help organize your space efficiently.



Figure 2.1: The fully assembled VASAGLE KKS013YA02 Kitchen Shelf, showcasing its compact design and storage capabilities in a kitchen setting. It features a top shelf, a main countertop, two lower shelves, a paper towel holder, and S-hooks.

Key Features:

- **Spacious Storage:** Top shelf, 8 S-hooks, paper towel holder, large countertop, and two lower shelves.
- **Integrated Power Outlet:** Two AC outlets with an on/off switch and overload protection for safety.
- **Adjustable Middle Shelf:** Three height options to accommodate various kitchen items.
- **Robust and Stable:** Constructed with a sturdy steel frame and durable particleboard, featuring adjustable feet for stability

on uneven surfaces.




Figure 2.2: This diagram provides the precise dimensions of the kitchen shelf: 40 cm (depth) x 45 cm (width) x 140 cm (height). It also indicates the weight capacity for each shelf: top shelf 10 kg, main countertop 25 kg, and lower shelves 20 kg each. The power cord length is 1.5 meters.

3. Setup and Assembly

Assembly of the VASAGLE KKS013YA02 Kitchen Shelf is designed to be straightforward. All necessary parts are labeled, and detailed instructions are included in the product packaging.

Assembly Steps:

1. **Unpack Components:** Carefully remove all parts from the packaging and verify against the parts list provided in the separate assembly guide.
2. **Assemble Frame:** Follow the numbered steps in the assembly guide to connect the steel frame components.
3. **Attach Shelves:** Securely attach the particleboard shelves to the frame using the provided hardware. Pay attention to the adjustable middle shelf during this step.
4. **Install Accessories:** Mount the paper towel holder and S-hooks as indicated in the instructions.
5. **Adjust Feet:** Once assembled, adjust the leveling feet at the bottom of the unit to ensure stability on your floor.
6. **Install Anti-Tip Kit:** For safety, attach the anti-tip strap to the top of the shelf and secure it to a wall stud using appropriate hardware.




Figure 3.1: This image demonstrates the anti-tip strap, which should be securely fastened to the wall to prevent the shelf from tipping over, ensuring safety.




Figure 3.2: This image shows the adjustable feet at the base of the shelf, which can be rotated to stabilize the unit on uneven surfaces and protect floors from scratches.

4. Operating Instructions

Using the Integrated Power Outlet:

The kitchen shelf includes a built-in power strip for convenient access to electricity for your kitchen appliances.

- **Connect to Wall Outlet:** Plug the shelf's power cord into a standard wall outlet.
- **Power On/Off:** Use the red switch on the power strip to turn the power on or off. Ensure the switch is in the 'On' position to supply power to the outlets.
- **Overload Protection:** The power strip is equipped with overload protection. If too many high-power devices are connected, the circuit breaker may trip. If this happens, disconnect some devices and press the reset button (if available) or cycle the power switch.
- **Appliance Compatibility:** Only connect appliances that are within the specified voltage (230V) and maximum wattage (1875W) of the power strip.



Figure 4.1: This image highlights the integrated power strip, featuring two 230V/16A AC outlets, an on/off switch, and overload protection. The maximum power output is 1875 Watts, with a 1.5-meter cable.

Adjusting the Middle Shelf:

The middle shelf can be adjusted to three different heights to accommodate items of varying sizes.

- **Unload Shelf:** Remove all items from the middle shelf before attempting to adjust its height.
- **Loosen Fasteners:** Carefully loosen the fasteners that secure the shelf to the frame.

- **Reposition:** Move the shelf to the desired height and align it with the pre-drilled holes.
- **Secure Fasteners:** Re-tighten all fasteners to ensure the shelf is stable and secure before placing items back on it.



Figure 4.2: This image illustrates the adjustable middle shelf, which offers three height options to accommodate various kitchen items, from tall blenders to smaller pots and pans. The adjustment points are clearly marked.

Using S-Hooks and Paper Towel Holder:

- **S-Hooks:** Hang kitchen utensils, mugs, or small towels on the provided S-hooks for easy access.

- **Paper Towel Holder:** Insert a standard roll of paper towels onto the holder for convenient dispensing.



Figure 4.3: This image shows the built-in paper towel holder, designed for easy access and convenient storage of kitchen rolls.

5. Maintenance

Regular cleaning and proper care will extend the life of your VASAGLE Kitchen Shelf.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the particleboard.
- **Fasteners:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary.
- **Power Outlet:** Ensure the power outlet remains dry and free from debris. Do not immerse in water.

6. Troubleshooting

Common Issues and Solutions:

- **Shelf is wobbly:**
  Solution: Adjust the leveling feet at the bottom of the unit until it stands firmly on the floor. Ensure all assembly screws are tightened.
- **Power outlet not working:**
  Solution: Check if the power cord is securely plugged into the wall outlet. Verify that the red on/off switch on the power strip is in the 'On' position. If the overload protection has tripped, unplug some devices and reset the breaker if applicable.
- **Difficulty assembling:**
  Solution: Refer to the detailed assembly instructions provided with the product. Ensure all parts are correctly identified and oriented. Do not force parts together.

7. Specifications

Feature	Detail
Model Number	KKS013YA02
Dimensions (L x W x H)	40 x 45 x 140 cm
Weight	9.2 Kilograms
Material	Engineered Wood, Alloy Steel

Number of Shelves	4
Special Feature	Integrated Power Outlet (2 AC outlets, On/Off switch, Overload Protection)
Power Outlet Voltage	230V
Power Outlet Max Wattage	1875 Watts
Power Cord Length	1.5 meters
Assembly Required	Yes
Mounting Type	Floor Mount (Freestanding)

8. Warranty and Support

For any questions, missing parts, or issues not covered in this manual, please contact VASAGLE customer support. Refer to your purchase documentation for specific warranty details and contact information.
You can typically find support contact details on the VASAGLE official website or through the retailer where you purchased the product.

© 2026 VASAGLE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FPFNPVSH

More documents and user manuals: **https://manuals.plus/**