



[Manuals.plus](#) /

> [AiJoy](#) /

> AiJoy ADP90 88-Key Weighted Digital Piano Keyboard Instruction Manual

AiJoy ADP90

AiJoy ADP90 88-Key Weighted Digital Piano Keyboard Instruction Manual

Model: ADP90 | Brand: AiJoy

INTRODUCTION

Welcome to your new AiJoy ADP90 Digital Piano. This manual provides essential information for setting up, operating, and maintaining your instrument. The AiJoy ADP90 features 88 weighted keys with graded hammer action, replicating the feel of an acoustic piano. It offers a wide range of sounds and connectivity options for an enriching musical experience.

Key Features

- Full-size 88-key weighted keyboard with graded hammer-action for realistic touch.
- 8 different tones, 128 rhythms, and 31 demonstration songs with 128-note polyphony.
- Multi-functionality including Dual Voice, Tempo Adjustment, Chord, Transpose, Metronome, and recording.
- USB-MIDI and Audio IN/OUT support for computer/phone connection and piano learning apps.
- Dual headphone jacks for silent practice.
- Upgraded anti-pinch piano cover with slow-close mechanism.
- Sensitive damping pedal system replicating grand piano feel.

SETUP

Assembly Instructions

The AiJoy ADP90 Digital Piano requires assembly. Please follow these steps carefully.

FRENCH DREAM SOURCE

Powerful chip performance to restore the sound of the source
Fuller and clearer sound quality




Image: All components of the AiJoy ADP90 Digital Piano laid out for assembly, including the keyboard unit, wooden stand parts, triple pedal unit, power adapter, and user manual.

Video: This video demonstrates the assembly process of a similar 88-key weighted digital piano, showing how to connect the stand components and attach the main keyboard unit. It also highlights the triple pedal installation.

Ensure all parts are present before beginning assembly. Refer to the included user manual for detailed diagrams.

OPERATING YOUR PIANO

Basic Controls

GRADED HAMMER ACTION



88 keys



Real Touch



Standard Size



Image: Close-up view of the AiJoy ADP90 Digital Piano's control panel, showing the power button, volume knob, and various function buttons for tone, rhythm, demo, and transpose.

The control panel is located on the left side of the keyboard.

- **Power On/Off:** Locate the **POWER** button on the control panel. Press to turn the piano on or off.
- **Volume Adjustment:** Use the **VOLUME** knob to adjust the overall sound level.
- **Tone Selection:** Press the **TONE/DEMO** button to cycle through the 8 available tones.
- **Rhythm and Demo Songs:** Use the **TONE/RHYTHM/DEMO** button to access 128 rhythms and 31 demonstration songs.
- **Transpose Function:** The **TRANSPOSE** button allows you to shift the pitch of the keyboard up or down.

Video: This video provides a sound sample of the AiJoy ADP-90 Digital Piano, showcasing its various tones and sound quality.

Connectivity

COMPACT & ELEGANT

Its compact design is a luxurious yet affordable addition to any space



Image: Detailed view of the rear connectivity panel of the AiJoy ADP90 Digital Piano, showing USB MIDI, Audio IN/OUT, and headphone ports.

The piano offers versatile connectivity options:

- **USB-MIDI:** Connect to a computer or smart device for MIDI applications and music production software.
- **Audio IN/OUT:** Connect external audio sources or output the piano's sound to external speakers or recording devices.
- **Headphone Jacks:** Two headphone jacks are available for silent practice, allowing two users to listen simultaneously.

MAINTENANCE

Care and Cleaning

To ensure the longevity and optimal performance of your AiJoy ADP90 Digital Piano, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the piano. Avoid abrasive cleaners or solvents.

- **Piano Cover:** Utilize the upgraded anti-pinch piano cover to protect the keys from dust and debris when not in use. The slow-close mechanism prevents accidental finger pinching.
- **Environment:** Keep the piano away from direct sunlight, extreme temperatures, and high humidity.

TROUBLESHOOTING

Common Issues and Solutions

- **No Sound:** Check the power connection, ensure the volume is turned up, and verify that headphones are not plugged in if you intend to use the internal speakers.
- **Keys Not Responding:** Ensure the piano is powered on and properly connected. If using MIDI, check software settings.
- **Connectivity Problems:** Verify all cables are securely connected. For USB-MIDI, ensure drivers are installed on your computer if required.

SPECIFICATIONS

Technical Details

Brand	AiJoy
Model Name	ADP90
Number of Keys	88
Key Type	Weighted, Graded Hammer Action
Connectivity	USB-MIDI, Audio IN/OUT
Power Source	Corded Electric
Item Weight	70 Pounds
Item Dimensions	16"D x 15"W x 56"H
Included Components	Piano Cover, Damping Pedal, USB-MIDI Cable, Audio IN/OUT Cable

WHAT'S IN THE BOX

Package Contents

- Main Piano Unit
- Wooden Stand Components
- Piano Cover
- Damping Pedal
- USB-MIDI Cable
- Audio IN/OUT Cable

WARRANTY AND SUPPORT

Warranty Information

Your AiJoy ADP90 Digital Piano comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions.

Customer Support

For technical assistance, troubleshooting, or warranty claims, please contact AiJoy customer support through their official website or the contact information provided in your product documentation.