Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Pamray /
- > Pamray S12 32 Inch Computer Desk with 4 Drawers Instruction Manual

Pamray S12

Pamray S12 32 Inch Computer Desk with 4 Drawers Instruction Manual

Model: S12 | Brand: Pamray

INTRODUCTION

Thank you for choosing the Pamray 32 Inch Computer Desk. This manual provides detailed instructions for the assembly, operation, and maintenance of your new desk. Please read this manual thoroughly before assembly and retain it for future reference.



Image: The Pamray 32 Inch Computer Desk, fully assembled, featuring a black desktop and four integrated fabric drawers on the left side.

SAFETY INFORMATION

Please observe the following safety precautions to prevent injury or damage to the product:

- Ensure all parts are present and undamaged before beginning assembly.
- Assemble the desk on a soft, clean surface to prevent scratches.
- Do not overtighten screws during assembly, as this may damage the material.
- Keep small parts away from children to avoid choking hazards.
- Do not stand or sit on the desk.
- Distribute weight evenly across the desktop and within drawers. The maximum weight recommendation for the desktop is 150 pounds. Each drawer supports up to 10 pounds.
- Regularly check all fasteners to ensure they remain tight.

PACKAGE CONTENTS

Before starting assembly, verify that all components listed below are included in your package. Refer to the included accessory bag for specific hardware.

- Desktop Panel
- Left Support Frame (with drawer housing)
- Right Support Frame
- Cross Braces (X-shape)
- · Adjustable Leg Pads
- Fabric Drawers (x4)
- Assembly Hardware (screws, Allen wrench, etc.)
- · Instruction Manual

ASSEMBLY INSTRUCTIONS

Assembly is required for this product. Clear instructions and all necessary tools are provided in the accessory bag. For a visual guide, scan the QR code on the packaging to access comprehensive installation videos.

Step 1: Prepare Components

Unpack all components and lay them out on a clean, soft surface to prevent damage. Identify each part using the provided labels and the parts list.

Step 2: Attach Support Frames

Secure the left and right support frames to the desktop panel using the designated screws. Ensure the drawer housing on the left frame is correctly oriented.




Image: An assembled Pamray desk in a home office setting, illustrating the overall structure and placement of the drawer unit.

Step 3: Install Cross Braces

Attach the "X" shaped back braces between the support frames. These braces enhance the desk's stability. Do not overtighten.

Image: A detailed view of the X-shaped metal cross brace, providing structural support to the desk frame.

Step 4: Attach Adjustable Leg Pads

Screw the adjustable leg pads into the bottom of each leg. These pads protect your floor and allow for minor leveling adjustments on uneven surfaces.



Image: A close-up of the desk's legs, showing the adjustable leg pads designed to protect flooring and stabilize the desk.

Step 5: Insert Fabric Drawers

Unfold the four fabric drawers and insert them into the designated slots within the left support frame. Ensure they slide smoothly.



Image: A close-up view of the four fabric drawers, partially pulled out to show their storage capacity.



Image: The fabric drawers shown with various items stored inside, demonstrating their practical use for organization.

USAGE GUIDELINES

This desk is designed for use as a computer desk, office desk, study table, or vanity. Its compact size makes it suitable for small spaces.

- **Desktop Use:** Place your computer, monitor, and other work essentials on the desktop. The surface is designed to be waterproof.
- **Drawer Storage:** Utilize the four fabric drawers for organizing office supplies, documents, or personal items. Each drawer can hold up to 10 lbs.
- Leveling: If the desk wobbles, adjust the leg pads at the bottom of each leg until the desk is stable.



Image: Water droplets on the desk surface, illustrating its waterproof property for easy cleaning and spill resistance.

MAINTENANCE

To ensure the longevity and appearance of your Pamray desk, follow these maintenance guidelines:

- Cleaning: Wipe the desktop and metal frame with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners. For the fabric drawers, spot clean with a mild detergent if necessary.
- Protection: Avoid placing hot items directly on the desktop. Use coasters for drinks.
- Fasteners: Periodically check all screws and bolts to ensure they are tight. Retighten if necessary.
- **Environment:** Keep the desk in a dry environment and avoid prolonged exposure to direct sunlight or extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Desk is wobbly.	Uneven floor or loose fasteners.	Adjust the leg pads until the desk is stable. Check and tighten all assembly screws.
Drawers do not slide smoothly.	Improper installation or obstruction.	Ensure drawers are fully unfolded and correctly inserted. Check for any items obstructing the drawer path.
Missing parts.	Packaging error.	Contact Pamray customer service immediately with your purchase details.

SPECIFICATIONS

Brand: Pamray

Model: S12

Product Dimensions (W x D x H): 31.5" x 15.7" x 29.2" (80 cm x 40 cm x 74.2 cm)

Color: Black

Base Material: Metal

Top Material Type: FSC-Certified Wood **Item Weight:** 16.4 Pounds (7.44 kg)

Number of Drawers: 4 (Fabric)

Maximum Desktop Weight Recommendation: 150 Pounds (68 kg)

Maximum Drawer Weight Recommendation: 10 Pounds (4.5 kg) per drawer

Assembly Required: Yes

Special Features: Compact design, X-shape back brace for stability, adjustable leg pads, waterproof desktop.



Image: A diagram illustrating the precise dimensions of the Pamray 32 Inch Computer Desk and its drawers.


CUSTOMER SERVICE & SUPPORT

Your satisfaction is our priority. If you encounter any issues regarding the desk's quality or during use, please do not hesitate to contact us. We are committed to providing prompt and effective solutions.


For assistance, please visit the Pamray store on Amazon or use the messaging assistant feature. You can typically find contact options on the product's Amazon page under the seller information.

How to Contact Customer Service:

- 1. Go to the product page on Amazon.
- 2. Click on the seller's name (e.g., "Xstone" or "Pamray Store").
- 3. Look for a "Ask a question" or "Contact Seller" option.



Related Documents - S12





ASSEMBLY INSTRUCTIONS

Pamray L-Shaped Computer Desk Assembly Instructions

Detailed assembly instructions for the Pamray L-Shaped Computer Desk, including parts list and step-by-step guidance for both right-side and left-side shelving configurations.