

[Manuals.plus](#) /

› [Breezary](#) /

› Breezary 84 Inch Industrial Ceiling Fan with Light and Remote, Model 35086-BLACK User Manual

Breezary 35086-BLACK

Breezary 84 Inch Industrial Ceiling Fan with Light and Remote

Model: 35086-BLACK User Manual

1. INTRODUCTION

Thank you for choosing the Breezary 84 Inch Industrial Ceiling Fan with Light and Remote. This manual provides essential information for the safe installation, operation, and maintenance of your new ceiling fan. Please read these instructions thoroughly before installation and retain them for future reference.



Image 1.1: Breezary 84 Inch Industrial Ceiling Fan in a living room setting.

This 84-inch ceiling fan is designed for large spaces, featuring 10 dual-finish blades, a 6-speed reversible DC motor, and an integrated 3CCT LED light. It includes a multi-function remote control for convenient operation.

2. SAFETY INFORMATION

Always follow basic safety precautions when installing and operating this appliance to reduce the risk of fire, electric shock, and personal injury.

- **Read all instructions:** Before beginning installation, read all instructions and safety information.
- **Electrical Safety:** All electrical wiring must be performed by a qualified electrician and conform to local codes and national electrical codes. Disconnect power at the main circuit breaker before installation or servicing.
- **Mounting:** The mounting structure must be capable of supporting the weight of the fan (approximately 30 lbs) plus the dynamic load of the fan in motion.
- **Blade Clearance:** Ensure there is adequate clearance from the blades to any obstructions. A minimum of 7 feet (2.13 meters) from the floor to the blade trailing edge is recommended.

- **Downrod Usage:** Use only the provided downrods (6", 12", 24") or approved extensions.
- **Light Source:** The integrated LED light is not dimmable and does not have a memory function. Do not attempt to replace the LED module yourself; contact qualified service personnel.
- **Remote Control:** Keep the remote control away from water and extreme temperatures.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged before proceeding with installation. If any parts are missing or damaged, contact customer support.

- Ceiling Fan Motor Housing
- Fan Blades (10)
- Downrods (6", 12", 24")
- Mounting Bracket
- Canopy
- LED Light Kit
- Remote Control with Wall Mount
- Mounting Hardware (screws, wire nuts, washers)
- Instruction Manual

4. SPECIFICATIONS

Feature	Specification
Model Number	35086-BLACK
Fan Size	84 inches
Number of Blades	10
Motor Type	DC Motor
Fan Speeds	6
Noise Level	Under 35 dB
Light Type	Integrated 24W LED
Color Temperature (CCT)	3000K (Warm), 4000K (Natural), 6000K (Cool White)
Light Dimmable	No
Remote Control	Yes, Multi-function
Timer Function	1H, 2H, 4H
Reversible Airflow	Yes
Downrod Lengths Included	6", 12", 24"
Sloped Ceiling Compatibility	Up to 12°
Recommended Room Size	Over 400 sq. ft.

Feature	Specification
Weight	Approximately 30 lbs
Materials	Acrylic, Engineered Wood, Metal




Image 4.1: Fan dimensions, downrod options, and room size recommendation.

5. SETUP AND INSTALLATION

Professional installation is recommended. Ensure power is disconnected at the circuit breaker before beginning. Refer to the included wiring diagram for electrical connections.

5.1 Mounting the Fan

- Secure the Mounting Bracket:** Attach the mounting bracket to a ceiling joist or an outlet box rated for ceiling fan support. Use appropriate hardware.
- Assemble Downrod:** Select the desired downrod (6", 12", or 24") based on your ceiling height. For ceilings 10 to 13

feet high, longer downrods are generally preferred. Feed the electrical wires through the downrod.

3. **Attach Downrod to Motor:** Secure the downrod to the fan motor housing.
4. **Hang the Fan:** Carefully lift the fan assembly and hang it on the mounting bracket.

5.2 Wiring Connections

Connect the fan's electrical wires to the household wiring according to the provided wiring diagram. Ensure all connections are secure and insulated with wire nuts.

5.3 Attaching Blades

Attach the 10 fan blades to the motor housing using the provided screws. The blades are dual-finish, allowing you to choose between matte black or a wood grain appearance.

5.4 Installing the Light Kit

Connect the LED light kit wires to the fan's light kit wires. Secure the light kit to the bottom of the fan motor housing.



Image 5.1: Fan suitability for various ceiling heights.

6. OPERATING INSTRUCTIONS

Your Breezary ceiling fan is operated using the included multi-function remote control.

6.1 Remote Control Functions



Image 6.1: Remote control layout and functions.

- **ALL OFF:** Turns off both the fan and the light.
- **LIGHT ON/OFF:** Toggles the light on or off.
- **Buzzer Mute:** Turns off the beep sound from the remote for quiet operation.
- **Fan Speeds (1-6):** Adjusts the fan speed from 1 (lowest) to 6 (highest).
 - Speed 1-2: Low comfortable wind, ideal for sleep.
 - Speed 3-4: Medium natural wind, suitable for work.
 - Speed 5-6: High cooling wind, for active environments.
- **Forward Rotating (F):** Sets the fan to rotate clockwise, pushing air downwards for a cooling effect (Summer Mode).

- **Reversal Rotating (R):** Sets the fan to rotate counter-clockwise, drawing air upwards to circulate warm air (Winter Mode).
- **Timer (1H, 2H, 4H):** Sets the fan to turn off automatically after 1, 2, or 4 hours.

6 FAN SPEEDS

Choose the wind speed



Speed 1-2 
Low comfortable wind



Speed 3-4  
Medium natural wind



Speed 5-6   
High cooling wind

Image 6.2: Fan speed settings.

REVERSIBLE DC MOTOR

Cool in summer, Warm in winter




Image 6.3: Reversible DC motor for year-round comfort.

6.2 Light Operation

The integrated 24W LED light offers three color temperature options: 3000K (Warm Light), 4000K (Natural Light), and 6000K (Cool White Light). Press the light button on the remote to cycle through these options. Note that the light is not dimmable and does not retain the last color temperature setting after being turned off.

3 COLOR TEMPERATURE ADJUSTABLE

3 color Light with memory function meet your needs



Image 6.4: 3 Color Temperature (CCT) options.

6.3 Quiet Operation

The fan features a quiet DC motor, operating at under 35 dB, ensuring minimal noise disturbance during use.



Image 6.5: Noise level comparison.

7. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your ceiling fan.

- **Cleaning:** To clean the fan, wipe the blades and motor housing with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these can damage the finish.
- **Dusting:** Periodically dust the fan blades and light kit to prevent dust buildup, which can affect performance and light output.
- **Tighten Fasteners:** Check all screws and fasteners on the fan and mounting hardware periodically to ensure they are secure. Loose connections can cause noise or wobble.
- **No Lubrication Needed:** The DC motor is permanently lubricated and does not require oiling.

Always ensure the power is turned off at the circuit breaker before performing any cleaning or maintenance.

8. TROUBLESHOOTING

If you experience issues with your ceiling fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Remote control battery low or not paired.	Check circuit breaker and wall switch; Verify all wire connections are secure; Replace remote battery or re-pair remote (refer to remote pairing instructions if available).
Light does not work	Loose wire connection to light kit; Faulty LED module.	Check light kit wiring connections; Contact customer support if LED module is faulty.
Fan wobbles	Loose blade screws; Unbalanced blades; Loose mounting bracket.	Ensure all blade screws are tight; Use a balancing kit (not included) if necessary; Tighten mounting bracket screws.
Remote control not responding	Low or dead battery; Remote not paired with fan; Obstruction between remote and receiver.	Replace remote battery; Re-pair remote with fan (if applicable); Ensure clear line of sight to fan.
Fan makes excessive noise	Loose screws; Motor hum (normal for DC motors); Blades hitting an obstruction.	Check and tighten all screws; Ensure no obstructions are near blades; If noise persists, contact customer support.

9. WARRANTY AND CUSTOMER SUPPORT

For warranty information, please refer to the documentation included with your purchase or contact the retailer. Breezary is committed to customer satisfaction.

Our dedicated and responsive customer service team is available 24/7 to assist you. Should you encounter any issues during installation or usage, please do not hesitate to reach out. We are committed to addressing your concerns promptly and ensuring your complete satisfaction.

Contact Information: Please refer to your purchase receipt or the manufacturer's website for the most current customer support contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question