

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [COMFIER](#) /

› [COMFIER Foot Spa Bath Massager CF-5415 Instruction Manual](#)

COMFIER CF-5415

COMFIER Foot Spa Bath Massager CF-5415 Instruction Manual

Model: CF-5415

INTRODUCTION

This manual provides detailed instructions for the safe and effective use of your COMFIER Foot Spa Bath Massager. Please read this manual thoroughly before operation and retain it for future reference. The COMFIER Foot Spa is designed to provide a relaxing foot bath experience with features such as heat, bubbles, red light, and massage rollers.



Image: A woman relaxing with her feet in the COMFIER Foot Spa, demonstrating its soothing heat with adjustable temperature.

IMPORTANT SAFETY INFORMATION

WARNING: To reduce the risk of electric shock, burns, fire, or injury:

- Always unplug the appliance from the electrical outlet immediately after using and before cleaning.
- Do not use while bathing or in a shower.
- Do not place or store appliance where it can fall or be pulled into a tub or sink.
- Do not place in or drop into water or other liquid.
- Do not reach for an appliance that has fallen into water. Unplug it immediately.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped or damaged, or dropped into water.
- Keep the cord away from heated surfaces.
- Never use while sleeping or drowsy.
- Do not use outdoors.
- Do not use on sensitive skin areas or where circulation is poor.
- Supervise children and individuals with reduced physical, sensory, or mental capabilities.
- Ensure the unit is fully expanded and stable before filling with water and operating.

- Do not use without water.

Legal Disclaimer: Actual product packaging and materials may contain more and different information than what is shown on our website. We recommend that you do not rely solely on the information presented and that you always read labels, warnings, and directions before using or consuming a product.

PRODUCT FEATURES

- **Relaxing Foot Massage:** Features 6 sets of 3D massage rollers designed to target acupressure points on the soles. Includes a built-in pumice stone for dead skin removal. (Note: Rollers are manual, not motorized.)
- **Smart Temperature Control:** Adjustable heating from 95°F to 118°F (35°C to 48°C), with a default setting of 107°F (41.6°C).
- **Customizable Timer Settings:** Built-in timer with settings for 10, 20, 30, 40, 50, or 60 minutes. Default setting is 30 minutes.
- **Bubbles & Red Light Function:** Continuous stream of oxygen bubbles for a hot-spring-like effect, combined with red light for a soothing spa experience.
- **Collapsible & Easy to Store:** Foldable design collapses to 4.1 inches (10.4 cm) in height for convenient storage.

Collapsible & Easy to Store



Image: Overview of the COMFIER Foot Spa highlighting its control panel, bubbles, massage rollers, pumice stone, red light, and support rod.

SETUP INSTRUCTIONS

- 1. Unpack the Unit:** Carefully remove the foot spa from its packaging.
- 2. Expand the Foot Spa:** Place the collapsed unit on a flat, stable surface. Gently pull up the sides to fully expand the foot spa until it locks into place. Ensure the support rod is engaged for stability.
- 3. Fill with Water:** Fill the foot spa with warm water to the indicated maximum fill line. Do not overfill. For optimal heating, start with warm water.
- 4. Connect Power:** Plug the power cord into a suitable electrical outlet.

Soothing Heat with Adjustable Temp

Relax your feet after whole day walk



Image: A person expanding the collapsible foot spa and preparing it for use.

Your browser does not support the video tag.

Video: Official COMFIER video demonstrating the setup and use of the foot spa bath massager.


OPERATING INSTRUCTIONS

- Power On:** Press the **ON/OFF** button on the control panel to turn on the foot spa. The default temperature is 107°F (41.6°C) and the default timer is 30 minutes.
- Adjust Temperature:** Use the **TEMP+** and **TEMP-** buttons to set your desired water temperature between 95°F (35°C) and 118°F (48°C).
- Set Timer:** Press the **TIMER** button to cycle through available time settings: 10, 20, 30, 40, 50, or 60 minutes.

4. **Activate Bubbles:** Press the **BUBBLE** button to turn on the bubble function. Press again to turn off.
5. **Activate Red Light:** Press the **RED LIGHT** button to turn on the red light function. Press again to turn off.
6. **Use Massage Rollers:** Place your feet on the manual massage rollers. Gently move your feet back and forth over the rollers to experience the shiatsu massage. Adjust pressure as desired.
7. **Use Pumice Stone:** Position your heel or other areas of your foot over the built-in pumice stone and gently rub to exfoliate dead skin.
8. **Power Off:** Once your session is complete, press the **ON/OFF** button to turn off the unit.

8 Deep Kneading Shiatsu Massage Rollers

Enjoy spa-like foot baths at home



Shiatsu Massage



Rolling Massage



Pressing Massage

Image: A user's feet in the foot spa, with a close-up view of the control panel showing temperature and function buttons.

MAINTENANCE

- **Draining Water:** After each use, unplug the unit and carefully pour out the water.

- **Cleaning:** Wipe the interior and exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or immerse the control panel in water.
- **Storage:** Ensure the unit is completely dry before collapsing it. Press down on the sides to fold the foot spa to its compact size. Store in a cool, dry place away from direct sunlight.



Image: The foot spa in its collapsed state, easily stored under furniture, demonstrating its space-saving design.

TROUBLESHOOTING

If you encounter any issues with your COMFIER Foot Spa, please refer to the following common solutions:

- **Unit does not power on:** Ensure the power cord is securely plugged into a working electrical outlet. Check if the outlet has power.
- **Water is not heating:** Verify that the temperature setting is activated and set to your desired temperature.

Ensure the unit is filled with water above the minimum level.

- **Bubbles or red light not working:** Confirm that the respective function buttons have been pressed to activate them.
- **Unit leaks:** Check for any cracks or damage to the basin. Ensure the unit is fully expanded and locked into place before filling.

For further assistance, please contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	COMFIER
Model Number	CF-5415
Product Dimensions (Expanded)	34.5L x 11.5W x 42.5H Centimetres (approx. 13.6L x 4.5W x 16.7H inches)
Product Dimensions (Collapsed)	Approx. 4.1 inches (10.4 cm) height
Item Weight	2 Kilograms (approx. 4.4 lbs)
Material	Plastic
Power Source	Corded Electric
Temperature Range	95°F to 118°F (35°C to 48°C)
Special Feature	Foldable
Color	Black

WARRANTY AND SUPPORT

Your COMFIER Foot Spa Bath Massager comes with 30-day after-sale support. If you have any questions, concerns, or require assistance with your product, please feel free to contact COMFIER customer support via Amazon's messaging system. Please refer to your purchase details for specific warranty terms and conditions.