

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [WE-VIBE](#) /

› [We-Vibe Temp Lay-On Vibrator User Manual](#)

WE-VIBE 4251460626101

We-Vibe Temp Lay-On Vibrator User Manual

Model: 4251460626101 | Brand: WE-VIBE

INTRODUCTION

Thank you for choosing the We-Vibe Temp Lay-On Vibrator. This device is designed to provide unique sensations through its heating and cooling functions, combined with powerful vibrations. Please read this manual thoroughly before use to ensure safe and optimal operation.

SAFETY INFORMATION

- This device is intended for external use only.
- Do not use if the device appears damaged or compromised.
- Clean the device thoroughly before and after each use as instructed in the Maintenance section.
- Use only with water-based lubricants. Oil-based lubricants may damage the silicone material.
- Keep out of reach of children.
- If you experience any discomfort or irritation, discontinue use immediately.
- Consult a healthcare professional if you have any medical conditions or concerns regarding use.

PACKAGE CONTENTS

The We-Vibe Temp package includes:

- We-Vibe Temp Lay-On Vibrator
- USB Charging Cable
- User Manual (this document)
- Storage Pouch (may vary by region)

PRODUCT OVERVIEW

The We-Vibe Temp features an ergonomic design with intuitive controls for vibration, heating, and cooling functions.



Image: We-Vibe Temp device with its control buttons and charging port clearly indicated. The buttons are for heat, cool, and vibration, and the device is shown with a magnetic charging cable attached.

- **Power/Vibration Button:** Controls power on/off and cycles through vibration patterns and intensities.
- **Heat Button:** Activates the warming function.
- **Cool Button:** Activates the cooling function.
- **Temperature Plate:** The metallic surface on the device that provides heating and cooling sensations.
- **Charging Port:** Magnetic port for USB charging cable.

CHARGING

Before first use, fully charge your We-Vibe Temp. A full charge typically takes approximately 90 minutes and provides up to 90 minutes of use, depending on the settings.

1. Connect the magnetic end of the USB charging cable to the charging port on the device.
2. Connect the USB-A end of the cable to a USB power adapter (not included) or a computer's USB port.

3. The indicator light on the device will pulse while charging and remain solid when fully charged.
4. Disconnect the charger once fully charged.

SETUP

Ensure the device is fully charged before initial use. Clean the device as per the "Cleaning and Maintenance" section.




Image: A hand holding the We-Vibe Temp, emphasizing its ergonomic shape and soft-touch silicone material, along with its waterproof capabilities.

For optimal experience, apply a generous amount of water-based lubricant to the device and the desired area of the body.

OPERATING INSTRUCTIONS

Power On/Off and Vibration Control

1. To turn on, press and hold the Power/Vibration button for 2 seconds. The device will start vibrating at the lowest setting.

2. Press the Power/Vibration button repeatedly to cycle through 3 vibration intensities and 3 vibration patterns.
3. To turn off, press and hold the Power/Vibration button for 2 seconds.

Heating Function



Image: The We-Vibe Temp device illustrating its temperature capabilities, with indicators for 38°C (100°F) warming and 20°C (68°F) cooling.

1. Press the Heat button to activate the warming function. The temperature plate will begin to warm up.
2. The device can reach a warming temperature of approximately 38°C (100°F).
3. Press the Heat button again to turn off the warming function.

Cooling Function

1. Press the Cool button to activate the cooling function. The temperature plate will begin to cool down.
2. The device can reach a cooling temperature of approximately 20°C (68°F).
3. Press the Cool button again to turn off the cooling function.

You can use the vibration, heating, and cooling functions independently or in combination for varied sensations.

CLEANING AND MAINTENANCE

Proper cleaning and maintenance ensure hygiene and prolong the lifespan of your We-Vibe Temp.

1. Clean the device thoroughly before and after each use.
2. Wash the device with warm water and a mild soap or a specialized toy cleaner.
3. Rinse thoroughly with clean water.
4. Dry completely with a lint-free cloth.
5. Do not use cleaners containing alcohol, petroleum, or acetone, as these can damage the silicone.
6. The device is 100% waterproof (IPX7 rated) and can be rinsed under running water or submerged for cleaning.

STORAGE

Store your We-Vibe Temp in a clean, dry, and dust-free environment, away from direct sunlight and extreme temperatures. Keep it separate from other toys made of different materials to prevent potential damage or reactions.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	Low battery.	Charge the device fully.
Vibrations are weak or inconsistent.	Low battery.	Charge the device fully.
Heating/Cooling function not working.	Low battery or function not activated correctly.	Ensure device is charged. Press the respective button firmly.
Device not charging.	Improper cable connection or faulty charger.	Ensure the magnetic cable is securely connected. Try a different USB port or power adapter.

If troubleshooting steps do not resolve the issue, please contact customer support.

SPECIFICATIONS

- **Model Number:** 4251460626101
- **Material:** Body-safe Silicone
- **Dimensions:** 3.94 x 6.3 x 2.76 inches
- **Weight:** 12.2 ounces
- **Battery:** Rechargeable Nonstandard Battery (included)
- **Charging Time:** Approximately 90 minutes
- **Run Time:** Up to 90 minutes (depending on settings)
- **Water Resistance:** IPX7 (100% waterproof)
- **Warming Temperature:** Up to 38°C (100°F)
- **Cooling Temperature:** Down to 20°C (68°F)
- **Manufacturer:** WOW Tech

WARRANTY INFORMATION

We-Vibe products are manufactured to the highest quality standards. For detailed warranty information, please refer to the warranty card included with your product or visit the official We-Vibe website. Keep your proof of purchase for warranty claims.

CUSTOMER SUPPORT

If you have any questions, concerns, or require assistance with your We-Vibe Temp, please contact We-Vibe customer support through their official website or the contact information provided in your product packaging.

Website: www.we-vibe.com