JBL JBLGRIPPUR

JBL GRIP Portable Bluetooth Speaker User Manual

Model: JBLGRIPPUR

INTRODUCTION

The JBL GRIP is a compact, portable Bluetooth speaker designed to deliver powerful JBL Pro Sound. It features AI Sound Boost technology for optimized audio output with minimal distortion. With its durable, dustproof, and waterproof design, the JBL GRIP is suitable for various environments and activities. This manual provides essential information for the proper use and maintenance of your speaker.

Image: The JBL GRIP speaker lineup in different colors, highlighting its portability.

WHAT'S IN THE BOX

Upon unboxing your JBL GRIP speaker, please ensure all components are present:

- JBL GRIP Portable Bluetooth Speaker
- Quick Start Guide
- USB-C Charging Cable (Note: USB charging cable is not included in some regions, please check packaging)

Image: A purple JBL GRIP speaker, representing the main product.

PRODUCT OVERVIEW

Familiarize yourself with the key features and components of your JBL GRIP speaker.

Controls and Ports

- **Power Button:** Located on the top panel.
- **Bluetooth Pairing Button:** Located on the top panel, for connecting to devices.
- **Play/Pause Button:** Located on the top panel.
- **Volume Up/Down Buttons:** Located on the top panel.
- **USB-C Charging Port:** Located on the side panel, protected by a cover.
- **Ambient Light:** Integrated on the side panel, offering customizable lighting effects.

Image: Top view of the JBL GRIP speaker, highlighting the control buttons.

Image: Side view of the JBL GRIP speaker, showing the USB-C charging port and the ambient light strip.

Key Features

- **AI Sound Boost:** Real-time music analysis algorithm optimizes output and suppresses distortion for enhanced sound quality.
- **IP68 Dustproof and Waterproof:** Designed to withstand immersion in water and protect against dust ingress.
- **Ambient Light:** Customizable LED light on the speaker's rear panel to set the mood.
- **Long Playback Time:** Up to 12 hours of continuous playback, extendable by an additional 2 hours with Playtime Boost.
- **Aura Cast Multi-Speaker Connection:** Connect multiple JBL GRIP speakers for a wider sound experience.
- **JBL Portable App Compatibility:** Control settings, customize ambient light, and manage features via the dedicated app.

Image: An internal diagram of the JBL GRIP speaker, illustrating the AI Sound Boost chip and dual passive radiators for enhanced bass.

SETUP

Charging the Speaker

1. Locate the USB-C charging port on the side of the speaker.
2. Open the protective cover of the USB-C port.
3. Connect one end of the USB-C charging cable to the speaker and the other end to a compatible USB power adapter (not included).
4. The LED indicator will show charging status. A full charge takes approximately 3 hours.
5. Once fully charged, disconnect the cable and securely close the protective cover to maintain IP68 rating.

Bluetooth Pairing

1. Power on the JBL GRIP speaker by pressing the Power button.
2. Press the Bluetooth button on the top panel. The LED indicator will flash, indicating pairing mode.
3. On your device (smartphone, tablet, etc.), go to Bluetooth settings and select "JBL GRIP" from the list of available devices.
4. Once connected, the LED indicator on the speaker will turn solid.

OPERATING INSTRUCTIONS

Basic Playback

- **Play/Pause:** Press the Play/Pause button once.
- **Volume Control:** Use the Volume Up (+) and Volume Down (-) buttons.
- **Skip Track:** Double-press the Play/Pause button for next track. Triple-press for previous track.

Ambient Light Control

The JBL GRIP features an ambient light that can be customized to match your mood.

- **Default Modes:** Cycle through pre-set light themes by pressing the dedicated light button (if available, otherwise use app).
- **Customization:** For advanced customization of brightness and color, download and use the JBL Portable app.

音質に特化したAI技術の
「AI Sound Boost」

AI Sound Boost で
小音量でもソリッドな低音再生

JBL GRIP

43x80mm
長円形ドライバーユニット

対向式デュアル・
パッシブラジエーター

Image: A JBL GRIP speaker displaying its customizable ambient light feature.

Aura Cast Multi-Speaker Connection

Aura Cast allows you to connect multiple JBL GRIP speakers for a synchronized audio experience.

1. Ensure all JBL GRIP speakers are powered on and in pairing mode.
2. Follow the instructions in the JBL Portable app to initiate Aura Cast pairing.
3. Once connected, audio will play simultaneously across all linked speakers.

Image: A visual representation of multiple JBL speakers connected using Aura Cast for multi-room audio.

JBL Portable App

Download the JBL Portable app from your device's app store to unlock additional features and control options for your JBL GRIP speaker. The app allows you to:

- Adjust equalizer settings.
- Customize ambient light themes and brightness.
- Manage Aura Cast connections.
- Update speaker firmware.

JBL GRIP

※充電用USBケーブルは非同梱

重量：390g

奥行65.2mm

152.5mm

64mm

Image: A screenshot of the JBL Portable app interface, showing customization options for sound and lighting.

MAINTENANCE

Waterproof and Dustproof (IP68)

The JBL GRIP speaker is rated IP68, meaning it is dust-tight and protected against continuous immersion in water up to 1.5 meters for up to 30 minutes. To maintain this rating:

- Ensure the USB-C port cover is securely closed before exposing the speaker to water or dust.
- Do not expose the speaker to salt water or other chemicals. If exposed, rinse with fresh water and dry thoroughly.
- Avoid using the speaker in extreme temperatures.

ムードを醸成する
カスタマイズ可能な
アンビエントライト搭載

JBL GRIP

Image: A JBL GRIP speaker in water, demonstrating its IP68 waterproof capability.

Cleaning

To clean your speaker, use a soft, damp cloth. Do not use abrasive cleaners or solvents.

TROUBLESHOOTING

Problem	Possible Solution
Speaker does not power on.	Ensure the battery is charged. Connect the speaker to a power source using the USB-C cable.

Problem	Possible Solution
Cannot pair via Bluetooth.	• Ensure the speaker is in pairing mode (flashing Bluetooth LED). • Check that Bluetooth is enabled on your device. • Move the speaker closer to your device. • Try unpairing and re-pairing the device.
No sound or low volume.	• Adjust the volume on both the speaker and your connected device. • Ensure the speaker is properly connected via Bluetooth. • Check for any obstructions between the speaker and your device.
Ambient light not working.	Check settings in the JBL Portable app. Ensure the speaker is powered on.

SPECIFICATIONS

Feature	Detail
Model Name	JBL GRIP
Product Model Number	JBLGRIPPUR
Speaker Type	Portable Speaker
Wireless Technology	Bluetooth
Frequency Band	2400MHz - 2483.5MHz
Frequency Response	20 KHz
Max Output Power	16 W
Power Source	Battery (Lithium Ion)
Battery Life	Up to 12 hours (extendable by 2 hours with Playtime Boost)
Charging Time	Approximately 3 hours
Waterproof/Dustproof Rating	IP68
Product Dimensions (D x W x H)	6.5 x 6.4 x 15.3 cm
Product Weight	385 grams
Control Method	App
Included Components	Quick Start Guide

12時間の連続再生が可能
少し延長したいときは
Playtime Boostで2時間延長も

JBL GRIP

Image: A diagram illustrating the dimensions and weight of the JBL GRIP speaker.

WARRANTY AND SUPPORT

The JBL GRIP speaker comes with a limited warranty. Please refer to the included Quick Start Guide or visit the official JBL website for detailed warranty information and support contacts.

For technical assistance, troubleshooting, or to register your product, please visit www.jbl.com/support.