

Beautyrest Luxaire

Beautyrest Luxaire 20-Inch Queen Luxury Air Mattress User Manual

Model: Luxaire | Brand: Beautyrest

1. IMPORTANT SAFETY INFORMATION

Please read and understand all safety warnings and instructions before using your Beautyrest Luxaire air mattress. Failure to follow these instructions may result in injury or product damage.

- **Proper Inflation/Deflation:** Always ensure the air mattress is properly inflated and deflated according to these instructions.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 750 pounds (340 kg). Overloading can cause damage to the mattress and potential injury.
- **Children and Pets:** Keep children and pets away from the air mattress during inflation and deflation, and when in use, to prevent suffocation risks.
- **Sharp Objects:** Keep the mattress away from sharp objects, heat sources, and open flames.
- **Surface:** Place the air mattress on a flat, clear surface free of debris to prevent punctures.
- **Electrical Safety:** Ensure the power outlet used for the pump is easily accessible and that the power cord is not pinched or damaged. Do not operate the pump with wet hands or in wet conditions.

2. PRODUCT OVERVIEW

The Beautyrest Luxaire 20-inch Queen Luxury Air Mattress is designed for comfort and convenience, featuring advanced technology for a superior sleeping experience. Its robust construction and smart pump system make it ideal for guest rooms, camping, or temporary sleeping arrangements.



Figure 2.1: Beautyrest Luxaire 20-inch Queen Air Mattress.

Key Features:

- **Smart Auto Shut-Off Pump:** Integrated pump for one-touch inflation and deflation, with pressure-sensing technology to prevent over-inflation and motor burnout.
- **Cool Vent Top:** Double-thick sculpted top surface with Cool Vent technology promotes airflow for temperature regulation.
- **Structural Stability:** Reinforced with sturdy horizontal beam construction and stabilizing angle beams to minimize motion transfer and swaying.
- **No Sag Raised Edge Support:** Provides enhanced stability and prevents roll-off.
- **Durable Fabric:** Puncture-resistant, no-stretch Ever Firm fabric ensures longevity and consistent firmness.
- **Portable Design:** Includes a sturdy carry bag for easy transport and storage.

3. SETUP INSTRUCTIONS

Follow these steps to set up your Beautyrest Luxaire air mattress:

1. **Unpack:** Remove the air mattress and carry bag from its packaging.
2. **Unfold:** Place the folded mattress on a clean, flat, and smooth surface. Ensure there are no sharp objects underneath that could puncture the mattress.



Figure 3.1: The Beautyrest Luxaire air mattress unfolded and ready for inflation.

3. **Locate Pump:** Identify the integrated electric pump on the side of the mattress.
4. **Power Connection:** Plug the pump's power cord into a standard electrical outlet (120V AC).

4. OPERATING INSTRUCTIONS

The Beautyrest Luxaire air mattress features a Smart Auto Shut-Off Pump for effortless inflation and deflation.

Your browser does not support the video tag.

Video 4.1: Official video demonstrating the setup, inflation, and key features of the Beautyrest Luxaire air mattress, including the auto shut-off pump and cool vent top.

4.1. Inflation

1. **Initiate Inflation:** Locate the pump control panel. Press the "INFLATE" button. The pump will begin to inflate the mattress.




Figure 4.1.1: Close-up of the pump control panel with "INFLATE" and "DEFLATE" buttons.

2. **Auto Shut-Off:** The smart pump is designed to automatically shut off once the mattress reaches optimal firmness. You do not need to monitor the inflation process.
3. **Adjust Firmness (Optional):** If you prefer a softer mattress, you can briefly press the "DEFLATE/ADJUST" button to release a small amount of air. To increase firmness, press "INFLATE" again briefly.
4. **Disconnect:** Once inflated to your desired firmness, unplug the power cord from the outlet.

4.2. Deflation

1. **Initiate Deflation:** Plug the pump's power cord back into the electrical outlet. Press the "DEFLATE/ADJUST" button. The pump will begin to extract air from the mattress.
2. **Auto Shut-Off:** The pump will automatically shut off once the mattress is fully deflated.
3. **Fold and Store:** After deflation, carefully fold the mattress to remove any remaining air and prepare it for storage in the included carry bag.

5. MAINTENANCE AND CARE

Proper care will extend the life of your Beautyrest Luxaire air mattress.

- **Cleaning:** Spot clean only. Use a mild soap and damp cloth to clean soiled areas. Do not use harsh

chemicals or abrasive cleaners.

- **Drying:** Ensure the mattress is completely dry before folding and storing to prevent mold or mildew.
- **Do Not Machine Wash:** The air mattress is not machine washable.
- **Avoid Over-Inflation:** The auto shut-off pump helps prevent over-inflation, which can stress seams and material.
- **Puncture Prevention:** Always place the mattress on a clean, smooth surface. Avoid dragging the mattress over rough terrain.

6. STORAGE

When not in use, store your air mattress properly to maintain its condition.

1. **Deflate Completely:** Ensure the mattress is fully deflated using the pump's deflate function.
2. **Fold Neatly:** Fold the mattress carefully to remove any residual air and minimize its size.



Figure 6.1: The air mattress neatly folded and placed into its carry bag.

3. **Use Carry Bag:** Place the folded mattress into the included sturdy carry bag.
4. **Store in Cool, Dry Place:** Store the mattress in a cool, dry location away from direct sunlight and extreme temperatures.

7. TROUBLESHOOTING

Here are some common issues and their solutions:

Problem	Possible Cause	Solution
Mattress not inflating.	Power cord not plugged in; pump switch not in "INFLATE" position; power outage.	Ensure the power cord is securely plugged into a working outlet. Verify the pump switch is set to "INFLATE". Check your power supply.
Mattress losing air.	Valve not fully closed; small puncture; pump housing not sealed.	Ensure the pump's external cap is securely closed. Inspect the mattress for small holes or leaks. Check that the pump housing is properly seated and sealed.

Problem	Possible Cause	Solution
Pump not turning off automatically.	Sensor malfunction; extreme temperature conditions affecting sensor.	Manually turn off the pump once desired firmness is reached. If the issue persists, contact customer support.
Mattress feels too soft/firm.	Personal preference; initial stretch of material.	Adjust firmness using the "INFLATE" or "DEFLATE/ADJUST" buttons. New air mattresses may stretch slightly after initial use; re-inflate as needed.

8. SPECIFICATIONS

Feature	Detail
Model Name	Luxaire
Size	Queen
Product Dimensions (Inflated)	80"L x 60"W x 20"Th
Weight Capacity	750 Pounds (340 kg)
Item Weight	15.5 Pounds (7.03 kg)
Material	Cool Vent Double-thick Fabric, Vinyl
Special Features	Auto Shut-off Pump, Cool Vent Top, No Sag Raised Edge Support, Stabilizing Angle Beams, Sturdy Horizontal Beam Construction
Included Components	Air Mattress, Carry Bag
UPC	612650649944
ASIN	B0FPGPT78S

9. WARRANTY INFORMATION

Specific warranty details for the Beautyrest Luxaire air mattress are typically provided with the product packaging or can be found on the manufacturer's official website. Please refer to the documentation included with your purchase for the most accurate and up-to-date warranty terms and conditions.

Generally, warranties cover manufacturing defects under normal use. Keep your proof of purchase for any warranty claims.

10. SUPPORT AND CONTACT

For further assistance, troubleshooting not covered in this manual, or to inquire about warranty services, please contact Beautyrest customer support.

- **Manufacturer:** Beautyrest
- **Online Support:** Visit the official Beautyrest website for FAQs, support resources, and contact information. You can often find this by searching for "Beautyrest customer support" online.
- **Retailer Support:** If purchased from a retailer, their customer service department may also be able to assist with product-related inquiries or direct you to the appropriate support channel.