

[Manuals.plus](#) /

> [Wonderlit](#) /

> Wonderlit LED Spaceman 3D Firework Light Instruction Manual WL-FRSPCM-WOD

Wonderlit WL-FRSPCM-WOD

Wonderlit LED Spaceman 3D Firework Light

MODEL: WL-FRSPCM-WOD

1. Introduction

Thank you for choosing the Wonderlit LED Spaceman 3D Firework Light. This product is designed to provide ambient lighting with a unique 3D firework effect, featuring multiple colors and a distinctive spaceman design. This manual provides essential information for the safe and effective use of your device.

2. Safety Information

- Read all instructions before use and retain for future reference.
- This product is for indoor use only. Avoid exposure to direct sunlight or extreme temperatures.
- Do not immerse the device in water or expose it to excessive moisture. The IP43 rating indicates protection against light water spray, but it is not waterproof.
- Handle the light unit with care. It is made of acrylic and can be damaged if dropped or subjected to strong impact.
- Use only the provided USB cable or a certified equivalent. Ensure the power source is compatible with USB 5V.
- Keep out of reach of children and pets.
- Do not attempt to disassemble or modify the product. This will void the warranty and may cause damage or injury.
- Unplug the device from the power source before cleaning or when not in use for extended periods.

3. Package Contents

Please check the package for the following items:

- Wonderlit LED Spaceman 3D Firework Light Unit (with integrated wooden base)

- USB Power Cable

4. Setup

1. **Unpack the Device:** Carefully remove the LED Spaceman 3D Firework Light from its packaging.
2. **Placement:** Place the light on a stable, flat surface. Ensure there is adequate space around the unit for optimal light projection. The sturdy wooden base provides stability.
3. **Connect Power:** Insert the small end of the USB power cable into the USB port located on the back or side of the wooden base. Connect the larger end of the USB cable to a compatible USB power adapter (not included) or a USB port on a computer or power bank.



Image 4.1: The Spaceman light placed on a bedside table, illustrating typical setup and connection.

5. Operating Instructions

The Wonderlit LED Spaceman 3D Firework Light is operated using a single push button located on the device.

1. **Power On/Off:** Press the button once to turn the light on. Press it again to turn the light off.
2. **Change Colors/Modes:** When the light is on, press the button repeatedly to cycle through the

available 8 vibrant colors and various lighting modes. One of the modes includes a slow fade between colors.

3. **Continuous Lighting:** The device supports continuous lighting operation, allowing for extended use to maintain your desired ambient atmosphere.



Image 5.1: The Spaceman light displaying a green and blue firework effect, demonstrating one of its many color options.



Image 5.2: The Spaceman light illuminating a room with a purple firework effect, showcasing its ambient capabilities.

6. Maintenance

- **Cleaning:** Ensure the device is unplugged before cleaning. Use a soft, dry, lint-free cloth to gently wipe the surface of the light unit and the wooden base. Do not use abrasive cleaners, solvents, or chemical sprays, as these may damage the acrylic or wood finish.
- **Storage:** When not in use for extended periods, store the light in a cool, dry place, away from direct sunlight and extreme temperatures.

7. Troubleshooting

Problem	Possible Cause	Solution
Light does not turn on.	No power supply or loose connection.	Ensure the USB cable is securely connected to both the light unit and a working USB power source. Try a different USB port or adapter.

Problem	Possible Cause	Solution
Colors do not change.	Button not pressed correctly or device malfunction.	Press the control button firmly and release to cycle through modes. If the issue persists, unplug and replug the device to reset it.
Light appears dim or flickers.	Insufficient power or faulty cable.	Ensure the USB power source provides sufficient power (e.g., 5V/1A). Try using a different USB cable.
Unit is unstable.	Uneven surface.	Place the light on a completely flat and stable surface.

8. Specifications

Feature	Detail
Brand	Wonderlit
Model Number	WL-FRSPCM-WOD
Light Type	LED Night Light
Dimensions (D x W x H)	10.2 x 10.2 x 20.3 cm (approx. 4 x 4 x 8 inches)
Weight	440 g
Power Source	USB Powered
Brightness	40 Lumens
Colors	8 Vibrant Colors (Multi-color RGB)
Material	Acrylic (light unit), Wood (base)
IP Rating	IP43 (Protection against solid objects & light water spray)
Switch Type	Push Button

9. Warranty and Support

Warranty Information: For details regarding the product warranty, please refer to the documentation provided at the time of purchase or visit the official Wonderlit website.

Customer Support: If you encounter any issues or have questions not covered in this manual, please contact Wonderlit customer support for assistance. Contact information can typically be found on the product packaging or the official brand website.