

## ARSHIA SP050-3201

# ARSHIA Spot Cleaner SP050-3201 Instruction Manual

Model: SP050-3201

## INTRODUCTION

Thank you for choosing the ARSHIA Spot Cleaner SP050-3201. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new spot cleaner. Please read these instructions thoroughly before first use and keep them for future reference.

The ARSHIA Spot Cleaner is designed for effective removal of stubborn stains from various surfaces, including sealed hard floors, carpets, upholstery, kitchen and bathroom surfaces, and windows. Its powerful motor and dual tank system ensure a deep and convenient cleaning experience.

## IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury. Read all instructions before using this appliance.

- Always connect to a properly grounded outlet. See grounding instructions.
- Do not leave appliance when plugged in. Unplug from outlet when not in use and before servicing.
- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.

- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce air flow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Turn off all controls before unplugging.
- Use extra care when cleaning on stairs.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use without tanks in place.
- Do not use cleaning solution that is not recommended by the manufacturer.

## PRODUCT COMPONENTS

---

Familiarize yourself with the parts of your ARSHIA Spot Cleaner:

- Main Unit with 750W - 1000W Motor
- Clean Water Tank (1000ml capacity)
- Dirty Water Collection Tank (800ml capacity)
- Flexible Hose with Cleaning Nozzle
- Small Multi-purpose Brush Attachment
- Thick Multi-purpose Brush Attachment
- 5m Power Cord



Image: ARSHIA Spot Cleaner SP050-3201, front view on a rug. This image displays the main unit with its handle, dual tanks, and the flexible hose neatly stored.



Image: ARSHIA Spot Cleaner SP050-3201 with cleaning nozzle and hose. This view highlights the attached cleaning tool, ready for use on various surfaces.

## SETUP GUIDE

Follow these steps for initial setup before using your spot cleaner:

1. **Unpack the Unit:** Carefully remove all components from the packaging. Ensure all parts listed in the "Product Components" section are present.
2. **Attach Cleaning Tool:** Connect the desired cleaning brush attachment (small or thick multi-purpose brush) to the end of the flexible hose. Ensure it clicks securely into place.
3. **Fill the Clean Water Tank:** Remove the clean water tank (usually marked with a blue or clear cap) from the main unit. Fill it with clean water and the recommended ARSHIA cleaning solution up to the MAX fill line. Do not overfill. Securely close the cap and reinsert the tank into the unit.
4. **Check Dirty Water Tank:** Ensure the dirty water collection tank is empty and properly seated in the unit.
5. **Power Connection:** Unwind the 5m power cord and plug the cleaner into a grounded electrical outlet.



Image: ARSHIA Spot Cleaner SP050-3201 out of box, showing tanks and handle. This image provides a clear view of the clean and dirty water tanks, essential for proper setup.

## OPERATING INSTRUCTIONS

---

Before cleaning, always test a small, inconspicuous area for colorfastness. Do not use on silk, wool, or delicate fabrics.

1. **Pre-treat (Optional):** For tough stains, pre-treat the area with a suitable stain remover according to its instructions.
2. **Turn On:** Press the power button located on the top of the unit to turn on the spot cleaner.
3. **Apply Solution:** Hold the cleaning nozzle directly over the stain. Press the trigger on the nozzle to spray cleaning solution onto the stained area.
4. **Scrub the Stain:** Gently scrub the stain with the brush attachment. Use back-and-forth motions to work the solution into the fibers.
5. **Extract Dirty Water:** Release the spray trigger and continue to move the nozzle over the treated area, applying downward pressure. This will suction up the dirty water and cleaning solution into the dirty water tank. Repeat until the stain is removed and no more dirty water is being extracted.
6. **Rinse (Optional):** For best results, you may rinse the area by filling the clean water tank with plain water (no solution) and repeating steps 3-5.
7. **Turn Off:** Once cleaning is complete, press the power button to turn off the unit and unplug it from the outlet.

## MAINTENANCE AND CLEANING

---

Regular maintenance ensures optimal performance and extends the life of your ARSHIA Spot Cleaner.

### After Each Use:

- **Empty and Rinse Dirty Water Tank:** Remove the dirty water tank, empty its contents, and rinse thoroughly with clean water. Allow it to air dry before reattaching.
- **Rinse Clean Water Tank:** If any solution remains, empty and rinse the clean water tank.
- **Clean Nozzle and Brushes:** Detach the cleaning nozzle and brush attachments. Rinse them under running water to remove any debris or residue. Allow them to air dry.
- **Wipe Down Unit:** Wipe the exterior of the main unit with a soft, damp cloth.

### Storage:

Store the spot cleaner in a dry, cool place. Ensure all tanks are empty and dry before storage. Wrap the power cord neatly around the designated cord wraps on the unit.

## TROUBLESHOOTING GUIDE

---

Refer to this section for common issues and their solutions.

| Problem | Possible Cause | Solution |
|---------|----------------|----------|
|---------|----------------|----------|

| Problem               | Possible Cause   | Solution  |
|-----------------------|--|---|
| Unit does not turn on | Not plugged in; Power outlet not working; Power button not pressed.                            | Ensure plug is securely in outlet; Test outlet with another device; Press power button firmly.                                  |
| No spray from nozzle  | Clean water tank empty; Tank not seated correctly; Nozzle clogged; Spray trigger not pressed.  | Refill clean water tank; Re-seat tank firmly; Clean nozzle opening; Press spray trigger.  |
| Poor suction          | Dirty water tank full; Tank not seated correctly; Nozzle or hose clogged; Tank lid not sealed. | Empty dirty water tank; Re-seat tank firmly; Clear any blockages from nozzle or hose; Ensure dirty tank lid is properly sealed. |
| Leaking               | Tanks not seated correctly; Tank caps not closed properly; Damaged tank.                       | Re-seat both tanks; Ensure all caps are tightly closed; Inspect tanks for cracks or damage. Contact support if damaged.         |

## TECHNICAL SPECIFICATIONS

- **Brand:** ARSHIA
- **Model Number:** SP050-3201
- **Power Source:** Corded Electric
- **Motor Power:** 750W - 1000W (Copper Motor)
- **Clean Water Tank Capacity:** 1000 ml
- **Dirty Water Tank Capacity:** 800 ml
- **Total Liquid Capacity:** 1800 ml
- **Extended Reach:** Up to 6.45 meters
- **Power Cord Length:** 5 meters
- **Included Components:** Small multi-purpose brush, Thick multi-purpose brush
- **Item Weight:** 4 kg
- **Color:** Grey & Blue
- **Form Factor:** Canister
- **Style:** Compact
- **Surface Recommendation:** Sealed hard floors, carpets, upholstery, kitchen and bathroom surfaces, windows, and other household surfaces

## WARRANTY AND SUPPORT

The ARSHIA Spot Cleaner SP050-3201 comes with an **18-month warranty** from the date of purchase. This warranty covers manufacturing defects under normal household use.

For warranty claims, technical support, or replacement parts, please contact ARSHIA customer service. Keep your proof of purchase for warranty validation.

For further assistance, please visit the official ARSHIA website or contact your local dealer.

