

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [SUNSEEKER](#) /

> [SUNSEEKER Robot Lawn Mower Garage \(Models X7, X7Plus, X5\) - Instruction Manual](#)

SUNSEEKER SK-X-GARAGE

SUNSEEKER Robot Lawn Mower Garage

MODELS: X7, X7PLUS, X5 (SK-X-GARAGE) - INSTRUCTION MANUAL

1. PRODUCT OVERVIEW

The SUNSEEKER Robot Lawn Mower Garage is designed to provide robust protection for your robotic lawn mower. This accessory ensures your mower remains clean and safe from environmental elements, extending its lifespan and maintaining optimal performance. It is precisely sized for full coverage without obstructing sensors or movement of compatible models.

Key Features

- **Applicable Models:** Compatible with SUNSEEKER X7 series and X5 robotic lawn mowers. Dimensions are 33.74"D x 24.53"W x 19.72"H.
- **Durable Reinforced Structure:** Engineered with reinforced edges for exceptional durability, while maintaining a lightweight design for effortless handling and long-lasting performance.
- **No-Signal Interference:** Constructed from thin yet tough material that allows uninterrupted operation, ensuring no disruption to mower signals.
- **Weather & UV Resistant:** Provides comprehensive protection against rain, sun, and debris to keep your mower clean and damage-free.



Figure 1: Front view of the SUNSEEKER Robot Lawn Mower Garage.



Figure 2: Robotic lawn mower (X7 series) parked inside the SUNSEEKER Garage.

2. SETUP & INSTALLATION

Proper installation of your SUNSEEKER Robot Lawn Mower Garage is crucial for effective protection and seamless operation of your robotic mower. Follow these general guidelines for optimal placement and secure setup.

Placement Considerations

- Choose a flat, stable surface for the garage.
- Ensure the location allows the robotic mower to easily enter and exit the garage without obstruction.
- Position the garage in an area that provides maximum shade and protection from direct sunlight and heavy rain, if possible.
- Verify that the garage does not interfere with the mower's boundary wires or navigation signals.

Sunseeker X series Sunproof Garage



Figure 3: The garage is compatible with both SUNSEEKER X7 and X5 series robotic lawn mowers.

Securing the Garage

- Use appropriate anchors or stakes (not included) to firmly secure the garage to the ground, preventing it from being moved by wind or accidental bumps.
- Ensure the garage is level to allow the mower to dock correctly.

Your browser does not support the video tag.

Video 1: General installation precautions for robotic mowers. While this video is for a specific mower model, the principles of careful placement and securing apply to the installation of the SUNSEEKER Robot Lawn Mower Garage.

3. OPERATING & PROTECTION

The SUNSEEKER Robot Lawn Mower Garage is designed to seamlessly integrate with your robotic mower's operation, providing continuous protection without requiring manual intervention during mowing cycles.

Automatic Protection

- The garage's design allows the robotic mower to automatically drive in and out for scheduled mowing tasks or charging cycles.
- The reinforced structure and weather-resistant materials shield the mower from harsh weather conditions, including rain, intense sunlight, and strong winds.



Figure 4: The garage offers all-weather protection, shielding your mower from sun, rain, and UV for longer life.

Optimized Performance

- The garage's design prevents overheating of the mower by providing shade, ensuring it remains cool and ready for operation.
- The non-interfering material ensures that the mower's signals (e.g., GPS, boundary wires) are not blocked, allowing for precise navigation and efficient mowing.



Figure 5: The garage helps keep the mower cool and efficient, preventing overheating and ensuring it's ready to work anytime.

4. MAINTENANCE

To ensure the longevity and effectiveness of your SUNSEEKER Robot Lawn Mower Garage, regular maintenance is recommended.

- **Cleaning:** Periodically wipe down the exterior of the garage with a damp cloth to remove dirt, dust, and debris. Avoid using harsh chemicals that could damage the material.
- **Inspection:** Regularly check the garage for any signs of wear, tear, or damage, especially after severe weather conditions. Ensure all screws and anchors remain tight.
- **Obstruction Clearance:** Keep the area around and inside the garage clear of leaves, twigs, and other debris that

could obstruct the mower's path or charging contacts.

5. TROUBLESHOOTING

If you encounter any issues with your SUNSEEKER Robot Lawn Mower Garage, refer to the following common troubleshooting tips:

- **Mower not docking correctly:** Ensure the garage is placed on a level surface and is securely anchored. Check for any debris blocking the mower's path or charging contacts.
- **Signal interference:** Although designed to prevent interference, ensure no new metal objects or electronic devices have been placed too close to the garage or mower's charging station.
- **Physical damage:** If the garage shows signs of damage, inspect it for cracks or broken parts. Contact customer support for replacement parts if necessary.

6. SPECIFICATIONS

Specification	Detail
Brand	SUNSEEKER
Model Number	SK-X-GARAGE
Product Dimensions	33.74"D x 24.53"W x 19.72"H
Item Weight	10 Pounds
Material	Plastic
Color	Gary
Assembly Required	Yes

7. WARRANTY & SUPPORT

For warranty information, product support, or to purchase replacement parts, please contact SUNSEEKER customer service. Refer to your purchase documentation for specific warranty terms and contact details.

- **Customer Service:** For assistance, please visit the [SUNSEEKER Store on Amazon](#) or contact the manufacturer directly.
- **Protection Plans:** Extended protection plans are available for purchase separately to cover your product beyond the standard warranty period.

