

[Manuals.plus](#) /

› [PERFASCIN](#) /

› PERFASCIN AKB73598009 Replacement Remote Control User Manual for LG Air Conditioners

## PERFASCIN AKB73598009

# PERFASCIN AKB73598009 Replacement Remote Control User Manual

For LG Air Conditioners

## INTRODUCTION

This manual provides instructions for the PERFASCIN AKB73598009 Replacement Remote Control, designed for use with various LG Air Conditioner models. This remote control offers a straightforward solution for operating your air conditioner without complex setup procedures.

## PRODUCT OVERVIEW

The AKB73598009 remote control is a direct replacement, featuring essential functions for your LG Air Conditioner. It is constructed from durable ABS material for long-term use.



Figure 1: Front view of the AKB73598009 remote control, showing the display and main buttons.



Figure 2: Angled view of the AKB73598009 remote control, highlighting button layout.

## SETUP

### 1. Battery Installation

The remote control requires two AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



MADE IN CHINA

AKB73598009



Figure 3: Back view of the remote control, showing the battery compartment cover.



Figure 4: Open battery compartment, showing where to insert AAA batteries.

## 2. Initial Use

No programming or setup is required for this replacement remote control. Once batteries are installed, it is ready for immediate use with compatible LG Air Conditioner models.

## OPERATING INSTRUCTIONS

Point the remote control directly at the LG Air Conditioner's infrared receiver. Ensure there are no obstructions between the remote and the air conditioner.

### Button Functions:

- **Power Button (Orange):** Turns the air conditioner ON or OFF.
- **Mode Button:** Cycles through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **Temp. Up/Down Arrows:** Adjusts the desired temperature setting.
- **Fan Speed Button:** Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **Energy Saver Button:** Activates or deactivates the energy-saving mode.
- **Sleep Button:** Activates or deactivates sleep mode for quiet operation and energy efficiency during sleep.
- **Timer Button:** Sets the ON/OFF timer for the air conditioner.
- **Clear Button:** Clears current settings or cancels a timer.
- **Diagnosis (5s) Button:** Press and hold for 5 seconds to initiate a self-diagnosis function (refer to your air conditioner's manual for specific diagnosis codes).

## MAINTENANCE

### Cleaning the Remote Control

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as they may damage the surface or internal components.

### Battery Replacement

Replace batteries when the remote control's range decreases or if the display becomes dim. Always replace both batteries simultaneously with new AAA batteries. Remove batteries if the remote control will not be used for an extended period to prevent leakage.

## TROUBLESHOOTING

| Problem                                       | Possible Cause                                              | Solution                                                                                 |
|-----------------------------------------------|-------------------------------------------------------------|------------------------------------------------------------------------------------------|
| Remote control not working.                   | Dead or incorrectly installed batteries.                    | Replace batteries with new ones, ensuring correct polarity.                              |
| Remote control range is poor.                 | Weak batteries; obstruction between remote and AC unit.     | Replace batteries. Ensure a clear line of sight to the air conditioner's receiver.       |
| Air conditioner does not respond to commands. | Remote control not compatible; AC unit is off or unplugged. | Verify compatibility with your specific LG AC model. Check if the AC unit is powered on. |

If the issue persists after attempting these solutions, please refer to the "Support" section for further assistance.

## SPECIFICATIONS

- **Model:** AKB73598009
- **Brand:** PERFASCIN
- **Compatible Devices:** LG Air Conditioners (models including LP1419IVSM, LW1022IVSM, LW8022IVSM, LW1022FVSM, AKB73598011, LW1222IVSM, LW1817IVSM, LW2217IVSM, LW1822IVSM, LW2422IVSM, LW1517IVSM, LW1019IVSM, LW1522IVSM)
- **Connectivity Technology:** Infrared (IR)
- **Controller Type:** Button Control
- **Power Source:** 2 x AAA Batteries (not included)
- **Maximum Range:** Approximately 10 meters (33 feet)
- **Material:** ABS
- **Dimensions (L x W x H):** 6" x 3" x 0.5" (approximate)
- **Special Feature:** No Programming Required

## WARRANTY INFORMATION

---

This product is typically covered by a standard return/replacement policy. For specific warranty details and return procedures, please refer to your purchase documentation or contact the seller directly. The seller, DeFascin Inc, offers a return policy of 30 days for refund or replacement.

## SUPPORT

---

If you encounter any issues or have questions regarding your PERFASCIN AKB73598009 Replacement Remote Control, please contact the seller, DeFascin Inc, through the platform where the purchase was made. They can assist with troubleshooting and provide further guidance.

For information specific to your LG Air Conditioner unit, please consult its original user manual.