

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [USKEYVISION](#) /

› [USKEYVISION Magnetic Mini Selfie Stick MPT-02 Instruction Manual](#)

## USKEYVISION MPT-02

# USKEYVISION Magnetic Mini Selfie Stick MPT-02 Instruction Manual

Your comprehensive guide to setup, operation, and maintenance.

Setup

Operating  
Instructions

Maintenance  
Warranty &  
Support

Troubleshooting

Specifications

## 1. SETUP

### 1.1 Package Contents

Verify that all items are included in your package:

- Magnetic Mini Selfie Stick x1
- LED Fill Light x2
- Phone Clip x1
- USB-C Cable x1
- Magnetic Ring x2
- User Manual x1



Figure 1: Package Contents

## 1.2 Charging the Remote Control and Fill Lights

The detachable remote control and LED fill lights are rechargeable via the included USB-C cable. Connect the cable to the charging port on each device and a suitable power source. A blue indicator light on the remote signifies charging, turning off when fully charged. The fill lights will also indicate their charging status.

Your browser does not support the video tag.

Video 1: Demonstrates the charging process for the detachable remote control and the attachment of the fill lights to the phone holder.

## 1.3 Bluetooth Pairing

1. Turn on the remote control by pressing and holding the button until the indicator light flashes.
2. On your smartphone, navigate to Bluetooth settings.
3. Search for "VIP" in the list of available devices and select it to pair.
4. The indicator light on the remote will stop flashing, indicating a successful connection.

## 1.4 Attaching Your Smartphone

### 1.4.1 For MagSafe Compatible Phones (iPhone 12 Pro Max and above, or MagSafe cases)

Align your MagSafe-compatible phone or case directly with the magnetic ring on the selfie stick's phone holder. The strong magnets will securely attach your phone.



Figure 2: Magnetic Attachment for MagSafe Compatible Phones

#### 1.4.2 For Non-MagSafe Phones

For phones without MagSafe or non-MagSafe cases, use the included adhesive magnetic ring. Peel off the protective film and carefully center the magnetic ring on the back of your phone or case. Press firmly for complete adhesion. It is recommended to wait at least 2 hours after applying before use for optimal bond strength. Once the ring is attached, your phone can be magnetically mounted to the selfie stick.



Figure 3: Magnetic Compatibility and Adhesive Ring Application

## 1.5 Attaching the Phone Clip (Optional)

The selfie stick includes a removable phone clip for additional security or for phones that may not be suitable for magnetic rings. Attach the phone clip to the top of the selfie stick's phone holder. Ensure your smartphone fits within the width range of 2.56-3.54 inches. Foldable phones are not recommended for use with the clip.

## 1.6 Attaching Fill Lights

The two LED fill lights can be attached to the sides of the phone holder. They snap into place securely, providing additional illumination for your photos and videos.

# Removable Fill LED Light

3 Adjustable Colors & 3 Brightness Switch



Figure 4: Removable Fill LED Lights

## 2. OPERATING INSTRUCTIONS

---

### 2.1 Opening the Tripod Legs

To deploy the tripod legs, press the one-touch open button located at the base of the selfie stick. The legs will automatically extend and lock into position, providing a stable base for hands-free use.

# One-Touch Open

## User-friendly and Safe to Open



Figure 5: One-Touch Tripod Opening Mechanism

### 2.2 Selfie Stick Mode

Hold the handle firmly. Extend the telescopic pole to your desired length for wider shots or group photos. The pole extends smoothly and locks at various lengths for flexible framing.

Your browser does not support the video tag.

Video 2: Demonstrates the compact size, extension, and selfie stick functionality of the device, including 360-degree rotation and telescopic reach.

## 2.3 Tripod Mode

With the tripod legs extended, place the selfie stick on a flat, stable surface. Adjust the telescopic pole to achieve your desired height for hands-free recording, live streaming, or video calls.

Your browser does not support the video tag.

Video 3: Shows the magnetic phone attachment, tripod setup, and extension capabilities for various camera types.

## 2.4 Phone Hand Grip Mode

Collapse the telescopic pole and fold the tripod legs. The device can then be used as a comfortable hand grip for more stable handheld shooting, similar to a camera grip.

## 2.5 Adjusting Angles and Orientation

The phone holder offers flexible adjustments:

- **225° Rotation:** Tilt the phone holder up or down to capture high-angle or low-angle shots.
- **360° Rotation:** Rotate your phone horizontally or vertically without removing it from the holder.
- **Sliding Rail:** Fine-tune your composition quickly with the integrated sliding rail.

# Multi-angle Adjustable Tripod

## More Freedom, More Creativity



Figure 6: Multi-Angle Adjustments

### 2.6 Using the Fill Lights

Each LED fill light offers three color modes (white, warm, natural) and three brightness levels. Press the power button on each light to cycle through the modes and brightness settings to adapt to different lighting environments.

Your browser does not support the video tag.

Video 4: Highlights the compact design, magnetic attachment, extendable pole, and the functionality of the detachable fill

## 3. MAINTENANCE

---

- Clean the device with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- Ensure the magnetic surfaces are clean and free of debris for optimal adhesion.
- Store the selfie stick in a cool, dry place away from direct sunlight and extreme temperatures.
- Regularly charge the remote control and fill lights to maintain battery health.

## 4. TROUBLESHOOTING

---

### 4.1 Remote Control Not Connecting

- Ensure the remote control is charged.
- Verify Bluetooth is enabled on your smartphone.
- Try re-pairing the remote control by following the Bluetooth Pairing instructions in Section 1.3.

### 4.2 Phone Not Securely Attached

- For MagSafe phones, ensure the phone or case is MagSafe compatible and properly aligned.
- For non-MagSafe phones, confirm the adhesive magnetic ring is securely attached to your phone or case and has had sufficient time to bond (at least 2 hours).
- Check for any obstructions or debris between the phone and the magnetic holder.

### 4.3 Tripod Instability

- Ensure the tripod legs are fully extended and locked into place.
- Place the tripod on a flat, stable surface.
- Avoid placing heavy objects on the extended pole, especially when fully extended.

## 5. SPECIFICATIONS

---

Feature	Detail
Model Name	MPT-02
Brand	USKEYVISION
Material	Metal
Color	Black
Special Features	Foldable, Lightweight, Remote Control, Telescopic
Compatible Devices	Smartphones (Width of 2.56-3.54", Foldable phones are not recommended)
Batteries	1 Lithium Ion battery required (included)
Product Dimensions (Folded)	12.8 x 8 x 6.9 cm

Product Weight	360 g
----------------	-------

## 6. WARRANTY & SUPPORT

---

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official USKEYVISION website. Keep your proof of purchase for any warranty claims.

© 2026 USKEYVISION. All rights reserved.