EDIFIER EvoBuds Pro

EDIFIER EvoBuds Pro Wireless Earbuds User Manual

Model: EvoBuds Pro

Setup   Operating   Maintenance   Troubleshooting   Specifications   Warranty & Support

1. SETUP

1.1 Product Package Contents

The EDIFIER EvoBuds Pro package includes the following items:

- Earbuds (1 pair)
- Charging Case (1)
- USB-C Charging Cable (0.3m) (1)
- Ear Tips (S/M/L/XL) (4 pairs)
- Instruction Manual (1)
- Safety Precautions (1)

パッケージ内容

① イヤホン本体 ×1ペア

② 充電ケース ×1

③ 充電ケーブル（0.3m）×1

④ イヤーチップ ×4ペア（S/M/L/XL）

⑤ 取扱説明書 ×1

⑥ 安全上の重要事項 ×1

Image: EDIFIER EvoBuds Pro package contents.

1.2 App Download

To unlock full features and customization, download the EDIFIER ConneX app:

1. Search for "EDIFIER ConneX" in your device's app store.
2. Alternatively, scan the QR code provided in the instruction manual or on the product packaging.

EDIFIER ConneX

専用アプリ
「EDIFIER ConneX」

「イコライザー作成」や「ノイキャンモード切替」、
「音量制限」などの様々なアクションを専用アプリ
「EDIFIER ConneX」を通じて、
詳細に設定すること が可能。

Image: EDIFIER ConneX app interface.

1.3 Initial Pairing

Follow these steps for initial device pairing:

1. Open the charging case. The earbuds will automatically enter pairing mode. The LED indicator on the case will blink red and green alternately.
2. On your smartphone, navigate to [Settings] and enable Bluetooth.
3. From the list of available devices, tap "EDIFIER EvoBuds Pro" to connect.
4. Once connected, the LED indicator will blink green once.

1.4 Multi-point Connection

The EDIFIER EvoBuds Pro supports multi-point connection, allowing seamless switching between two paired devices:

1. First, pair the earbuds with your primary device (Device A) as described in the "Initial Pairing" section.

2. With the earbuds in the case and the lid open, press and hold the button on the case for 3 seconds to re-enter pairing mode.

3. Pair the earbuds with your secondary device (Device B) via Bluetooth.

4. Finally, reconnect the earbuds to Device A via Bluetooth. The multi-point connection is now complete, allowing you to switch between Device A and Device B.

安定したワイヤレス接続

Bluetooth®
Bluetooth 6.0を搭載

マルチポイント接続
2つのデバイス間で
シームレスに切り替え

60ms低遅延モード
動画視聴やゲームプレイに最適

Image: Stable Wireless Connection and Multi-point Feature.

2. OPERATING INSTRUCTIONS

2.1 Basic Controls (Pinch Control)

The EvoBuds Pro feature intuitive pinch controls to manage playback and calls:

- **Play/Pause:** Pinch either earbud once.
- **Next Track:** Pinch the right earbud twice.
- **Previous Track:** Pinch the left earbud twice.
- **ANC Mode Switching:** Pinch and hold either earbud. The default switching order is High Noise Cancelling → Ambient Sound.

Note: Control settings can be customized via the EDIFIER ConneX app.

誤操作が起きにくい
ピンチコントロール

※ イヤホンのコントロールはアプリでカスタマイズできます。

通話	
応答/終了	任意側を1回ピンチ
着信拒否	任意側を長ピンチ

音楽	
再生/停止	任意側を1回ピンチ
曲送り	右側を2回ピンチ
曲戻し	左側を2回ピンチ

モード	
ANCモード切替	任意側を長ピンチ

Image: Pinch Control Guide.

2.2 Call Management

- **Answer/End Call:** Pinch either earbud once.
- **Reject Call:** Pinch and hold either earbud.

2.3 Noise Cancelling (ANC) and Ambient Sound Modes

The EvoBuds Pro features a hybrid ANC system with dual microphones, achieving up to -48dB environmental noise reduction. Multiple modes are available for various scenarios:

- **High Noise Cancelling:** For environments with high noise levels (e.g., airplanes, buses).
- **Medium Noise Cancelling:** For moderate noise environments (e.g., office, park).
- **Wind Noise Reduction:** Specifically designed to reduce wind noise during outdoor activities like cycling.
- **Ambient Sound Mode:** Allows you to hear surrounding sounds, conversations, or traffic without removing your earbuds. The ambient sound level can be adjusted from -3 to +3 via the app.

ノイズキャンセリング機能
全身で音楽の世界に取り込む

デュアルマイクを搭載したハイブリッドANCシステムにより、最大-48dBの環境ノイズ低減を実現。複数のモードが、通勤、飛行機内、仕事中など、さまざまなシーンに適用します。周りの音に注意を払う必要があるときは、外音取り込みモードで周囲の音を取り込み、会話や交通音をイヤホンを外さずに聞くことができます。

Image: Noise Cancelling Function.

シーンによって使い分ける

ノイキャンモード（高）
飛行機/電車/バス

ノイキャンモード（中間）
会社/カフェ/公園

外音取り込みモード
会話/待合室

風切り音低減モード
自転車に乗る

Image: Usage scenarios for different modes.

2.4 AI Voice Translation

The EvoBuds Pro offers seamless AI voice translation supporting 21 languages:

1. Ensure your earphones are paired with your smartphone.
2. Open the EDIFIER ConneX app and tap the translate icon to enable AI voice translation.
3. Select your native language and the target language. Download the necessary language packs if prompted.
4. Choose a conversation mode: "Side by Side" or "Face to Face".

5. Tap the screen or double-tap either earbud to speak. Your speech will be translated, displayed on the screen, and played back through the smartphone and earphones.
6. You can also specify who is wearing the earphone (yourself or the other person) or use the smartphone microphone only for translation.

Image: AI Voice Translation Function.

2.5 Game Mode

Activate game mode via the EDIFIER ConneX app to enjoy ultra-responsive audio with a low latency of

60ms, ideal for video viewing and gaming.

2.6 Wearing Detection

The earbuds feature wearing detection. When you remove an earbud, music playback will automatically pause. When you put it back in, playback will resume.

装着検出機能

イヤホンを装着し音楽を再生している際に、イヤホンを一時的に外すと、自動で音楽が一時停止します。再度装着すると自動で音楽が再生します。

Image: Wearing Detection Function.

2.7 Hearing Protection

The EDIFIER ConneX app includes a hearing protection function. By enabling "Volume Limit", you can set a maximum volume level and receive reminders to protect your hearing health.

聴覚保護機能

EDIFIER ConneX アプリで機能「音量制限」を有効にすると、音量制限レベルを設定したり、リマインダーを受信したりして、聴覚の健康を守ります。

Image: Hearing Protection Function.

3. MAINTENANCE

3.1 IP54 Water and Dust Resistance

The EDIFIER EvoBuds Pro are rated IP54 for water and dust resistance, making them suitable for use during outdoor activities or sports. This rating protects against splashes of water and limited dust ingress. Please note that they are not designed for use underwater.

IP54防水防塵

雨天や汗をかく場面でも使用可能なため、
外出時やスポーツ時もいつでも使用頂けます。

※ 防水仕様は、雨などで濡れた場合の保護を目的で設計されています
（IP54相当）。水中では使用できることではありません。

Image: IP54 Water and Dust Resistance.

4. TROUBLESHOOTING

4.1 Resetting the Earbuds

If you encounter any issues during use, you can reset the earphones to their factory default settings:

1. Place both earbuds into the charging case and leave the lid open.
2. Press the button on the charging case three times.
3. The LED indicator will blink green until the reset process is complete.
4. After the reset, the earphones will automatically enter pairing mode, and the LED will blink red and green alternately, indicating they are ready for a new connection.

4.2 Finding Lost Earbuds

The EDIFIER ConneX app includes a "Find My Product" feature to help locate lost earbuds. Access this feature within the app to play an audio signal from the lost earbud.

5. SPECIFICATIONS

Feature	Specification
Connectivity Technology	Wireless
Wireless Communication Technology	Bluetooth
Included Components	Earbuds, Charging Case, Charging Cable, Ear Tips (S/M/L/LL), Instruction Manual, Safety Precautions
Charging Time	1.5 Hours

Item Weight	0.05 Grams
Control Method	App
Battery Required	Yes
Continuous Use Time	36 Hours
Manufacturer	EDIFIER
Package Dimensions	10.3 x 10 x 4.3 cm
ASIN	B0FPLL98P5
Brand	Edifier
Color	Grey
Noise Control	Hybrid Noise Cancelling
Frequency Response	40 KHz
Sensitivity	92 dB

6. WARRANTY & SUPPORT

6.1 1-Year Warranty

All EDIFIER products come with a 1-year warranty from the date of purchase. In case of product defects within this period, we offer exchanges, returns, or refunds.

6.2 Customer Support

If you have any questions or require assistance during use, please feel free to contact our customer support.