



[Manuals.plus](#) /

› [Treocho](#) /

› Treocho ET2504-WN-S Walnut End Table Set of 2 Instruction Manual

Treocho ET2504-WN-S

Treocho ET2504-WN-S Walnut End Table Set of 2 Instruction Manual

Model: ET2504-WN-S

INTRODUCTION

Thank you for choosing the Treocho ET2504-WN-S Walnut End Table Set of 2. This manual provides essential information for the safe assembly, proper use, and maintenance of your new end tables. Please read these instructions carefully before beginning assembly and retain them for future reference.

SAFETY INFORMATION

- Always assemble the product on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not exceed the recommended weight capacity for the table surfaces.
- Keep small parts and packaging materials away from children to prevent choking hazards.
- Avoid placing hot items directly on the table surface without protective coasters.
- Do not stand or climb on the tables.

PACKAGE CONTENTS

Please verify that all components and hardware are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Table Tops (2)
- Lower Storage Shelves (2)
- Leg Frames (4 per table, total 8)
- Assembly Hardware (screws, Allen wrench)

- Assembly Guide (this document)

SETUP AND ASSEMBLY

The Treocho End Tables are designed for easy assembly. Each part is clearly marked, and the installation steps are straightforward.

1. Unpack all components and lay them out on a clean, soft surface to prevent damage.
2. Identify the table top, lower shelf, and leg frames for one table.
3. Attach the leg frames to the underside of the table top using the provided screws. Ensure they are aligned correctly.
4. Secure the lower storage shelf to the leg frames, ensuring it is level and all connection points are firm.
5. Tighten all screws with the included Allen wrench until the table is stable. Do not overtighten.
6. Repeat the process for the second end table.



Image: Dimensions of the Treocho End Table. The table measures 23.6 inches in depth, width, and height, with the lower shelf positioned 18.5 inches from the top.



Image: Key features of the Treocho End Table, including its painted surface, square molding top, distinctive strip-shaped side frame design, and robust thickened table legs.

OPERATING AND USAGE

The Treocho End Tables offer versatile functionality and can be used in various settings:

- **Living Room Side Table:** Place next to a sofa or armchair to hold drinks, books, remote controls, or decorative items. The two-tier design provides ample storage.
- **Bedroom Nightstand:** Ideal for use beside a bed, providing space for a lamp, alarm clock, phone, and bedtime reading materials.
- **Office Accent Table:** Can serve as a convenient surface for a printer, office supplies, or as a decorative element in a study or home office.

3 Use of Side table



Regular end side table
for living room



Nightstand for bedroom



Printer table beside
Computer desk

Image: Demonstrating the three primary uses of the Treocho side table: as an end table in a living room, a nightstand in a bedroom, and a printer table in an office setting.



Image: A Trecho end table serving as a functional and decorative piece in a living room, showcasing its capacity for holding various items.



Image: The Trecho end table functioning as a nightstand, providing convenient storage and surface space in a bedroom.



Image: The Trecho end table utilized as a printer stand in an office, demonstrating its utility for holding office equipment and supplies.

Your browser does not support the video tag.

Video: A detailed overview of the Trecho End Table, showcasing its features, assembly process, and various applications in different home settings.

MAINTENANCE

To ensure the longevity and appearance of your Trecho End Tables, follow these maintenance guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using abrasive cleaners, harsh chemicals, or excessive moisture, as these can damage the engineered wood and water-based paint finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the finish.
- **Protection:** Use coasters under beverages and placemats under decorative items to protect the surface from scratches and heat marks.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration.

- **Humidity:** Maintain a stable humidity level in the room to prevent warping or cracking of the wood material.

TROUBLESHOOTING

If you encounter any issues with your Treocho End Tables, refer to the following common solutions:

- **Table is wobbly:** Check all assembly screws and ensure they are securely tightened. If the floor is uneven, consider using furniture pads or shims under the legs.
- **Scratches on surface:** Minor scratches can sometimes be minimized with a furniture repair marker or polish designed for wood finishes. For deeper scratches, professional repair may be necessary.
- **Difficulty assembling:** Re-read the assembly instructions carefully. Ensure all parts are oriented correctly. Do not force parts together. If issues persist, contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	Treocho
Model Name	ET2504-WN-S
Product Dimensions (D x W x H)	23.62" x 23.62" x 23.62"
Item Weight	39 Pounds (for the set)
Frame Material	Engineered Wood
Top Material Type	Engineered Wood
Color	Walnut
Number of Items	2 (Set of 2)
Required Assembly	Yes
Indoor/Outdoor Usage	Indoor
Tools Recommended For Assembly	Screw Driver (Allen wrench included)

WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the purchase documentation or contact Treocho customer service directly through the retailer where the product was purchased. Please have your model number (ET2504-WN-S) and purchase date available when contacting support.

