

FUNYET FUN01-06

FUNYET Laptop Computer (Model FUN01-06) User Manual

This manual provides instructions for the setup, operation, maintenance, and troubleshooting of your FUNYET Laptop Computer.

1. INTRODUCTION

Welcome to the FUNYET Laptop Computer user manual. This document will guide you through understanding and utilizing your new device. The FUNYET Laptop Computer, model FUN01-06, is designed for efficient performance and portability, featuring an 11th generation Celeron N5095 processor, a 14.1-inch Full HD display, 8GB RAM, and a 256GB SSD, running on Windows 11 Pro.

For optimal performance and longevity, please read this manual carefully before using your laptop.

2. SETUP

2.1 Unboxing

Carefully remove the laptop and all accessories from the packaging. The box should contain the LAPTOP and a power adapter.

2.2 Initial Power On and Charging

Before first use, it is recommended to fully charge the laptop battery. Connect the power adapter to the laptop's DC input port and then to a power outlet. The charging indicator light will illuminate.

To power on the laptop, open the lid and press the power button located on the keyboard. The laptop will boot up and guide you through the initial Windows 11 Pro setup process.

Quick productivity Int With Celeron N5095 processor

4 Cores

4 Threads

Up to 2.9Ghz

Turbo Frequency

UHD

Int UHD Graphics




Image: The FUNYET Laptop Computer with its screen open, ready for initial setup.

3. OPERATING INSTRUCTIONS

3.1 Power Management

- **Power On:** Press the power button.
- **Sleep Mode:** Close the lid or press the power button briefly.
- **Shut Down:** Click the Start button, then Power, and select "Shut down".

3.2 Display and Visuals

The laptop features a 14.1-inch Full HD (1920x1080) IPS display with a narrow bezel design, offering an 85% screen-to-body ratio for an immersive viewing experience. The screen supports a 180-degree opening angle for flexible viewing positions.

1920X1080



14.1" FHD Visual Experience

With narrow bezel design,
14.1" FHD screen brings you extreme visual enjoyment

1920*1080

1920*1080 FHD



Eye Protection



178° View Angle

Image: The laptop's 14.1-inch Full HD IPS display showcasing a scenic view, highlighting the narrow bezels and immersive visual experience.

3.3 Performance and Multitasking

Equipped with an 11th generation Intel Celeron N5095 processor (4 cores, 4 threads) with a turbo frequency up to 2.9 GHz, the laptop provides responsive performance for daily tasks and multitasking. It includes 8GB DDR4 RAM and a 256GB high-speed SSD for efficient operation and quick boot times.

Sophisticated Design Sleek and Lightweight

The laptop fusing style and sophistication, ensuring you stand out wherever you go.



Image: A diagram illustrating the Intel Celeron N5095 processor, highlighting its 4 cores, 4 threads, and up to 2.9GHz turbo frequency.

Storage can be expanded by up to 128GB using a TF card (not included).



Image: The laptop displaying multiple applications open simultaneously, demonstrating its multitasking capabilities with 8GB RAM and 256GB SSD.

3.4 Ports and Connectivity

The laptop offers various ports for connectivity:

- 2x USB 3.0 ports (one on each side)
- 1x Mini HDMI port
- 1x Headphone jack
- 1x TF Card slot
- 1x 12V/2A DC power input

Multiple Ports for Greater Versatility

One USB port on each side for greater flexibility



Image: A detailed view of the laptop's side ports, including USB 3.0, headphone jack, TF card slot, Mini HDMI, and DC power input.



Image: A diagram illustrating the various ports on the laptop and their functions.

3.5 Battery Life

The integrated 5000 mAh battery provides up to 8 hours of battery life under normal usage conditions, with a full charge typically achieved in 2 hours.

Get rid of power supply worries



Capacity
5000 mAh



8 Hours
Battery Life



2 Hours
Full Charge



Image: A person comfortably using the laptop on a couch, illustrating the convenience of its long battery life for on-the-go use.

4. MAINTENANCE

4.1 Cleaning

- **Screen:** Use a soft, lint-free cloth slightly dampened with water or a screen cleaner. Avoid harsh chemicals.
- **Chassis and Keyboard:** Use a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, ensuring no liquid enters openings.

4.2 Battery Care

- Avoid fully discharging the battery frequently.
- Store the laptop in a cool, dry place if not used for extended periods.
- Use only the provided power adapter for charging.

4.3 Software Updates

Regularly check for and install Windows updates to ensure system stability, security, and optimal performance. Go to *Settings > Windows Update* to check for updates.

4.4 Thermal Management

The laptop features improved thermal design to maintain optimal operating temperatures. Ensure that the ventilation openings on the bottom of the laptop are not obstructed during use to prevent overheating.



Image: The underside of the laptop, illustrating the cooling vents designed for efficient heat dissipation.

5. TROUBLESHOOTING

This section addresses common issues you might encounter. If the problem persists, please contact customer support.

5.1 Laptop Not Turning On

- Ensure the power adapter is securely connected to both the laptop and a working power outlet.
- Check if the battery is charged. If completely drained, it may take a few minutes of charging before the laptop can power on.

- Try holding the power button for 10-15 seconds to perform a hard reset.

5.2 Slow Performance

- Close unnecessary applications running in the background.
- Check for and install any pending Windows updates.
- Ensure there is sufficient free space on the SSD.
- Run a virus scan to check for malware.

5.3 Display Issues

- If the screen is blank, ensure the laptop is powered on and not in sleep mode.
- Adjust screen brightness using the function keys (Fn + Fx).
- If connecting to an external monitor, ensure the cable is secure and try pressing *Windows key + P* to cycle through display modes.

6. SPECIFICATIONS

Feature	Detail
Brand	FUNYET
Model Name	Duetbook 14 (FUN01-06)
Screen Size	14.1 Inches
Screen Resolution	1920 x 1080 pixels (FHD)
Processor	Intel Celeron N5095 (up to 2.9 GHz)
RAM	8 GB DDR4
Hard Drive	256 GB SSD
Operating System	Windows 11 Pro
Graphics Coprocessor	Intel Celeron Integrated Graphics
Wireless Type	5 GHz Radio Frequency (Wi-Fi), Bluetooth
USB Ports	2x USB 3.0
Other Ports	Mini HDMI, Headphone Jack, TF Card Slot, DC Input
Item Weight	4.18 pounds (approx. 1.9 kg)
Product Dimensions	12.7 x 8.3 x 0.8 inches (32.26 x 21.08 x 2.03 cm)
Battery	5000 mAh (up to 8 hours)

7. WARRANTY AND SUPPORT

7.1 Warranty Information

Your FUNYET Laptop Computer comes with a 1-year limited warranty from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or natural disasters.

Please retain your proof of purchase for warranty claims.

7.2 Customer Support

For any questions, technical assistance, or warranty claims, please contact FUNYET customer service. We offer round-the-clock support to ensure a smooth experience with your product.

You can find more information and contact details on the official FUNYET store page:[FUNYET Store](#).