

Oviala 113860

Oviala Scandinavian 4-Door Buffet L160 cm Light Wood Instruction Manual

Model: 113860 (Dario)

INTRODUCTION

Thank you for choosing the Oviala Scandinavian 4-Door Buffet. This manual provides essential information for the safe assembly, proper use, and maintenance of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.

SAFETY INFORMATION

WARNING: Furniture tipping hazard. To prevent serious injury, this furniture must be securely attached to the wall using the provided anti-tip hardware. Always assemble with caution and ensure the unit is stable before use. Do not allow children to climb on or hang from the furniture.

- Keep all assembly hardware out of reach of children.
- Ensure all connections are tightened securely before use.
- Do not overload shelves or drawers.
- Place the buffet on a level, stable surface.

PACKAGE CONTENTS

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact Oviala customer support.

- Buffet panels (top, bottom, sides, back, shelves)
- 4 Doors
- 4 Hevea wood legs

- Central support leg
- Assembly hardware (screws, dowels, hinges, push-to-open mechanisms, anti-tip kit)
- Instruction manual

SETUP AND ASSEMBLY INSTRUCTIONS

Assembly requires two people. Please follow these steps carefully. A Phillips head screwdriver and a hammer may be required (not included).

1. **Step 1: Prepare the Panels**

Unpack all components and lay them out on a clean, soft surface to prevent scratches. Identify the top, bottom, side, and back panels.



Image: Front view of the assembled Oviaa Scandinavian 4-Door Buffet, showcasing its light wood finish and four doors.

2. **Step 2: Attach Side Panels and Internal Dividers**

Connect the side panels to the bottom panel using the provided hardware (dowels and cam locks/screws). Insert the internal vertical dividers.



Image: Interior view of the buffet showing multiple shelving compartments, indicating the structure after internal dividers and shelves are installed.

3. **Step 3: Install Shelves**

Place the adjustable shelves into the desired positions using the shelf pins. Ensure they are level and secure.



Image: The buffet with all four doors open, revealing the internal shelving structure. Each section contains one adjustable shelf.

4. **Step 4: Attach Top Panel and Back Panel**

Secure the top panel to the assembled frame. Carefully attach the back panel using small nails or screws, ensuring the unit is square.



Image: Rear view of the Oviola Scandinavian 4-Door Buffet, showing the back panel and the structure of the unit from behind.

5. **Step 5: Install Legs**

Attach the four Hevea wood legs to the bottom panel. Install the central support leg for added stability. Ensure all legs are firmly tightened.



Image: A close-up view of one of the buffet's legs, showing its round, solid wood design and an adjustable foot for leveling.

6. **Step 6: Attach Doors and Push-to-Open Mechanisms**

Mount the hinges to the doors and then attach the doors to the buffet frame. Install the push-to-open mechanisms according to their specific instructions. Adjust hinges for proper door alignment.



Image: The buffet with one door partially open, revealing an internal shelf and the hinge mechanism.

7. **Step 7: Secure to Wall (Anti-Tip)**

Using the provided anti-tip kit, securely fasten the buffet to a wall stud. This step is crucial for safety and prevents the furniture from tipping over.

OPERATING INSTRUCTIONS

- **Door Operation:** The buffet features a push-to-open mechanism. Gently press the center of the door to release the latch and open. To close, push the door until it clicks into place.
- **Shelf Adjustment:** The internal shelves are adjustable. To change shelf height, remove items, lift the shelf, reposition the shelf pins to the desired height, and then place the shelf back on the pins.
- **Leveling:** The legs are equipped with adjustable feet. If the buffet is uneven, rotate the feet clockwise or counter-clockwise to achieve a stable, level position.

MAINTENANCE AND CARE

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals, as these can damage the wood finish.
- **Spills:** Immediately wipe up any spills to prevent staining or water damage.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration.
- **Heat and Moisture:** Keep the buffet away from direct heat sources and areas of high humidity.

- **Hardware:** Periodically check all screws and connections to ensure they remain tight. Retighten as necessary.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Doors do not close properly or are misaligned.	Hinges are loose or improperly adjusted.	Adjust the screws on the hinges to align the doors. Ensure the push-to-open mechanism is correctly installed.
Buffet is wobbly or unstable.	Uneven floor or loose leg connections.	Adjust the leveling feet on the legs. Ensure all leg screws are tightened. Verify the anti-tip kit is securely installed.
Push-to-open mechanism not working.	Mechanism is jammed or incorrectly installed.	Check for obstructions. Re-install the mechanism according to its specific instructions.

SPECIFICATIONS

Brand:	Oviala
Model Name:	Dario
Model Number:	113860
Color:	Beige (Light Wood)
Material:	Engineered Wood (MDF Melamine top), Hevea Wood legs
Dimensions (L x W x H):	160 cm x 40 cm x 75 cm
Item Weight:	30 Kilograms
Number of Doors:	4
Number of Shelves:	4 (adjustable)
Special Feature:	Push-to-open doors
Assembly Required:	Yes
Mounting Type:	Floor Mount (with anti-tip wall attachment recommended)

WARRANTY AND SUPPORT

Oviala products are manufactured to high-quality standards. For information regarding warranty coverage, missing parts, or technical assistance, please contact Oviala customer support. Keep your purchase receipt as proof of purchase.

For customer support, please visit the official Oviala website or refer to the contact information provided with your purchase.

