Motorola Razr 60

Motorola Razr 60 Smartphone User Manual
Model: Razr 60

1. INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Motorola Razr 60 5G smartphone. Please read this guide thoroughly to ensure optimal performance and longevity of your device.

Figure 1: Motorola Razr 60 in unfolded state, displaying the main screen.

2. SETUP

2.1. Unboxing and Initial Inspection

Carefully remove all components from the packaging. Verify that the following items are present:

- Motorola Razr 60 Smartphone
- USB Cable
- Quick Start Guide (if included)

Inspect the device for any visible damage before proceeding.

2.2. Inserting SIM Cards

The Motorola Razr 60 supports Dual SIM functionality. To insert your SIM cards:

1. Locate the SIM card tray on the side of the device.
2. Use a SIM ejector tool (not included, typically comes with new phones) to open the tray.

3. Place your nano-SIM cards into the designated slots, ensuring the gold contacts face downwards.

4. Carefully reinsert the SIM tray into the device.

Figure 2: Side view of the Motorola Razr 60, indicating the location of the SIM tray and power/volume buttons.

2.3. Charging the Battery

Before first use, it is recommended to fully charge the device. Connect the provided USB cable to the phone's USB-C port and the other end to a compatible power adapter (sold separately) or a computer's USB port.

Figure 3: Bottom view of the Motorola Razr 60, highlighting the USB-C charging port.

2.4. Powering On and Initial Configuration

Press and hold the Power button (located on the side) until the Motorola logo appears. Follow the on-screen prompts to select your language, connect to a Wi-Fi network, and set up your Google account.

3. OPERATING YOUR DEVICE

3.1. Foldable Screen Operation

The Motorola Razr 60 features a foldable display. Gently unfold the device to access the main 6.9-inch screen. When finished, you can fold the device to a compact form factor for portability and to utilize the external display.

Figure 4: Motorola Razr 60 in its folded, compact state.

Figure 5: Motorola Razr 60 partially folded, showcasing the external display and camera module.

3.2. Android 15 Operating System

Your device runs on Android 15. Navigate through the interface using gestures and taps. Swipe up from the

bottom to access the app drawer, swipe down from the top for notifications and quick settings.

3.3. Connectivity

The Razr 60 supports 5G connectivity for high-speed mobile data. Ensure your SIM card is provisioned for 5G service. The device also features Wi-Fi for internet access and Bluetooth for connecting accessories.

3.4. Dual SIM Functionality

With Dual SIM support, you can use two different phone numbers or carriers simultaneously. Manage your SIM preferences for calls, messages, and mobile data through the Settings menu under "Network & internet" > "SIMs".

4. MAINTENANCE

4.1. Cleaning Your Device

To clean your Motorola Razr 60, use a soft, lint-free cloth. For stubborn smudges, slightly dampen the cloth with water. Avoid using harsh chemicals, abrasive materials, or aerosol sprays, as these can damage the screen and finish.

4.2. Battery Care

The device is equipped with a 4500 mAh battery. To prolong battery life:

- Avoid extreme temperatures.
- Do not leave the device fully charged or fully discharged for extended periods.
- Use only approved charging accessories.

4.3. Software Updates

Regularly check for and install software updates to ensure your device has the latest features, security patches, and performance improvements. Go to *Settings > System > System updates*to check for available updates.

5. TROUBLESHOOTING

If you encounter issues with your Motorola Razr 60, try the following steps:

5.1. Device Not Responding

If the device is unresponsive, press and hold the Power button for approximately 10-15 seconds to force a restart.

5.2. Network Connectivity Issues

- Ensure Airplane Mode is off (*Settings > Network & internet*).
- Check that your SIM cards are properly inserted.
- Restart the device.
- Contact your mobile carrier to verify service status.

5.3. Battery Draining Quickly

- Reduce screen brightness.
- Close unused apps running in the background.

- Disable unnecessary features like GPS or Bluetooth when not in use.
- Check battery usage in *Settings > Battery* to identify power-consuming apps.

5.4. Factory Reset

As a last resort, if software issues persist, you may perform a factory data reset. This will erase all data from your phone. **Backup your data before proceeding.** Go to *Settings > System > Reset options > Erase all data (factory reset)*.

6. SPECIFICATIONS

Below are the key technical specifications for the Motorola Razr 60:

Feature	Specification
Model Name	Motorola Razr 60
Operating System	Android 15
CPU Model	Cortex
CPU Speed	2.8 GHz
RAM Memory Installed Size	8 GB
Internal Storage	256 GB
Screen Size	6.9 Inches (Main Display)
Resolution	1080 x 2640
Connectivity Technologies	5G
Special Features	Dual SIM, Foldable Screen
Battery Power Rating	4500 Milliamp Hours
Product Dimensions	6.74 x 0.29 x 2.91 inches
Item Weight	7.1 ounces (200 Grams)
Audio Jack	No headphone jack
Color	Pantone Gibraltar Sea

7. WARRANTY AND SUPPORT

7.1. Warranty Information

Your Motorola Razr 60 is covered by a limited warranty. For detailed warranty terms and conditions, please refer to the warranty card included with your device or visit the official Motorola support website. This product is listed as "Renewed," which may affect warranty terms; consult your seller for specific details regarding renewed product warranties.

7.2. Customer Support

For further assistance, technical support, or service inquiries, please visit the official Motorola support website or contact their customer service. You can typically find contact information on the manufacturer's website or in the documentation provided with your device.

For issues related to the "Renewed" status or purchase, please contact your seller directly.