

OUKITEL P1 Pro

OUKITEL P1 Pro Smartphone User Manual

Model: P1 Pro

1. INTRODUCTION

The OUKITEL P1 Pro is a high-performance smartphone designed for a seamless user experience. It features a vibrant 6.7-inch FHD+ AMOLED display with a 120Hz refresh rate, a powerful 50MP main camera, and a long-lasting 5150mAh battery. This device is equipped with a MediaTek Helio G100 processor, 16GB of RAM, and 256GB of internal storage, expandable up to 2TB. Running on Android 15, the P1 Pro offers advanced features such as an under-display fingerprint sensor, Dynamic Island notifications, and NFC for convenient transactions.



Image: OUKITEL P1 Pro showcasing its user interface and key features.

2. WHAT'S IN THE BOX

Please check the contents of your OUKITEL P1 Pro package. If any items are missing or damaged, contact customer support.

- OUKITEL P1 Pro Smartphone
- Maintenance Card (Warranty Card)
- Quick Start Guide
- Tempered Glass Screen Protector
- Protective Case
- USB Cable
- Charger
- SIM Ejector Pin



Image: The OUKITEL P1 Pro packaging list, showing all included accessories.

3. SETUP

3.1. SIM Card and TF Card Installation

The OUKITEL P1 Pro supports dual Nano SIM cards or one Nano SIM card and one TF (microSD) card for expanded storage. Use the provided SIM ejector pin to open the SIM tray.

1. Locate the SIM tray on the side of your device.
2. Insert the SIM ejector pin into the small hole next to the tray and press gently until the tray pops out.
3. Place your Nano SIM card(s) and/or TF card into the designated slots on the tray, ensuring the gold contacts face downwards.
4. Carefully push the tray back into the device until it clicks into place.

Doble SIM o SIM + Tarjeta TF

Con dos ranuras, puedes usar dos tarjetas Nano SIM o una tarjeta Nano SIM y una tarjeta TF, haciendo fácil administrar tus conexiones y expandir tu capacidad de almacenamiento sin la molestia de cambiar tarjetas.



Image: Dual SIM or SIM + TF card slot configuration.

3.2. Initial Power On

Press and hold the Power button located on the side of the device until the OUKITEL logo appears. Follow the on-screen instructions to complete the initial setup, including language selection, Wi-Fi connection, and Google account setup.

3.3. Biometric Security Setup

For enhanced security, you can set up the under-display fingerprint sensor and Face ID.

- Go to **Settings > Security & privacy > Device unlock**.
- Select **Fingerprint Unlock** and follow the prompts to register your fingerprint.
- Select **Face Unlock** and follow the prompts to register your face.

Desbloquea Más Rápido Que Nunca con Sensor de Huellas Dactilares en Pantalla

Disfruta de acceso rápido y seguro en segundos con nuestro innovador sensor óptico de huellas dactilares en pantalla, diseñado para tu conveniencia y tranquilidad.



Image: Unlocking the device using the under-display fingerprint sensor.

4. OPERATING YOUR DEVICE

4.1. Dynamic Island

The Dynamic Island feature provides quick access to notifications, calendar events, battery alerts, and other daily information directly from the top of your screen, simplifying your daily interactions.

Dynamic Island

Conveniencia a tu Alcance

Simplifica tu vida con la dynamic island del P1 Pro. Accede a notificaciones y controles con un solo toque.



Image: Dynamic Island displaying notifications and system information.

4.2. Display Features

Experience an immersive visual experience with the 6.7-inch FHD+ AMOLED display, offering a resolution of 1080x2412 pixels and a 120Hz refresh rate for smooth scrolling and gaming. The display also supports HDR with pixel-level control for brighter whites and deeper blacks.

HDR con control a nivel de píxel

Aprovechando el alto brillo y la atenuación precisa del AMOLED, HDR produce blancos más brillantes y negros más profundos que SDR.



Image: HDR display capabilities with pixel-level control.

4.3. Camera Usage

Capture stunning photos and videos with the OUKITEL P1 Pro's versatile camera system.

- **50MP Main Camera:** For high-resolution photos with excellent detail and color. Supports ultra-wide angle and bokeh effects.
- **32MP Front Camera:** For clear selfies and video calls.
- **2MP Macro Camera:** For capturing intricate details of small objects.

To take a photo or record a video, open the Camera app and select your desired mode (Photo, Video, Portrait, Macro, etc.). Tap the shutter button to capture.

Captura Los Momentos De La Vida
 Ya sea una videollamada con la familia o una foto rápida de tu aventura de fin de semana, el sistema de doble cámara te tiene cubierto. La cámara principal de 50MP ofrece fotos claras y detalladas con buena luz.

Image: The 50MP main camera of the OUKITEL P1 Pro.

Cámara Principal 50MP
 Con su cámara principal de 50 MP, cada detalle cobra vida. Captura imágenes nítidas y llenas de color, desde retratos hasta paisajes, con una calidad excepcional.

Image: Capturing a selfie with the 32MP front camera.

4.4. Performance

The OUKITEL P1 Pro is powered by the 6nm MediaTek Helio G100 octa-core processor, offering improved sustained performance and lower power consumption. Coupled with 16GB of RAM and 256GB of ROM (expandable up to 2TB via TF card), the device ensures smooth multitasking and fast application loading.

Libera un Rendimiento Excepcional
 Desbloquea un rendimiento superior con el 4G MediaTek Helio G100 Octa-Core, elaborado con tecnología avanzada de 6nm. Soporta multitarea fluida, menor consumo de energía y sobresalientes capacidades de juego y multimedia, todo mientras garantiza un funcionamiento confiable y eficiente.

Image: MediaTek Helio G100 processor for exceptional performance.



Image: 16GB RAM + 256GB ROM for seamless operation.

4.5. Battery Management

The OUKITEL P1 Pro features a 5150mAh battery, providing extended usage times. It supports 18W fast charging, allowing a full charge in approximately 2.5 hours. The device also offers reverse charging, enabling it to act as a power bank for other electronic devices via an OTG cable.

Batería Grande 5150mAh Energía al Alcance de tu Mano

Mantente energizado durante todo tu día con la batería de alta capacidad 5150mAh, que ofrece hasta 18 horas de uso continuo. Diseñada para usuarios intensivos, mantiene tus actividades y entretenimiento funcionando sin interrupciones.

25 Days
En Espera

10 Hrs
Video

10 Hrs
Juegos

50 Hrs
Llamadas



Image: 5150mAh battery with 18W fast charging.



Carga Inversa

La Máxima Comodidad para Energía en Movimiento

La carga inversa facilita alimentar tus dispositivos en cualquier lugar, añadiendo un toque de conveniencia a tu vida diaria.

Image: Reverse charging functionality for convenience.

4.6. Connectivity

The OUKITEL P1 Pro supports various connectivity options:

- **Dual 4G:** Stay connected with high-speed mobile data.
- **Wi-Fi (2.4G/5G):** Connect to wireless networks for internet access.
- **NFC:** For contactless payments and quick data exchange.
- **GPS:** Integrated navigation system for accurate location services.



Image: Integrated navigation system for precise location tracking.

Corning Gorilla Glass 5

Corning Gorilla Glass 5 proporciona una protección excepcional, asegurando que las pantallas permanezcan resistentes a rasguños y caídas, manteniendo una apariencia impecable con el tiempo.



Pagos Suaves y NFC

NFC ofrece un intercambio rápido de contenido digital y asegura que todas las transacciones, haciendo tu experiencia suave y sin complicaciones.



Image: NFC for smooth and secure payments.

4.7. Software (Android 15)

The OUKITEL P1 Pro runs on Android 15, offering enhanced privacy protection, AI optimization, and a smoother user experience. It provides improved features for managing app permissions, data access, and customizable lock screen options.



Image: Android 15's privacy, security, and customization features.

5. MAINTENANCE

5.1. General Care

To ensure the longevity of your OUKITEL P1 Pro, follow these general care guidelines:


- Keep your device clean by wiping it with a soft, dry cloth.
- Avoid exposing the phone to extreme temperatures, direct sunlight, or excessive moisture.
- Do not use harsh chemicals or abrasive materials for cleaning.

5.2. Screen Protection

The OUKITEL P1 Pro features Corning Gorilla Glass 5 for enhanced scratch and drop resistance. For additional protection, use the included tempered glass screen protector and protective case.

Corning Gorilla Glass 5

Corning Gorilla Glass 5 proporciona una protección excepcional, asegurando que las pantallas permanezcan resistentes a rasguños y caídas, manteniendo una apariencia impecable con el tiempo.



Pagos Suaves y NFC

NFC ofrece un intercambio rápido de contenido digital y asegura que todas las transacciones, haciendo tu experiencia suave y sin complicaciones.



Image: Corning Gorilla Glass 5 for superior screen protection.

5.3. Software Updates

Regularly check for and install software updates to ensure your device has the latest features, security patches, and performance improvements. You can check for updates in **Settings > System > System update**.

6. TROUBLESHOOTING

If you encounter issues with your OUKITEL P1 Pro, try the following common troubleshooting steps:

- **Device not turning on:** Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on.
- **Apps freezing or crashing:** Close and restart the app. If the issue persists, clear the app's cache (Settings > Apps > [App Name] > Storage > Clear cache).
- **Poor battery life:** Reduce screen brightness, disable unnecessary features like GPS or Bluetooth when not in use, and close background apps.
- **Connectivity issues (Wi-Fi/Mobile Data):** Toggle Wi-Fi or mobile data off and on. Restart your device. For Wi-Fi, try forgetting the network and reconnecting.
- **Fingerprint sensor not working:** Ensure your finger is clean and dry. Re-register your fingerprint if necessary.
- **Device unresponsive:** Press and hold the Power button for about 10-15 seconds to force a restart.

If these steps do not resolve the issue, please refer to the Warranty and Support section for further assistance.

7. SPECIFICATIONS

Below are the detailed technical specifications for the OUKITEL P1 Pro smartphone:

Feature	Specification
Model Name	OUKITEL P1 Pro
Dimensions	16.24 x 7.62 x 0.82 cm (162.4 x 76.2 x 8.2 mm)

Feature	Specification
Operating System	Android 15
Display Size	6.7 Inches
Display Type	AMOLED
Resolution	2412 x 1080 (FHD+)
Refresh Rate	120 Hz
CPU Model	MediaTek Helio G100
RAM	16 GB
Internal Storage (ROM)	256 GB
Expandable Storage	Up to 2 TB (via TF card)
Rear Camera Resolution	50 MP (Main)
Front Camera Resolution	32 MP
Battery Capacity	5150 mAh
Charging	18W Fast Charging, Reverse Charging
Mobile Technology	4G
SIM Card Slots	Dual SIM (Nano)
Biometric Security	Under-display Fingerprint Recognition, Face ID
Connectivity	Wi-Fi (2.4G/5G), NFC, GPS
Water Resistance Level	Not water resistant
Screen Protection	Corning Gorilla Glass 5

8. WARRANTY AND SUPPORT

The OUKITEL P1 Pro is backed by a two-year manufacturer's warranty covering defects in materials and workmanship. This warranty ensures your peace of mind regarding the quality and reliability of your device.

For any questions, technical assistance, or warranty claims, please contact OUKITEL customer support. You can typically find contact information on the official OUKITEL website or through the retailer where you purchased the device. Please have your product model and purchase details ready when contacting support.

OUKITEL is committed to providing quality products and excellent customer service. Support inquiries are generally responded to within 12 hours.



© 2026 OUKITEL. All rights reserved.