

Saved from manuals.plus.

Open the live page for links to other documents and user manuals.

[Manuals.plus](#) /

> [leejdn](#) /

> leejdn Mid Century Modern Rattan 9-Drawer Dresser Instruction Manual

leejdn dougui

leejdn Mid Century Modern Rattan 9-Drawer Dresser Instruction Manual

Model: dougui

1. PRODUCT OVERVIEW

This manual provides essential information for the assembly, operation, and maintenance of your leejdn Mid Century Modern Rattan 9-Drawer Dresser. Please read these instructions carefully before beginning assembly and retain them for future reference.



This image displays the fully assembled leejdn Mid Century Modern Rattan 9-Drawer Dresser, showcasing its warm wood finish and rattan drawer fronts in a typical home environment.

Key Features:

- **Modern Bentwood Design:** Features elegant lines and a smooth, textured surface with smooth rounded corners.
- **Natural Rattan Drawers:** Hand-woven rattan fronts provide a unique aesthetic, airiness, and damp-proof qualities.
- **Spacious Storage:** Nine drawers offer ample space for various items.
- **Smooth Drawer Operation:** Equipped with full-extension, noise-free drawer slides.
- **Safety Features:** Includes an anti-tipping device for secure installation.

2. SAFETY INFORMATION


To ensure safe use of your dresser, please adhere to the following guidelines:

- **Anti-Tipping Device:** Always install the included anti-tipping device to prevent accidental tipping, which can cause

serious injury.

- **Weight Limits:** Do not exceed the maximum load capacity. The top surface supports up to 180 lbs (81.6 kg). Each individual drawer supports up to 35 lbs (15.9 kg).
- **Even Weight Distribution:** Distribute weight evenly across drawers and the top surface to maintain stability.
- **Child Safety:** Keep children away from the dresser during assembly. Do not allow children to climb on or play with the dresser.
- **Stable Placement:** Place the dresser on a flat, level surface to prevent wobbling.

Product Dimensions



Max.Load

Top 180lbs | , Each cabinet 35lbs
Anti-tipping included

This diagram illustrates the overall dimensions of the dresser (59.06 inches wide, 15.55 inches deep, 31.5 inches high) and individual drawer dimensions (18.03 inches wide, 13.98 inches deep, 7.28 inches high). It also highlights the included anti-tipping mechanism for safety.

3. PACKAGE CONTENTS

Before assembly, verify that all components and hardware are present. Each part is meticulously labeled for easy

identification.

Included Components:

- Dresser panels (top, bottom, sides, back)
- Drawer components (fronts with rattan, sides, backs, bottoms)
- Drawer slides
- Assembly hardware (screws, dowels, cam locks, etc.)
- Anti-tipping kit
- Assembly instructions
- Spare parts (for common hardware)

4. SETUP AND ASSEMBLY

Assembly of this dresser requires two adults. Follow the clear, user-friendly instructions provided in the package. All components are labeled with serial numbers to simplify the process.


General Assembly Steps:

1. **Unpack and Identify:** Carefully unpack all parts and lay them out on a clean, soft surface to prevent scratches. Identify each component using the provided labels.
2. **Assemble Frame:** Follow the step-by-step diagrams to assemble the main frame of the dresser. Ensure all connections are secure.
3. **Assemble Drawers:** Construct each of the nine drawers, attaching the rattan fronts and installing the drawer slides.
4. **Install Drawers:** Insert the assembled drawers into the dresser frame, ensuring they slide smoothly.
5. **Attach Anti-Tipping Device:** Securely attach the anti-tipping device to the back of the dresser and to a wall stud, following the specific instructions in the kit. This step is crucial for safety.

5. OPERATING INSTRUCTIONS

Drawer Usage:

- The drawers are designed with full-extension slides, allowing them to open completely for easy access to contents.
- The noise-free design ensures quiet operation when opening and closing drawers.
- To open a drawer, gently pull the handle-less front. To close, push firmly until it is fully seated.



Smooth drawer slides

- *Drawers slide easily and smoothly.
- *Full-extension slides allow drawers to open completely for easy access to items.
- *Noise-free design for a quiet experience.

This image focuses on the drawer slides, highlighting their full-extension capability and noise-free design, which ensures smooth and quiet operation when opening and closing drawers.

Storage Capacity:

Each of the nine drawers provides generous storage space. For reference, each drawer can typically hold:

- Approximately 20-25 T-shirts
- Approximately 15-20 pairs of jeans

9 Drawer Dresser

Keep Your Room Clean and Tidy



This image demonstrates the spacious interior of the dresser drawers, illustrating that each drawer can comfortably hold approximately 20-25 T-shirts or 15-20 pairs of jeans, providing ample storage.



6. MAINTENANCE

Proper care will extend the life and appearance of your dresser:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish and rattan.
- **Rattan Care:** For the rattan fronts, gently dust with a soft brush or vacuum with a brush attachment. Avoid excessive moisture.
- **Spills:** Clean spills immediately with a dry cloth to prevent staining or damage to the engineered wood.
- **Sunlight Exposure:** Avoid prolonged direct sunlight exposure to prevent fading or discoloration of the wood and rattan.
- **Hardware Check:** Periodically check and tighten all assembly hardware to ensure the dresser remains stable.

Unique Rattan style

Adding a touch of natural charm to your home



Hexagonal rattan weaving craftsmanship

Refreshing to the touch



Good flexibility



Highly breathable



This image provides a detailed view of the natural rattan weaving on the drawer fronts, emphasizing its unique texture, breathability, and flexibility.

Smooth Curved Solid Wood Edge Design

Finely polished with a smooth touch, ensuring family safety.



This image highlights the finely polished, smooth curved edges of the dresser, a design feature that enhances both aesthetics and user safety.

7. TROUBLESHOOTING

If you encounter any issues with your dresser, consider the following common solutions:

- **Wobbly Dresser:** Ensure the dresser is placed on a level surface. Check all assembly hardware and tighten any loose screws.
- **Drawers Not Sliding Smoothly:** Verify that the drawer slides are correctly installed and aligned. Ensure no objects are obstructing the slides. A small amount of silicone lubricant can be applied to the slides if needed.
- **Drawer Misalignment:** Check that the drawer box is assembled squarely and that the drawer slides are attached correctly to both the drawer and the dresser frame.
- **Missing Parts:** Refer to the package contents list. If parts are missing, contact customer support.

8. SPECIFICATIONS

Brand	leejdn
Model Name	dougui
Overall Dimensions (W x D x H)	59.06" x 15.55" x 31.5" (150 cm x 39.5 cm x 80 cm)
Individual Drawer Dimensions (W x D x H)	18.03" x 13.98" x 7.28" (45.8 cm x 35.5 cm x 18.5 cm)
Material	Engineered Wood, Natural Rattan
Item Weight	52 lbs (23.6 kg)
Number of Drawers	9
Maximum Top Load	180 lbs (81.6 kg)
Maximum Drawer Load (each)	35 lbs (15.9 kg)
Assembly Required	Yes

9. WARRANTY AND SUPPORT

leejdn is committed to providing excellent after-sales service. While specific warranty details are not provided in this manual, please contact us directly if you encounter any product problems or have questions regarding your dresser.

Contact Information:

For support, please refer to the contact details provided with your purchase or visit the official leejdn store page on Amazon:

[leejdn Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FPQ9DFVD>

More documents and user manuals: <https://manuals.plus/>