Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

BETMI Wireless Gaming Controller

BETMI Wireless Gaming Controller User Manual

Model: Wireless Gaming Controller

1. Product Overview

The BETMI Wireless Gaming Controller is designed for multi-platform compatibility, offering an enhanced gaming experience with advanced features such as Hall Effect joysticks and triggers, customizable RGB lighting, macro programming, 6-axis gyro motion sensing, and dual vibration feedback. It includes a 3.5mm TRRS audio jack for headset connectivity.



Image: Front view of the BETMI Wireless Gaming Controller, showcasing its design and button layout.

2. Setup and Connection

2.1 Package Contents

- BETMI Wireless Gaming Controller
- USB-C Charging/Data Cable
- User Manual

2.2 Charging the Controller

Connect the supplied USB-C cable to the controller's charging port and the other end to a USB power source (e.g., console, PC, USB wall adapter). The controller's indicator light will show charging status and turn off or change color when fully charged. A full charge typically takes approximately 2-3 hours.

2.3 Connecting to PS5 via Bluetooth

For the initial Bluetooth connection to a PS5 console, or if the controller was previously connected to another host, follow these steps:

1. Connect the controller to the PS5 console using the provided USB-C cable. The console will automatically recognize and pair the controller.
2. Once the controller is recognized, unplug the USB-C cable.
3. Press the "HOME" button on the controller. The controller will attempt to connect wirelessly via Bluetooth.
4. When successfully connected, the controller's light will stay blue.

Watch the video below for a visual guide on connecting to a PS5 console via Bluetooth mode:

Video: Instructions on how to connect the BETMI Wireless Gaming Controller to a PS5 console using Bluetooth mode, including initial wired pairing and subsequent wireless connection.

2.4 Connecting to PC (Windows)

- **Wired Connection:** Connect the controller to your PC using the USB-C cable. The PC should automatically detect and install the necessary drivers.
- **Bluetooth Connection:** Ensure your PC has Bluetooth enabled. Put the controller into pairing mode (refer to specific button combination in the quick start guide if different from PS5). Go to your PC's Bluetooth settings, search for new devices, and select the "Wireless Controller" to pair.

2.5 Multi-platform Compatibility

The controller is compatible with PS5, PS5 Pro, PS5 Slim, PC (Windows 7/8/10/11), Android, iOS, and Steam Deck. Connection methods may vary slightly for different platforms; refer to the respective device's Bluetooth pairing instructions.



Image: Diagram illustrating the BETMI Wireless Gaming Controller's compatibility with various platforms including PS5, PS5 Pro, PS5 Slim, PC, Android/iOS, and Steam Deck.

3. Operating Instructions

3.1 Hall Effect Joysticks and Triggers

The controller features Hall Effect joysticks and linear triggers, providing precise and responsive input with anti-drift performance and no delay. This technology ensures durability and accuracy for all gaming actions, from subtle movements to rapid accelerations.



Image: Close-up view highlighting the Hall Linear Triggers and Hall Effect Joysticks of the controller, emphasizing their precision and anti-drift capabilities.

3.2 Adjustable RGB Lighting

Customize your gaming atmosphere with 9 RGB light colors (Red, Orange, Yellow, Green, Cyan, Blue, Purple, White, Color Gradient) and 4 light modes (Dazzle, Monochrome, Monochrome Breathe Cycle, Light Off). Use the dedicated button or combination (refer to quick start guide) to cycle through colors and modes.



Image: Illustration of the controller's RGB lighting features, showing 9 color options and 4 distinct light modes including Single Color, Light Off, Single Color Cycle, and Dazzling Color Change.

3.3 Macro Programming Function

The controller features a Marco Programming Function, allowing you to assign complex sequences of commands to the M1 and M2 back buttons. This enables swift execution of multiple actions with a single press, providing a competitive advantage. Refer to the quick start guide for detailed instructions on setting up macros.




Image: Rear view of the controller highlighting the M1 and M2 programmable back buttons, used for macro functions to unlock more combos.

3.4 6-Axis Gyro Motion Sensing

Equipped with a 6-axis gyroscope, the controller detects inclination and movement in real-time. This allows for intuitive in-game actions such as controlling character direction, attacking, or dodging through slight hand movements, enhancing the sensory experience and realism of games.

3.5 Dual Vibration Feedback

The integrated dual-motor vibration system provides realistic haptic feedback, immersing you further into the game world. Experience impacts, explosions, and environmental effects through dynamic vibrations.



Image: Visual representation of the controller's internal dual vibration motors and the 6-axis gyro sensor, illustrating how they contribute to immersive gameplay.

3.6 3.5mm TRRS Audio Jack

Connect your headset to the built-in 3.5mm TRRS audio jack for immersive sound and clear communication with teammates in supported games. The controller also features a built-in speaker for additional audio cues.




Image: A person wearing headphones while holding the BETMI Wireless Gaming Controller, demonstrating the use of the built-in 3.5mm TRRS audio jack.

4. Maintenance

4.1 Cleaning

To clean the controller, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals, solvents, or abrasive materials, as these can damage the controller's finish and internal components.

4.2 Storage

Store the controller in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity. Keep it away from dust and liquids. When not in use for extended periods, ensure the controller is fully charged before storage to maintain battery health.

4.3 Battery Care

The controller contains a rechargeable lithium-ion battery. To prolong battery life, avoid fully discharging the battery frequently. Charge the controller regularly, even if not in constant use. Do not expose the battery to high temperatures or attempt to disassemble it.

5. Troubleshooting

5.1 Controller Not Connecting

- Ensure the controller is charged.
- For initial PS5 connection, ensure you perform the wired pairing step first.
- Check if Bluetooth is enabled on your console/PC/device.
- Try restarting your console/PC and the controller.
- If connecting to a new device, ensure the controller is in pairing mode.

5.2 Input Lag or Unresponsive Buttons

- Ensure the controller is fully charged. Some users report better performance when not at maximum charge, but generally, a good charge is recommended.
- Reduce interference by moving closer to the console/PC or removing obstacles.
- Try a wired connection to eliminate potential wireless interference.
- Reset the controller (refer to quick start guide for reset pinhole location, if applicable).

5.3 Controller Disconnecting Randomly

- Ensure the controller is within range of the console/PC.
- Check for other wireless devices that might be causing interference.
- Ensure the controller's battery is not critically low.
- Update console/PC system software and controller firmware (if available).

6. Specifications

Model Number	Wireless Gaming Controller
Brand	BETMI
Compatibility	PS5/Pro/Slim, PC (Windows 7/8/10/11), Android, iOS, Steam Deck
Connectivity	Bluetooth 5.3, Wired (USB-C)
Joysticks & Triggers	Hall Effect
Lighting	9 RGB Colors, 4 Light Modes
Special Features	Macro Programming, Dual Vibration, 6-Axis Gyro, Touchpad, 3.5mm TRRS Audio Jack
Battery Capacity	1000mAh
Product Dimensions	5.98 x 4.02 x 2.17 inches
Item Weight	9.6 ounces

7. Warranty and Support

7.1 Warranty Information

Please refer to the product packaging or the official BETMI website for specific warranty terms and conditions. Typically, electronic products come with a limited manufacturer's warranty covering defects in materials and workmanship.

7.2 Customer Support

For technical assistance, troubleshooting, or warranty claims, please contact BETMI customer support through the contact information provided on the product packaging or the official BETMI website. Have your product model number and purchase details ready when contacting support.

© 2026 BETMI. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FPQVPC1P

More documents and user manuals: **https://manuals.plus/**