Unineo 25IN-26-16G

Unineo Fireplace TV Stand with Electric Fireplace and LED Lights

Model: 25IN-26-16G
Brand: Unineo

1. Introduction

Thank you for choosing the Unineo Fireplace TV Stand. This manual provides essential information for the safe assembly, operation, and maintenance of your new entertainment center. Please read all instructions carefully before use and retain this manual for future reference.

Important Safety Information

- Always follow the instructions provided in the manual for safe use of the fireplace insert.
- Keep children and pets away from the fireplace when in use.
- Do not leave the fireplace unattended while in use.
- Allow the fireplace to cool down before cleaning or performing any maintenance.
- Ensure the TV stand is placed on a stable, level surface.
- Do not overload the TV stand; the maximum weight limit is 150 lbs.

2. Product Overview

The Unineo Fireplace TV Stand combines rustic farmhouse aesthetics with modern features, including an electric fireplace and customizable RGB LED lighting. It is designed to accommodate TVs up to 80 inches and offers ample storage with sliding barn doors and adjustable shelves.



Figure 2.1: Overall view of the Unineo Fireplace TV Stand.

Your browser does not support the video tag.

Video 2.1: Overview of the Unineo Fireplace TV Stand with Sliding Barn Door. This video provides a general visual introduction to the product's features and design.

3. Package Contents

The Unineo Fireplace TV Stand is shipped in two separate packages: one for the cabinet and one for the electric fireplace insert. Please ensure you have received both packages and all components are present before beginning assembly.

Included Components:

- TV Stand Cabinet (various panels and hardware)
- 26-inch Electric Fireplace Insert
- Electric Fireplace Remote Control
- RGB LED Light Strip and Remote Control

- Assembly Instructions Manual



Figure 3.1: Diagram showing the dimensions of the TV stand and its weight capacity. Note that the cabinet and fireplace may arrive in separate shipments.

4. Assembly Instructions

Assembly of the Unineo Fireplace TV Stand requires two people. All parts are independently labeled, and step-by-step instructions are included in the separate assembly manual. Please refer to the dedicated assembly manual for detailed diagrams and instructions for each step.

General Assembly Tips:

- Lay out all components and hardware on a soft, clean surface to prevent scratches.
- Identify each part using the labels and the parts list in the assembly manual.
- Follow the numbered steps sequentially.
- Do not overtighten screws to avoid damaging the engineered wood.

- The fireplace insert is installed into the central compartment of the TV stand during assembly.

5. Initial Setup

Placement

- Place the assembled TV stand on a flat, stable surface.
- Ensure there is adequate clearance around the unit for proper ventilation, especially for the fireplace heater.
- Position the TV stand near a standard electrical outlet for the fireplace and LED lights.

Power Connection

- Plug the electric fireplace into a grounded 120V AC outlet.
- Connect the RGB LED light strip to its power source and ensure the remote control for the lights is accessible.

6. Operating the Electric Fireplace

The 26-inch electric fireplace insert provides realistic 3D flame effects and a 1400W heater. It can be operated via the included remote control or the control panel on the unit.



Figure 6.1: Detailed view of the 26-inch electric fireplace insert, showcasing its realistic 3D log and flame effects.

Fireplace Features:

- **Power On/Off:** Press the power button on the remote or unit.
- **Flame Color Modes:** Choose from 8 flame color modes and 6 ember bed colors to customize the ambiance.
- **Flame Brightness & Speed:** Adjust the intensity and movement of the flames.
- **Heater Function:** The 1400W heater provides supplemental heat for rooms up to 450 sq. ft.
- **Thermostat:** Set your desired room temperature (62°F-90°F).
- **Timer:** Program the fireplace to turn off automatically after a set period (0.5-9 hours).
- **Overheat Protection:** The unit includes a safety feature that automatically shuts off if it overheats.
- **Child Lock:** A child lock feature is available for added safety.

The fireplace can operate with or without the heat function, allowing for year-round enjoyment of the flame effects.

7. Operating the RGB LED Lights

The TV stand features customizable RGB LED lights in the side compartments, controlled via a dedicated remote or a smartphone

app.



Figure 7.1: The TV stand with RGB LED lights illuminated, showing control options via remote or smartphone app.

LED Light Features:

- **Color Selection:** Choose from hundreds of colors to match your mood or decor.
- **Brightness Levels:** Adjust the intensity of the lighting.
- **Rhythm Modes:** Lights can change automatically with music or via a built-in microphone mode, synchronizing with audio.
- **Control Options:** Use the included remote control or download the compatible smartphone app for full control.

8. Care and Maintenance

Cleaning the TV Stand:

- Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- For the glass panels on the sliding barn doors, use a glass cleaner and a lint-free cloth.

Fireplace Maintenance:

- Ensure the fireplace is unplugged and completely cool before cleaning.
- Wipe the exterior surfaces with a soft, damp cloth.
- Do not block the air intake or exhaust vents of the heater.

9. Troubleshooting

Fireplace Issues:

- **No Power:** Check if the unit is properly plugged into a working outlet. Ensure the power switch on the unit is in the 'ON' position.
- **No Heat:** Verify the thermostat setting. If the room temperature is above the set temperature, the heater will not activate. Check if the overheat protection has been triggered (unplug, wait 15 minutes, then plug back in).
- **Remote Not Working:** Replace the remote control batteries. Ensure there are no obstructions between the remote and the fireplace sensor.

LED Light Issues:

- **Lights Not Turning On:** Check the power connection for the LED strip. Ensure the LED remote control batteries are functional.
- **Inconsistent Lighting:** Ensure the LED strip is securely connected and not damaged.

If you encounter issues not listed here or if troubleshooting steps do not resolve the problem, please contact customer support.

10. Specifications

Feature	Specification
Brand	Unineo
Model Name	25IN-26-16G
Color	Rustic Gery
Material	Engineered Wood
Product Dimensions (D x W x H)	15.63"D x 69.61"W x 32.11"H
Item Weight	130 Pounds
Weight Limit	150 Pounds
Fireplace Size	26 inches
Heater Power	1400W
Heating Area	Up to 450 Sq.ft
Special Features	Adjustable Flame, Music Mode, RGB LED Light, Thermostat, Timer, Overheat Protection, Child Lock
Door Style	Sliding Barn Door with Window
Number of Shelves	7 (including adjustable shelves)

11. Warranty and Support

For any questions, concerns, or issues regarding your Unineo Fireplace TV Stand, please refer to the contact information provided with your purchase or visit the Unineo official website for customer support. Please retain your proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question