

RALGEND 1901SCBK

RALGEND Farmhouse Tall Shoe Cabinet with Coat Rack (Model 1901SCBK) - Instruction Manual

Model: 1901SCBK | Brand: RALGEND

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your RALGEND Farmhouse Tall Shoe Cabinet with Coat Rack, Model 1901SCBK. Please read this manual thoroughly before assembly and use to ensure safe and proper operation of the product.

SAFETY INFORMATION

Important Safety Warnings:

- Always secure the cabinet to the wall using the anti-tip device provided. This prevents accidental tipping and ensures stability.
- Keep small children and pets away from the cabinet when it is not secured to prevent injury.
- Exercise caution with sharp edges and small parts during assembly to avoid cuts or choking hazards.
- Ensure all screws and fasteners are tightened securely before use. Periodically check for loose connections.
- Do not overload shelves or hooks beyond their intended capacity.

Anti-Tip Device

The anti-tip device prevents accidental tipping, ensuring safety.





Image: Anti-Tip Device installation. The diagram illustrates the correct method of securing the cabinet to the wall to prevent tipping, showing the difference between a secured and unsecured unit.

PRODUCT FEATURES

- **Multi-Space Storage:** This unit integrates 10 double hooks, 3 tiered flip drawers, 2 top open cubbies, and 1 open shelf, providing versatile storage for various items.
- **3 Flip Drawers:** Features tilt-out drawers for easy access to shoes. These drawers help prevent dust accumulation and protect shoes. Each drawer includes a removable divider to accommodate different shoe heights.
- **Classic Farmhouse Style:** Designed with a wood grain finish, X-framed doors, and black metal handles, offering a farmhouse aesthetic that complements various home decor styles.
- **Space-Saving Design:** Offers significant storage capacity within a compact footprint, suitable for entryways, hallways, living rooms, and foyers.
- **Durable Construction:** Constructed from premium engineered wood for stability and longevity. Includes an anti-tip device for enhanced safety.

Spacious Storage Space



Closing



Opening

Image: Spacious Storage Space. This image demonstrates the cabinet's capacity with its flip drawers closed and open, revealing multiple pairs of shoes.



Upper Open Storage

Adds extra storage space for bags, books, or decorations.

10 Metal Hooks

Make it easy to hang hats, scarves, and bags for easy access.



X-Framed Design

Creates a cozy farmhouse look that easily complements any home decor.

Image: Feature Details. Close-up views of the upper open storage for bags and decor, the 10 metal hooks for hanging items, and the X-framed design on the drawer fronts.

COMPONENTS AND PARTS LIST

Before beginning assembly, ensure all components are present and undamaged. Refer to the included assembly instructions for a complete, detailed parts list and hardware identification.

- Main Cabinet Panels (Side panels, back panel, top panel, bottom panel)
- Flip Drawers (3 units)
- Removable Dividers for Flip Drawers
- Coat Hooks (10 double hooks)
- Upper Open Cubby Shelves
- Anti-Tip Device and Wall Anchors
- Assembly Hardware (Screws, dowels, cam locks, etc.)
- Handles for Flip Drawers

ASSEMBLY INSTRUCTIONS

Your RALGEND shoe cabinet comes with a comprehensive assembly manual. Please follow the step-by-step instructions provided in that document for proper and safe assembly.


Before You Begin:

1. **Unpack:** Carefully unpack all components and hardware. Lay them out on a clean, soft surface to prevent scratches.
2. **Identify Parts:** Match each part to the diagrams and labels in the included assembly manual.
3. **Gather Tools:** Ensure you have the necessary tools (e.g., screwdriver, hammer, level) as specified in the assembly manual.
4. **Read Instructions:** Read through all assembly steps before starting.

General Assembly Steps (Refer to included manual for specifics):

- Assemble the main frame of the cabinet.
- Install the back panel.
- Attach the upper cubby shelves and coat rack section.
- Assemble and install the three flip drawers, including their dividers and handles.
- Secure the anti-tip device to the cabinet and then to a wall stud or appropriate wall anchor.

PRODUCT SIZE



Anti-Tip Device



Removable Dividers



Image: Product Dimensions and Key Features. This diagram provides overall dimensions of the cabinet, including the height of the upper shelf and depth of the shoe compartments, along with close-ups of the anti-tip device and removable drawer dividers.



Image: Assembled Product in Use. A complete view of the RALGEND shoe cabinet with coat rack, showcasing its functionality in an entryway with shoes stored in flip drawers, and hats and coats on hooks.

OPERATING INSTRUCTIONS

Using the Flip Drawers:

- To open a drawer, gently pull the handle outwards. The drawer will tilt forward, revealing the shoe compartments.
- Place shoes into the compartments. The removable dividers can be adjusted or removed to accommodate different shoe sizes and types (e.g., boots, heels).
- To close, push the drawer back into the cabinet until it is flush with the cabinet front.

3-Position Adjustable Shelf



With



Without



Image: 3-Position Adjustable Shelf. This image highlights the adjustable nature of the shoe dividers within the flip drawers, allowing for customization based on shoe height.

Using the Coat Rack and Upper Storage:

- The 10 double hooks are designed for hanging coats, hats, scarves, bags, and other accessories. Distribute weight evenly across the hooks.
- The two top open cubbies and the open shelf provide space for decorative items, small storage baskets, books, or frequently used items.

Upper Open Storage

Adds extra storage space for bags, books, or decorations.



Image: Upper Open Storage. A detailed view of the top section of the cabinet, showing how the open cubbies can be used for decorative items, small plants, or storage baskets.

MAINTENANCE AND CARE

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Dusting:** Regularly dust with a dry, soft cloth to prevent buildup.
- **Spills:** Clean spills immediately with a dry cloth to prevent staining or water damage.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading or discoloration.
- **Humidity Control:** Maintain a stable humidity level to prevent warping or cracking of the engineered wood.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Cabinet is wobbly or unstable.	Screws are loose; anti-tip device not installed or improperly secured.	Ensure all assembly screws are tightened. Install or re-secure the anti-tip device to a wall stud or appropriate anchor.
Flip drawers do not open/close smoothly.	Misalignment during assembly; obstruction; worn hardware.	Check drawer runners and hinges for proper alignment. Remove any obstructions. If hardware is worn, contact support.
Shoes do not fit in drawers.	Dividers are set too high/low; shoes are too large.	Adjust or remove the internal dividers within the flip drawers to accommodate taller shoes.
Missing parts or damaged components.	Manufacturing error or shipping damage.	Do not proceed with assembly. Contact RALGEND customer support immediately for replacement parts.

PRODUCT SPECIFICATIONS

- **Brand:** RALGEND
- **Model Number:** 1901SCBK
- **Material:** Engineered Wood
- **Color:** Black
- **Style:** Farmhouse
- **Overall Dimensions:** 31.5"L x 9.4"W x 76.4"H
- **Item Weight:** Approximately 80 pounds
- **Special Features:** Flip Drawers, Storage Cubbies, Coat Hooks, Anti-Tip Device
- **Assembly:** Required (Instructions Included)

OFFICIAL PRODUCT VIDEOS

RALGEND Farmhouse Tall Shoe Cabinet Overview

Your browser does not support the video tag.

Video: An overview of the RALGEND Farmhouse Tall Shoe Cabinet, showcasing its design and features in various settings.

Farmhouse Tall Shoe Cabinet with Coat Rack Features

Your browser does not support the video tag.

Video: A detailed look at the features of the Farmhouse Tall Shoe Cabinet with Coat Rack, including its storage solutions and design elements.

WARRANTY AND SUPPORT

For warranty information, missing parts, or any product-related inquiries, please contact RALGEND customer support. Refer to your purchase documentation or the RALGEND official website for contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FPQW8NPS>

More documents and user manuals: **<https://manuals.plus/>**