

RALGEND 3501CWWH

RALGEND Kids Toy Storage Organizer

Model: 3501CWWH

			Introduction	Safety Information	Package		
Contents	Assembly	Features	Usage	Maintenance	Troubleshooting	Specifications	Support

1. INTRODUCTION

This manual provides instructions for the assembly, operation, and maintenance of your RALGEND Kids Toy Storage Organizer, Model 3501CWWH. Please read this manual thoroughly before assembly and use to ensure safe and correct operation. Keep this manual for future reference.

2. SAFETY INFORMATION

WARNING: Failure to follow these safety instructions may result in injury or damage to the product.

- Always assemble according to the instructions provided.
- Do not overload shelves or storage compartments.
- Use the included anti-tip devices to securely anchor the unit to a wall. This is crucial to prevent tipping and potential injury, especially for children.
- Keep the unit away from heat sources and liquids.
- Do not use the product if any part is damaged. Contact customer support for replacement parts.
- Ensure all fasteners are tightened securely before use and periodically check for tightness.
- Supervise children when they are using or interacting with the storage organizer.

Anti-Tip Devices

Securely anchors the bookshelf to the wall for safe use by children.




Figure 2.1: Anti-Tip Devices. This image shows a close-up of the anti-tip bracket and diagrams illustrating how to securely anchor the bookshelf to the wall to prevent tipping, especially when children are present.

3. PACKAGE CONTENTS

Before assembly, verify that all parts and hardware are present. Refer to the parts list included in your product packaging for a complete inventory. If any parts are missing or damaged, do not proceed with assembly and contact RALGEND customer support.

4. ASSEMBLY INSTRUCTIONS

Assembly is required for this product. Please follow the illustrated instructions provided in your product packaging carefully. All necessary tools are included. It is recommended to assemble the unit on a soft, clean surface to prevent scratches.

1. Unpack all components and lay them out on a protected surface.
2. Identify each part by comparing it to the parts list in the manual.

3. Follow the step-by-step diagrams for connecting panels and installing hardware.
4. Ensure all screws and fasteners are securely tightened. Do not overtighten.
5. Install the anti-tip device as instructed in the safety section and the assembly guide.



Figure 4.1: Product Dimensions. This diagram provides detailed measurements for the overall unit and individual storage sections, including cubbies, cabinets, and bookshelf tiers.

5. PRODUCT FEATURES

- **Storage Capacity:** The organizer measures 46.8"L x 13.7"W x 42"H and includes 4 open cubbies, 2 storage cabinets, a 3-tier step bookshelf, and 3 toy storage bins.
- **Child-Friendly Design:** The height is designed for easy access by children, promoting organization skills.
- **Durable Construction:** Crafted from high-quality particle board for stability and longevity.
- **Safety Features:** Smoothly rounded corners, floor protectors, and anti-tip devices are included for enhanced safety.



3 Toy Storage Cubbies

Perfectly organizing toys and keeping the space tidy.

Figure 5.1: Toy Storage Cubbies. This image highlights the three spacious cubbies designed for organizing toys, helping to keep the play area tidy.



Figure 5.2: Organized Storage. This image displays the organizer with books on the tiered shelves, toys in the open cubbies, and baskets in the central compartments, demonstrating its versatile storage capabilities.

6. USAGE

The RALGEND Kids Toy Storage Organizer is designed for organizing books and toys in children's rooms, playrooms, nurseries, or classrooms. Its multi-functional design allows for various items to be stored efficiently.

- Use the tiered bookshelf for displaying books, allowing children easy access to their reading materials.
- The open cubbies are suitable for larger toys, stuffed animals, or toy bins.
- The closed cabinets can be used for items that need to be stored out of sight or for smaller accessories.

Your browser does not support the video tag.

Video 6.1: Toy Storage Organizer Overview. This video provides a brief demonstration of the RALGEND Kids Toy Storage Organizer, showcasing its various compartments and how it can be used to store books and toys.

Your browser does not support the video tag.

Video 6.2: 3-Tier Toy Storage Cabinet Features. This video highlights the specific features of the 3-tier toy storage cabinet, including the doors and overall design for organizing children's items.

7. MAINTENANCE

To ensure the longevity and appearance of your RALGEND Kids Toy Storage Organizer, follow these simple maintenance guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.
- **Inspection:** Periodically check all fasteners and connections to ensure they remain tight. Retighten if necessary.
- **Damage:** If any part becomes damaged, discontinue use and contact customer support for assistance or replacement parts.

8. TROUBLESHOOTING

If you encounter any issues with your RALGEND Kids Toy Storage Organizer, refer to the following common solutions:

- **Unit feels wobbly:** Ensure all screws are fully tightened. Verify that the unit is placed on a flat, level surface. Re-install the anti-tip device if it has come loose.
- **Doors do not close properly:** Check hinges for proper alignment and tightness. Adjust if needed.
- **Scratches or minor damage:** For minor blemishes, touch-up paint or furniture markers matching the product color may be used.

For issues not listed here, please contact RALGEND customer support.

9. SPECIFICATIONS

Feature	Detail
Model Name	Storage Cabinet
Model Number	3501CWWH
Brand	RALGEND
Dimensions (L x W x H)	46.8" x 13.7" x 42" (119cm x 35cm x 106.8cm)
Material	Engineered Wood
Color	White and Walnut
Number of Shelves	3 (tiered bookshelf)
Included Components	Hardware Kit, Anti-Tip Accessory
Assembly Required	Yes
Item Weight	64.5 pounds

10. WARRANTY AND SUPPORT

RALGEND products are designed for quality and durability. For warranty information, replacement parts, or technical

support, please refer to the contact information provided in your product packaging or visit the official RALGEND website. Please have your model number (3501CWWH) and purchase date available when contacting support.

© 2025 RALGEND. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page
<https://manuals.plus/asin/B0FPQYGRS3>

More documents and user manuals: <https://manuals.plus/>