



[Manuals.plus](#) /

> [VEVOR](#) /

> VEVOR Baby Playpen P2001-1 Instruction Manual

## VEVOR P2001-1

# VEVOR Baby Playpen P2001-1 Instruction Manual

Model: P2001-1

## 1. INTRODUCTION

This instruction manual provides essential information for the safe assembly, operation, and maintenance of your VEVOR Baby Playpen, model P2001-1. Please read this manual thoroughly before use and retain it for future reference. This playpen is designed to provide a safe and enclosed space for babies aged 6 to 24 months.

## 2. SAFETY INFORMATION

**WARNING: Failure to follow these safety instructions could result in serious injury or death.**

- Always ensure all parts are correctly assembled and securely locked before placing a child in the playpen.
- Never leave a child unattended in the playpen. Constant supervision is required.
- Do not modify the playpen or use accessories not approved by VEVOR.
- Keep the playpen away from open flames, heaters, and other heat sources.
- Ensure the playpen is placed on a flat, stable surface.
- Do not place items with strings, cords, or ribbons inside the playpen that could pose a strangulation hazard.
- Discontinue use if any part of the playpen is damaged or broken. Contact customer support for replacement parts.
- The playpen is suitable for children aged 6 to 24 months.
- The play mat is not included. Please prepare it separately.

## 3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly.



*Image: All components of the VEVOR Baby Playpen, including fabric covers, tubes, connectors, and tools.*

- Fabric Covers (Single Piece): 8
- Lower Surround Tubes with Suction Cups: 8
- Upper Surround Tubes: 8
- Upright Tubes: 16
- Pull Rings: 2
- L-Shaped Hex Wrench: 1

## 4. SETUP AND ASSEMBLY

Follow these steps to assemble your VEVOR Baby Playpen.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface. Refer to the "Package Contents" section to ensure all pieces are present.
2. **Connect Tubes:** Insert the upright tubes into the connectors on the lower surround tubes (with suction cups) and upper surround tubes. Ensure a secure fit.

3. **Attach Fabric Covers:** Slide the fabric covers over the assembled frame sections. Ensure the mesh panels are facing outwards and the zippered door is positioned as desired.
4. **Secure Connections:** Use the provided L-shaped hex wrench to tighten any screws or connections, ensuring the frame is rigid and stable.
5. **Check Stability:** Once assembled, gently push on the playpen to confirm it is stable and does not wobble. The suction cups on the bottom tubes should firmly grip the floor.

## Enhanced Triple Reinforcement

Ensure the playpen stays firm & secure



*Image: Detail of the playpen's reinforced structure, highlighting strong suction cups, thickened iron tubes, and durable connectors for enhanced stability.*

## 5. OPERATING INSTRUCTIONS

### 5.1 Adjusting Playpen Shape

The VEVOR Baby Playpen features a modular design, allowing you to configure it into various shapes

such as a circle, square, or L-shape to fit your space requirements.



*Image: Examples of the playpen configured into different shapes, demonstrating its modularity.*

## 5.2 Folding for Storage and Portability

The playpen is designed for easy 3-step folding for convenient storage and transport.

1. **Lift the Switch:** Locate the folding switches on the connectors. Lift the switch to unlock the mechanism.
2. **Activate All Switches:** Unlock all switches according to step 1 to make all folding mechanisms active.
3. **Fold Completely:** Push both sides of the playpen closer together until it is fully folded into a compact size.

# 3-Step Folding

Fold it easily with one person



①  
Lift the switch  
to unlock



②  
Unlock all switches according  
to step 1, making them active



③  
Push both sides closer  
until fully folded

Image: Visual guide demonstrating the three steps to fold the playpen for compact storage.

## Multiple Safety Features

Safe for baby to play inside alone



Safe Height  
Prevent baby from  
climbing out



No Gap Design  
Avoid pinching  
hands




Visible & Breathable Mesh  
Enhance baby's  
security & comfort



Image: The playpen in its folded state, illustrating its compact size for storage and travel.

## 6. MAINTENANCE AND CARE

- **Cleaning Fabric:** The fabric cover is detachable and washable. Remove the fabric cover from the frame and machine wash it on a gentle cycle with mild detergent. Air dry thoroughly before reattaching.




*Image: Demonstrating the detachable and washable fabric cover for easy cleaning.*

- **Cleaning Frame:** Wipe the metal frame and plastic connectors with a damp cloth and mild soap. Dry immediately to prevent rust.
- **Regular Inspection:** Periodically check all parts for wear, damage, or loose connections. Tighten any loose screws and replace damaged parts immediately.
- **Storage:** When not in use, store the folded playpen in a dry, cool place away from direct sunlight.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Playpen is wobbly or unstable.	Connections are not fully secured; suction cups not engaged.	Ensure all tubes are fully inserted into connectors and screws are tightened. Press down firmly on the playpen to engage suction cups on a smooth surface.
Difficulty folding the playpen.	Folding switches are not fully unlocked.	Ensure all folding switches are lifted and active before attempting to fold. Refer to Section 5.2.
Zippered door is stuck.	Fabric caught in zipper; zipper mechanism damaged.	Gently free any fabric caught in the zipper. If damaged, contact customer support.

## 8. SPECIFICATIONS



*Image: Detailed diagram with playpen dimensions and a summary of key specifications.*

**Item Model Number:** P2001-1

**Fabric Material:** 210D Oxford Fabric, Nylon Zipper

**Support Rod Material:** Iron Tubes

**Shape:** Amorphous (Adjustable as Needed)

**Net Weight:** 19.62 lbs / 8.9 kg

**Internal Dimensions:** 47.2 x 47.2 inch / 1200 x 1200 mm

**External Dimensions:** 50 x 50 x 27.36 inch / 1270 x 1270 x 695 mm

**Age Range:** 6-24 Months

**UPC:** 197988160595

## 9. WARRANTY AND SUPPORT

For warranty information, replacement parts, or technical support, please contact VEVOR customer service through their official website or the retailer where the product was purchased.

Please have your model number (P2001-1) and proof of purchase ready when contacting support.