

SUNVIVI Black-GlassTop-B

SUNVIVI 3-in-1 Sandwich, Waffle, and Panini Maker

Model: Black-GlassTop-B

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using this appliance. Retain this manual for future reference.

- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- The appliance is equipped with smart temperature control to prevent overheating.
- The cool-touch handle ensures safer operation during cooking and plate removal.

2. PRODUCT OVERVIEW


The SUNVIVI 3-in-1 Sandwich Maker is a versatile kitchen appliance designed for preparing sandwiches, waffles, and grilled items. It features a compact design and removable non-stick plates for easy use and cleaning.

Components:



- Main Unit with Cool-Touch Handle
- Removable Waffle Plates (2 sets)
- Removable Sandwich Plates (2 sets)
- Removable Grill Plates (2 sets)
- Instruction Manual

3-In-1 Sandwich Maker

3 different baking trays for all your cooking needs



Waffle Plates



Sandwich Plates



Grill Plates



Image: The 3-in-1 Sandwich Maker includes interchangeable waffle, sandwich, and grill plates, demonstrated with various cooked foods.

Compact Size

Perfect for dorms, apartments, offices, kitchenettes...



Image: The appliance's compact size makes it suitable for small spaces.

3. SETUP AND FIRST USE

Unpacking:

1. Remove all packaging materials, stickers, and labels from the appliance.
2. Wipe the exterior of the appliance with a damp cloth.

Installing Plates:

1. Ensure the appliance is unplugged and cool.
2. Select the desired plates (waffle, sandwich, or grill).
3. Align the plates with the slots on the top and bottom heating elements.
4. Press down gently until the plates click into place.

Non-stick Plates

Easy to clean and maintain



Image: The appliance with non-stick waffle plates installed, ready for use.

4. OPERATING INSTRUCTIONS

General Operation:

1. Ensure the correct plates are installed and securely locked.
2. Close the appliance and plug it into a 120V AC electrical outlet.
3. The red indicator light will illuminate, signaling that the appliance is preheating.
4. Once the green indicator light illuminates, the appliance has reached the optimal cooking temperature and is ready for use. Preheating typically takes 3-4 minutes.
5. Carefully open the appliance using the cool-touch handle.
6. Place your food (e.g., bread for sandwiches, batter for waffles, meat for grilling) onto the bottom plate.
7. Close the lid and latch the handle.
8. Cook until desired browning is achieved. Waffles typically cook in 5 minutes.
9. Use a heat-resistant plastic or wooden utensil to remove cooked food. Do not use metal utensils, as they can damage the non-stick coating.

10. Unplug the appliance after use and allow it to cool completely before cleaning.



**Done in
5 minutes**

Quick breakfast,
start your day full of energy.

Image: Preparing waffles in the appliance, which cooks quickly.

Your browser does not support the video tag.

Video: This video demonstrates the process of changing plates, cooking bacon and eggs on the grill plates, and preparing a sandwich on the sandwich plates, followed by making waffles and cleaning the plates. It highlights the versatility and ease of use of the 3-in-1 appliance.

5. MAINTENANCE AND CLEANING

Proper cleaning and maintenance will extend the life of your appliance.

Cleaning the Plates:

1. Ensure the appliance is unplugged and completely cool.
2. Press the release buttons to detach the plates from the main unit.
3. Wash the non-stick plates with warm, soapy water using a soft sponge or cloth. The non-stick coating allows for easy cleaning.
4. Rinse thoroughly and dry completely before reattaching or storing.

Cleaning the Main Unit:

- Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water or any other liquid.
- Do not use abrasive cleaners or scouring pads, as they may damage the surface.



Image: Details of the cool-touch handle, safety indicator lights, and overheat protection feature.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in or power outlet issue.	Ensure the appliance is securely plugged into a working 120V outlet. Check the circuit breaker.
Food is not cooking evenly.	Insufficient preheating or uneven food placement.	Allow the appliance to fully preheat until the green indicator light turns on. Distribute food evenly on the plates.

Problem	Possible Cause	Solution
Food sticks to the plates.	Plates not properly greased or damaged non-stick coating.	Lightly grease the plates with cooking spray or oil before adding food. Avoid using metal utensils that can scratch the coating.
Smoke or unusual odor during first use.	Residual manufacturing oils burning off.	This is normal for first use. Ensure adequate ventilation. If smoke persists, unplug and contact support.

7. SPECIFICATIONS

- **Brand:** SUNVIVI
- **Model:** Black-GlassTop-B
- **Wattage:** 1000 watts
- **Voltage:** 120 Volts
- **Product Dimensions (D x W x H):** 9.33" x 9.25" x 3.82"
- **Item Weight:** 5.06 Pounds
- **Special Feature:** Non-Stick Coating, Tempered Glass Top
- **Certifications:** UL certified

8. WARRANTY AND SUPPORT

The SUNVIVI 3-in-1 Sandwich Maker comes with a 1-year warranty from the date of purchase. This warranty covers manufacturing defects under normal household use.

For any quality issues, technical support, or warranty claims, please contact SUNVIVI customer service.

You can find more information and contact details on the official SUNVIVI website: sunvivi.com

Please have your model number (Black-GlassTop-B) and purchase information ready when contacting support.