

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Radiolink](#) /

› [Radiolink T12D 12-Channel 2.4GHz RC Transmitter and R12F Receiver Kit Instruction Manual](#)

Radiolink T12D

Radiolink T12D 12-Channel 2.4GHz RC Transmitter and R12F Receiver Kit Instruction Manual

Model: T12D | Brand: Radiolink

[Overview](#) [Setup](#) [Operating Instructions](#) [Maintenance Support](#) [Troubleshooting](#) [Specifications](#)

1. PRODUCT OVERVIEW

The Radiolink T12D is a 12-channel 2.4GHz RC transmitter designed for a wide range of remote-controlled models. It comes paired with the R12F receiver, offering reliable control and advanced features for enthusiasts and professionals. This system provides stable signal transmission, extensive model storage, and compatibility with various external modules and simulators.

Key Features

- **12 Fully Proportional Channels:** All 12 channels are programmable for advanced settings, including V-tail and Delta-Wing mixing. (Note: T12D firmware must be updated to version 1.7.1 for full functionality).
- **32 Model Storage Capacity:** Store settings for up to 32 different models.
- **Extended Range and Stability:** Features 2.4GHz FHSS spread spectrum technology with 67 channels, ensuring excellent anti-interference performance and a stable signal up to 4 km.
- **External Module Support:** Compatible with popular long-range RC modules like ExpressLRS (e.g., BETA FPV ELRS Nano TX, Radiolink ATA ELSR 1W) and TBS Crossfire (e.g., TBS Crossfire Nano TX) via a pre-installed module bay.
- **Open-Source Simulator Compatibility:** Connect directly to your computer via a Type-C cable for use with simulators such as TRYP FPV, AeroFly, Uncrashed, Liftoff, FPV LOGIC, and Velocidrone (TBS Simulator). Compatible with MacOS and Windows.
- **Multi-Language Navigation:** The 2.8-inch color screen offers a user-friendly menu in multiple languages, including English, German, French, Russian, Chinese, Japanese, Spanish, Korean, Thai, and Polish.
- **Wide Receiver Compatibility:** Compatible with Radiolink R16F, R12F, R8EF, R8XM, R8FM, R8SM, R8FGH, R8FG, R7FG, R6FG, R6F, R4FGM, and R4F receivers. *Note: Not compatible with non-Radiolink receivers/transmitters.*

Wide Applicability

Support helicopters, fixed-wings, gliders, multi-rotors, racing drones, football drones, engineering vehicles, racing boats, robots, lawnmowers, bait boats, mechas and more.



Image: Radiolink T12D Transmitter highlighting its 12 channels and other features.

Radiolink T12D

12 Channels Transmitter

- Long-range Modules Supports
- 50 Groups of Models Storage
- 16 Groups of Models Sub-ID Storage
- Battery Voltage Telemetry
- 8 Programmable Mixes Control
- Multiple Languages



Image: Wide Applicability of the T12D transmitter across different RC models.

2. SETUP


2.1 Package Contents

Before proceeding with setup, ensure all components are present in the package:


- 1 x T12D Transmitter
- 1 x R12F Receiver
- 1 x Type-C Cable
- 1 x Hook and Spring
- 1 x Instruction Manual
- 1 x ELSR Module Mounting Base (pre-installed)

Menu Multiple Languages


The optional language menu includes Chinese, English, German, French, Russian, Japanese, Spanish, Korean, Thai and Polish, etc.




English



German



French




Spanish

Image: Package List showing all included items.

2.2 Battery Installation

The T12D transmitter supports various battery types. Open the battery compartment on the back of the transmitter. Insert the chosen battery type, ensuring correct polarity. The transmitter supports LiPo batteries (2S-4S / 18650 LiPo Battery) or 8x AA batteries. A Type-C port is available for temporary 5V power, and a JST 2Pin connector is provided for battery connection.

Interface and Function



Dimension: 174.3 * 206.9 * 106.9mm (6.86" * 8.15" * 4.21")
Weight: 558g (19.68oz)

Image: Supported Battery Types and Battery Compartment details.


2.3 Binding the Receiver

To establish communication between the T12D transmitter and the R12F receiver, a binding process is required. Refer to the detailed binding instructions in the included manual for your specific receiver model. Ensure the transmitter and receiver are powered on and within close proximity during the binding procedure.


2.4 Firmware Update

For optimal performance and access to the latest features, it is recommended to keep the T12D firmware updated. Connect the transmitter to your computer using the provided Type-C cable. Visit the official Radiolink website for the latest firmware and update instructions. Firmware version 1.7.1 or higher is required for full 12-channel functionality and advanced mixing options.

T12D Features



RSSI & Voltage Telemetry



Programmierbare Mix Control Funktion



Multiple Languages Select



Fishing Spot Position

Image: Firmware Update and RC Simulator Support.

3. OPERATING INSTRUCTIONS

3.1 Transmitter Interface and Controls

Familiarize yourself with the various controls and indicators on the T12D transmitter:



Image: Transmitter Interface and Function Diagram.

- **VRA/VRB Knobs:** Proportional rotary knobs.
- **SWB/SWA (Three-way Switch):** Configurable 3-position switches.
- **SWC/SWD (Two-way Switch):** Configurable 2-position switches.
- **Trim Levers:** For fine-tuning control surfaces.
- **End Button:** Used for menu navigation and selection.
- **Push Button:** Used for menu navigation and selection.
- **Buzzer:** Provides audible feedback.
- **Type-C Port:** For firmware upgrades and simulator connection.
- **Long-range Modules Interface:** Bay for external modules.
- **Speaker:** For voice broadcast.
- **Memory Expansion Port:** Supports 4G TF card.

3.2 Menu Navigation and Settings

The T12D features a 2.8-inch color display with an intuitive menu system. Use the navigation buttons and knobs to access and adjust settings for your models.




Image: Menu Multiple Languages display.

- **Main Menu:** Access General Settings, Advanced Settings, Transmitter Settings, and Receiver Settings.
- **Language Selection:** Navigate to System Settings to choose your preferred language.
- **Model Storage:** The transmitter can store up to 32 models. Select and configure model-specific settings as needed.
- **Programmable Mixes:** Configure various mixing functions such as V-tail, Delta-Wing, and other custom mixes. Ensure firmware is updated to version 1.7.1 for advanced mixing capabilities.

3.3 External Module Usage

The T12D supports external long-range modules. Insert the compatible module into the pre-installed module bay.

Configure the module settings through the transmitter's menu as required by the specific module.

Mainstream External Modules Support



TBS Crossfire
Nano TX



ATA ELRS 1W



BETA FPV ELRS
Nano TX

*TBS Crossfire TX and BETA FPV ELRS Micro TX do not support direct insertion due to their size



T12D Parameter Adjustment Screen




Image: Mainstream External Modules Support.

3.4 Simulator Function

Connect the T12D to your computer using the Type-C cable to use it as a controller for RC simulators. No additional dongle is required. This feature is compatible with popular simulators like TRYP FPV, AeroFly, Uncrashed, Liftoff, FPV LOGIC, and Velocidrone (TBS Simulator) on MacOS and Windows.

3.5 Bait Boat Application

The T12D offers specialized functions for bait boat control, including 50cm fishing spot accuracy, user-defined 100 fishing spots, 600m stable offshore control distance, real-time built-in telemetry, and fishing spot GPS coordinate saving. Ensure the receiver is changed to R16F when using the fishing spot function.

Powered Battery Types Support




Image: Application to Bait Boat.

4. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the transmitter and receiver. Avoid using solvents or abrasive cleaners.
- **Storage:** Store the transmitter and receiver in a cool, dry place away from direct sunlight and extreme temperatures. Remove batteries if storing for extended periods to prevent leakage.
- **Battery Care:** Follow the manufacturer's guidelines for charging and discharging LiPo batteries. Do not overcharge or over-discharge.
- **Firmware:** Regularly check the Radiolink website for firmware updates to ensure optimal performance and access to new features.

5. TROUBLESHOOTING

- **No Power:**
 - Check battery installation and ensure batteries are charged.
 - Verify battery polarity.
 - Try connecting via Type-C for temporary power to diagnose.
- **No Signal/Binding Issues:**
 - Ensure both transmitter and receiver are powered on.
 - Repeat the binding procedure as described in the manual.
 - Check for physical obstructions or excessive distance between transmitter and receiver during binding.
 - Confirm receiver compatibility with the T12D.
- **Controls Unresponsive:**

- Check receiver connections to your model's servos/ESCs.
- Verify model settings in the transmitter menu.
- Ensure the transmitter's battery is not low.

- **Simulator Not Working:**

- Ensure the Type-C cable is securely connected to both the transmitter and computer.
- Verify that the simulator software recognizes the T12D as a joystick/controller.
- Check computer's device manager for proper driver installation (usually plug-and-play).

6. SPECIFICATIONS

Model Name	Radiolink T12D
Channels	12 Channels
Frequency	2.4GHz FHSS
Control Distance	Up to 4 km (2.49 miles)
Model Storage	32 Models
Display	2.8-inch Color Screen (320*240 pixels)
Main Material	Plastic
Color	White
Dimensions (L x W x H)	20.7 x 17.4 x 10.7 cm (8.15 x 6.85 x 4.21 inches)
Weight	540 grams (1.19 lbs)
Battery Requirement	Yes (Batteries not included)
Operating Mode	Remote Control
Special Features	12-channel RC transmitter with 32 storage modes, anti-interference, stable signal up to 4 km, compatible with external modules (ExpressLRS, TBS Crossfire), open-source simulator support, multi-language menu.

7. WARRANTY AND SUPPORT

7.1 Product Warranty

Information regarding product warranty is typically provided with the purchase documentation or on the manufacturer's official website. Please refer to these resources for details on warranty coverage and terms.

7.2 Customer Support

For technical assistance, troubleshooting, or any product-related inquiries, please contact the Radiolink after-sales team. You can typically find contact information on the official Radiolink website or through the retailer where the product was purchased. Online support is also available via Amazon by contacting Radiolink Direct.

Radiolink is committed to providing high-quality, diversified, and competitive technological products, backed by a professional research and development team and automated testing processes.



© 2025 Radiolink. All rights reserved.