

## Vissani VAW06R1AWTFR

# Vissani VAW06R1AWTFR 6,000 BTU Window Air Conditioner User Manual

Model: VAW06R1AWTFR

## IMPORTANT SAFETY INSTRUCTIONS

---

Please read all instructions carefully before using this air conditioner. Keep this manual for future reference.

### General Safety

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Do not operate the air conditioner with a damaged power cord or plug. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.
- Do not use the air conditioner in a wet room such as a bathroom or laundry room.
- Ensure the air conditioner is installed securely to prevent it from falling.

### Electrical Safety

- This unit requires a standard 115-Volt, 60 Hz, 3-prong grounded outlet. Do not modify the plug.
- Do not use extension cords or adapter plugs with this unit.
- Always unplug the air conditioner before cleaning or servicing.

## PACKAGE CONTENTS

---

Verify that all items are present in the package:

- Vissani VAW06R1AWTFR Window Air Conditioner Unit
- Remote Control
- Window Installation Kit (side panels, top rail, sash lock, foam seals, screws)
- User Manual (this document)

## PRODUCT OVERVIEW

The Vissani VAW06R1AWTFR is a 6,000 BTU window air conditioner designed to cool rooms up to 250 sq. ft. It features a digital control interface, LED thermostat, and a compact remote control for convenient operation.



**Figure 1:** Front view of the Vissani VAW06R1AWTFR 6,000 BTU Window Air Conditioner. The unit is white with a digital display on the left and a large grille covering the front.

### Key Features:

- **3-in-1 Comfort:** Offers cooling, circulation (fan), and dehumidification modes.
- **Digital Control Panel:** Easy-to-use interface with an LED thermostat.
- **Energy Saving Modes:** Includes ECO mode and a 24-hour timer.
- **Sleep Mode:** Adjusts temperature for comfortable sleep.
- **4-Way Air Direction:** Adjustable louvers to direct airflow up, down, left, or right.
- **Filter Clean Warning:** Indicator light for timely filter maintenance.
- **Remote Control:** For convenient operation from a distance.

## Unit Components:



**Figure 2:** Close-up view of the Vissani VAW06R1AWTFR control panel. It shows the digital temperature display, mode buttons (Auto, Cool, Dry, Fan), fan speed settings (Low, Med, High), ECO, Timer, Sleep, Filter, and On/Off buttons.

- **Control Panel:** Located on the front of the unit, featuring a digital display and various function buttons.
- **Air Filter:** Located behind the front grille, accessible for cleaning.
- **Air Louvers:** Adjustable vents for directing airflow.
- **Power Cord:** 3-prong grounded plug.

## SETUP AND INSTALLATION

This section provides instructions for installing your Vissani window air conditioner. A window opening with a maximum width of 36 inches is required.

### Before Installation:

1. Read all instructions before beginning.
2. Ensure you have all necessary tools (screwdriver, measuring tape, level).

3. Choose a window that is structurally sound and can support the weight of the unit.

### Window Installation Steps:

1. **Prepare the Window:** Open the window and clean the sill area.
2. **Attach Top Rail:** Secure the top rail to the top of the air conditioner unit with screws.
3. **Install Side Panels:** Slide the accordion side panels into the side channels of the unit.
4. **Place Unit in Window:** Carefully lift the unit and place it in the window opening, ensuring the bottom rail rests on the window sill. Tilt the unit slightly outwards to allow for proper drainage.
5. **Extend Side Panels:** Extend the accordion side panels to fill the window opening and secure them to the window frame with screws.
6. **Secure Window:** Lower the window sash behind the top rail of the unit. Install the sash lock and foam seals to prevent air leakage and provide security.



**Figure 3:** The Vissani VAW06R1AWTFR unit properly installed in a window, with side panels extended to fill the gap. The power cord is visible extending downwards.



**Figure 4:** A view of the Vissani VAW06R1AWTFR unit showing the accordion-style side panels extended, ready for installation into a window frame.

## OPERATING INSTRUCTIONS

Your Vissani air conditioner can be operated using the control panel on the unit or the included remote control.

### Control Panel Functions:

- **ON/OFF Button:** Press to turn the unit on or off.
- **MODE Button:** Cycles through operating modes: Auto, Cool, Dry (Dehumidify), Fan.
- **FAN Button:** Adjusts fan speed (Low, Med, High) in Fan mode. In Cool or Auto mode, it adjusts fan speed for cooling.
- **Temperature Up/Down Arrows:** Adjusts the desired temperature setting.
- **ECO Mode:** Activates energy-saving operation. The fan will turn off when the compressor cycles off and will cycle on periodically to check room temperature.
- **TIMER Button:** Sets a delay start or delay stop time (up to 24 hours).
- **SLEEP Button:** Activates sleep mode, which gradually increases the set temperature over several hours for energy efficiency and comfort during sleep.
- **FILTER Button:** The filter clean warning light will illuminate after approximately 250 hours of operation. Press this button after cleaning the filter to reset the timer.

### Remote Control Functions:





**Figure 5:** The remote control for the Vissani VAW06R1AWTFR air conditioner. It features buttons for power, mode, fan speed, temperature adjustment, timer, sleep, ECO, and I Sense functions.

The remote control duplicates most functions of the control panel and adds the "I Sense" feature.

- **I SENSE Button:** When activated, the remote control acts as a thermostat, sensing the temperature at its location and adjusting the air conditioner's operation accordingly. This provides more precise temperature control in your immediate vicinity.
- **C/F Button:** Toggles the temperature display between Celsius and Fahrenheit.
- **LED Display Button:** Turns the LED display on the unit on or off.

## MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your air conditioner.

## Cleaning the Air Filter:

1. **Turn Off and Unplug:** Always turn off the unit and unplug it from the power outlet before cleaning.
2. **Remove Filter:** Open the front grille and carefully slide out the air filter.
3. **Clean Filter:** Wash the filter with warm, soapy water. Rinse thoroughly. For heavy dust, a vacuum cleaner can be used first.
4. **Dry Filter:** Allow the filter to air dry completely before reinserting. Do not expose to direct sunlight or heat.
5. **Reinstall Filter:** Slide the dry filter back into its position and close the front grille.
6. **Reset Filter Light:** Press the "FILTER" button on the control panel or remote to reset the filter clean warning light.

*Recommendation:* Clean the air filter every two weeks or more frequently if the unit is used in a dusty environment.

## Cleaning the Unit Casing:

- Wipe the casing with a soft, damp cloth.
- Do not use harsh chemicals, abrasives, or solvents, as these can damage the surface.

## Winter Storage:


- If storing the unit for an extended period, clean the air filter and ensure the unit is dry.
- Store the unit in an upright position in a dry, cool place.

## TROUBLESHOOTING

Before contacting customer service, please refer to the following troubleshooting guide for common issues.

Problem	Possible Cause	Solution
Unit does not turn on.	No power; power cord unplugged; circuit breaker tripped; unit is off.	Ensure unit is plugged in; check circuit breaker; press ON/OFF button.
Unit is not cooling effectively.	Dirty air filter; blocked air intake/outlet; room too large; windows/doors open; temperature setting too high.	Clean air filter; ensure clear airflow; close windows/doors; lower temperature setting.
Water dripping inside.	Unit not tilted properly; drain hole blocked.	Ensure unit is slightly tilted outwards; clear any blockage from the drain hole.
Remote control not working.	Batteries dead or incorrectly inserted; remote out of range; obstruction between remote and unit.	Replace batteries; ensure correct polarity; operate remote within 20 feet of unit; remove obstructions.
Filter Clean light is on.	Air filter needs cleaning.	Clean the air filter and press the FILTER button to reset.

SPECIFICATIONS



**Figure 6:** The Vissani VAW06R1AWTFR unit shown with its approximate dimensions: 15.99 inches width, 12.05 inches height, and 13.19 inches depth. The remote control is also pictured.

Feature	Detail
Model Number	VAW06R1AWTFR
Cooling Capacity	6,000 BTU
Coverage Area	Up to 250 sq. ft.
Voltage	115V, 60Hz
Wattage	540 watts
Noise Level	53 Decibels
Product Dimensions (W x D x H)	15.99" x 13.19" x 12.05"
Item Weight	67.1 pounds
Refrigerant	R32 (typical for modern ACs, assuming based on general knowledge as not specified)
Included Components	Remote Control, Window Installation Kit












## WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided at the time of purchase or contact Vissani customer service directly. As this product is listed as "Renewed" by Amazon Renewed, specific warranty terms may vary. Please consult your purchase details for applicable warranty coverage.

For technical assistance or to inquire about replacement parts, please visit the official Vissani website or contact their support line.

### Related Documents - VAW06R1AWTFR

 <p><b>Warranty</b></p> <p><b>VISSANI LIMITED WARRANTY</b></p> <p>This warranty is provided by the manufacturer, Vissani, for the original purchaser of the product. It covers the product against defects in materials and workmanship for a period of two (2) years from the date of purchase. The warranty is limited to the repair or replacement of the defective part or the replacement of the entire unit, at the discretion of Vissani. This warranty does not cover damage caused by misuse, neglect, or accidents, or damage caused by unauthorized repairs or modifications. For more details, please refer to the full warranty document.</p>	<p><a href="#">VISSANI Window Air Conditioner Limited Warranty</a></p> <p>Details the limited warranty for VISSANI window air conditioners, covering two years from the original purchase date. Outlines responsibilities for both VISSANI and the consumer, including exclusions and service procedures.</p>
 <p><b>VISSANI.</b></p> <p><b>USE AND CARE GUIDE</b></p> <p><b>WINDOW TYPE ROOM AIR CONDITIONER</b></p> <p></p> <p>Model: VAW06R1AWTFR Capacity: 6,000 BTU/h Voltage: 115V-60Hz Power: 1400W</p>	<p><a href="#">Vissani Window Air Conditioner Use and Care Guide</a></p> <p>Comprehensive guide for Vissani window type room air conditioners, covering safe installation, operation, maintenance, and troubleshooting. Includes model numbers VAWA10V4HWT, VAWA12V4HWT, VAWA14V4HWT.</p>
 <p><b>VISSANI.</b></p> <p><b>USE AND CARE GUIDE</b></p> <p><b>AIR CONDITIONER</b></p> <p></p> <p>Model: VW5024 Capacity: 5000 BTU/h Voltage: 115V-60Hz Power: 1400W</p>	<p><a href="#">Vissani Air Conditioner Use and Care Guide VW5024</a></p> <p>This comprehensive guide provides essential information for Vissani window air conditioner model VW5024, covering safety precautions, installation steps, operating instructions, maintenance procedures, and troubleshooting tips. Ensure optimal performance and longevity of your Vissani air conditioner.</p>
 <p><b>VISSANI.</b></p> <p><b>USE AND CARE GUIDE</b></p> <p><b>WINDOW AIR CONDITIONER</b></p> <p></p> <p>Model: VWA05 Capacity: 5000 BTU/h Voltage: 115V-60Hz Power: 1400W</p>	<p><a href="#">Vissani VWA05 Window Air Conditioner Use and Care Guide</a></p> <p>Comprehensive guide for the Vissani VWA05 Window Air Conditioner, covering installation, operation, care, cleaning, and troubleshooting. Learn how to properly set up, use, and maintain your air conditioner for optimal performance and longevity.</p>

<div data-bbox="124 118 304 347"><div>VISSANI</div><div>USE AND CARE GUIDE</div><div>WINDOW AIR CONDITIONER</div><div></div><div>Read this manual carefully before using the unit. It contains important information about the unit's operation, safety, and maintenance. Keep this manual in a safe place for future reference. © 2010 Vissani Corporation</div></div>	<div data-bbox="341 181 1155 212"><a href="#">Vissani Window Air Conditioner Use and Care Guide (VWA06, VWA10)</a></div> <div data-bbox="341 224 1343 293">Comprehensive guide for Vissani VWA06 and VWA10 window air conditioners, covering installation, operation, care, and troubleshooting.</div>
<div data-bbox="124 425 304 654"><div>VISSANI</div><div>USE AND CARE GUIDE</div><div>WINDOW ROOM AIR CONDITIONER</div><div></div><div>Read this manual carefully before using the unit. It contains important information about the unit's operation, safety, and maintenance. Keep this manual in a safe place for future reference. © 2010 Vissani Corporation</div></div>	<div data-bbox="341 492 1018 524"><a href="#">Vissani Window Room Air Conditioner Use and Care Guide</a></div> <div data-bbox="341 533 1468 602">Comprehensive use and care guide for Vissani window room air conditioners, including installation, operation, safety, and troubleshooting tips for models VAW05R1AWT and VAW06R1AWT.</div>