Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HolaiNail B0FPWQ9GNY

HolaiNail L-Shaped Rotating Manicure Table with LED Light User Manual

Model: B0FPWQ9GNY | Brand: HolaiNail

Important Safety Information

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

- Ensure all parts are present and undamaged before assembly.
- Assemble on a soft, clean surface to prevent scratches.
- Do not overtighten screws during assembly.
- Keep small parts away from children.
- Only use the product for its intended purpose.
- Disconnect the LED light power supply before cleaning or maintenance.

Product Overview

The HolaiNail L-Shaped Rotating Manicure Table is a versatile piece of salon furniture designed for nail technicians. It features a rotating desktop, ample storage, and integrated LED lighting.



Image: The HolaiNail L-Shaped Rotating Manicure Table, showcasing its L-shaped configuration, integrated LED lighting, and storage compartments. The table is white and set in a modern salon environment.

Key Features:

- **Convertible L-Shaped Layout:** Can be configured as L-shaped, extended, or overlapped.
- **Spacious Desktop:** A wide 53.1-inch worktop provides ample space for nail essentials.
- **Integrated Storage:** Includes a drawer, cabinets, and a 3-tier side shelf.
- **Modern LED Light Design:** Adjustable colors and lighting modes with remote control.
- **Durable & Mobile:** Constructed from MDF with a reinforced metal turntable connector and four casters (two lockable).

Package Contents

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Main Desktop Panel
- Storage Cabinet Unit
- Side Shelf Unit with Casters
- Metal Turntable Connector
- LED Light Strip with Remote Control
- Assembly Hardware (screws, dowels, cam locks, etc.)
- Instruction Manual

Setup and Assembly

Assembly typically requires two people. Follow the numbered steps carefully. All parts are labeled for easy identification.

Tools Required (Not Included):

- Phillips Head Screwdriver
- Hammer (optional, for dowels)

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent damage. Identify each part using the provided labels.
2. **Assemble the Storage Cabinet Unit:** Follow the diagrams to connect the side panels, bottom, and top panels of the main storage cabinet using the provided hardware. Ensure all connections are secure.
3. **Install Drawer Slides and Drawer:** Attach the drawer slides to the cabinet and assemble the drawer. Insert the drawer into the slides.
4. **Attach Cabinet Doors:** Mount the cabinet doors using the hinges provided. Adjust for proper alignment.
5. **Assemble the Side Shelf Unit:** Connect the shelves to the side panels. Attach the four casters to the bottom of this unit. Ensure two of the casters are lockable and positioned correctly.



Image: A detailed view of one of the lockable caster wheels, highlighting its 360-degree rotation capability and the lock/unlock mechanism. This wheel is part of the side shelf unit.

6. **Connect the Main Desktop Panel:** Position the main desktop panel onto the storage cabinet unit. Secure it using the metal turntable connector, allowing for rotation.



Image: A diagram illustrating the 360-degree rotating mechanism that connects the main desktop to the storage cabinet, enabling flexible table configurations.

7. **Attach the Side Shelf Unit:** Slide the side shelf unit under the main desktop panel.
8. **Install LED Light Strip:** Adhere the LED light strip to the designated area within the cabinet or under the desktop, as per the instructions. Connect it to the power supply.



Image: The manicure table's storage compartments illuminated by the LED lights, showcasing organized nail polishes and tools. The clear acrylic panels allow light to pass through.

9. **Final Check:** Ensure all connections are tight and the table is stable.

Operating Instructions

Adjusting Table Configuration:

The manicure table offers three primary configurations: L-shaped, Extended, and Overlapped. To change the configuration:

1. Unlock the casters on the side shelf unit if they are locked.
2. Gently rotate the main desktop panel to the desired position. The metal turntable connector allows for smooth 360-degree rotation.
3. Adjust the side shelf unit as needed to support the main desktop in the chosen configuration.
4. Lock the casters on the side shelf unit to secure the table in place.




Image: A visual guide demonstrating the three possible configurations of the manicure table: L-shaped, extended, and overlapped, highlighting its adaptability.

Using the LED Light:

The LED light strip is controlled by a wireless remote.

- **Power On/Off:** Press the power button on the remote.
- **Color Selection:** Use the color buttons to choose from various static colors.
- **Mode Adjustment:** Select different lighting modes (e.g., flash, fade, strobe) using the mode buttons.
- **Brightness Control:** Adjust the light intensity using the brightness up/down buttons.
- **Speed Control:** For dynamic modes, adjust the speed of the effect.



Image: The manicure table with its LED lights set to blue, accompanied by a remote control showing buttons for color, mode, brightness, and speed adjustments. The remote has a range of up to 5 meters.

Maintenance and Care

Proper maintenance ensures the longevity and appearance of your manicure table.

- **Cleaning:** Wipe surfaces with a damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Spills:** Clean up spills immediately to prevent staining.
- **LED Lights:** Ensure the LED light strip is disconnected from power before cleaning. Do not immerse in water.
- **Hardware:** Periodically check and tighten all screws and connections to maintain stability.
- **Casters:** Keep casters free of debris to ensure smooth movement.

Troubleshooting

Problem	Possible Cause	Solution
Table is unstable/wobbly.	Loose hardware; uneven floor; casters not locked.	Tighten all assembly screws. Ensure the table is on a level surface. Lock the casters on the side shelf unit.
LED light not working.	Power not connected; remote battery dead; faulty light strip.	Check power connection. Replace remote battery. Contact customer support if the issue persists.
Desktop rotation is stiff.	Debris in turntable mechanism; overtightened connection.	Clean the turntable area. Ensure the turntable connector is not overtightened during assembly.
Casters not rolling smoothly.	Debris in wheels; casters locked.	Clean any hair or debris from the caster wheels. Unlock the casters.

Specifications

- **Brand:** HolaiNail
- **Model:** B0FPWQ9GNY
- **Material:** Engineered Wood (MDF)
- **Color:** White
- **Product Dimensions (L-shaped):** Approximately 53 inches (W) x 45 inches (D) x 32.3 inches (H)
- **Product Dimensions (Extended):** Approximately 53 inches (W) x 17.7 inches (D) x 32.3 inches (H)
- **Item Weight:** 115 pounds
- **Number of Drawers:** 1
- **Number of Shelves:** 3 (on side unit)
- **Special Feature:** LED Light Included, 360° Rotating Desktop, Lockable Casters
- **Product Care Instructions:** Wipe with Damp Cloth



Image: A technical diagram illustrating the dimensions of the HolaiNail manicure table in both its L-shaped and extended configurations, with measurements in inches.

Warranty and Support

For warranty information or customer support, please refer to the contact details provided with your purchase documentation or visit the official HolaiNail website. Please have your model number (B0FPWQ9GNY) ready when contacting support.

Product Care Instructions: As per manufacturer guidelines, wipe with a damp cloth for cleaning.

© 2025 HolaiNail. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FPWQ9GNY

More documents and user manuals: **https://manuals.plus/**