BSNAW XL-638A

BSNAW Cordless Stick Vacuum Cleaner XL-638A User Manual

Model: XL-638A | Brand: BSNAW

1. Introduction

The BSNAW Cordless Stick Vacuum Cleaner XL-638A is designed for efficient and versatile cleaning across various surfaces. Featuring a powerful 35000Pa suction, a detachable battery for extended runtime, and an advanced filtration system, this vacuum is suitable for daily cleaning tasks including pet hair, dust, and debris on hard floors and carpets. Its lightweight design and multiple attachments enhance usability and adaptability for different cleaning needs.



Figure 1: Overview of the BSNAW Cordless Stick Vacuum Cleaner's powerful suction capabilities.

2. What's in the Box

Carefully unpack all components and ensure everything is present before assembly. The package includes:

- Main Motor (Handheld Vacuum)
- Retractable Metal Tube
- Motorized Brush (Floor Head)
- 2-in-1 Brush
- Gap Head (Crevice Nozzle)
- Battery Pack (1 Lithium Ion battery included)
- HEPA Filter (additional filter may be included)
- Adapter (Charger)
- Wall Mount Plate
- Hair Cleaning Tool
- Manual Instruction




Figure 2: All components included in the BSNAW Cordless Stick Vacuum Cleaner package.

Unboxing and Initial Assembly Video

Your browser does not support the video tag. Please update your browser to view this content.

Video 1: Demonstrates the unboxing and initial assembly of the vacuum cleaner and its accessories.

3. Setup

3.1 Assembly

1. Attach the Retractable Metal Tube to the Main Motor unit.
2. Connect the Motorized Brush (floor head) to the other end of the Retractable Metal Tube.
3. For handheld use, attach the 2-in-1 Brush or Gap Head directly to the Main Motor unit.

3.2 Charging the Battery

The vacuum cleaner is powered by a detachable Lithium Ion battery. It is recommended to fully charge the battery before first use and subsequent uses to ensure optimal performance.

- Connect the Adapter to the charging port on the battery or directly to the Main Motor if the battery is attached.
- Plug the Adapter into a power outlet.
- The LED display will indicate charging status. A flashing white light typically indicates charging, and a solid white light indicates a full charge.



Figure 3: Detachable battery pack and charging details.

4. Operating Instructions

4.1 Power On/Off and Suction Modes

Press the power button on the Main Motor to turn the vacuum on or off. The vacuum features multiple suction modes (e.g., Standard and Max) to adapt to different cleaning needs. Use the mode selection button to switch between these settings. The LED display will show the current mode and battery level.



Figure 4: The vacuum's LED display for battery and mode information.

4.2 Cleaning with the Motorized Brush

The motorized brush is ideal for cleaning hard floors and carpets. It features a V-shaped roller brush designed to prevent tangling of hair and an LED light to illuminate dark areas, ensuring no dust is missed.



Figure 5: Motorized brush with flexible swivel and LED lights for enhanced visibility.

4.3 Handheld Versatility

Easily convert the stick vacuum into a handheld unit by detaching the metal tube and attaching the desired accessory directly to the main motor. This is perfect for cleaning:

- Stairs and windowsills
- Sofas and beds
- Desks and curtains
- Car interiors and RVs



Figure 6: Demonstrating the vacuum's versatility with different attachments.

Cleaning Demonstrations

Your browser does not support the video tag. Please update your browser to view this content.

Video 2: Short demonstration of the vacuum's cleaning capabilities on various surfaces.

Your browser does not support the video tag. Please update your browser to view this content.

Video 3: Another short demonstration showing the vacuum cleaning different areas.

Your browser does not support the video tag. Please update your browser to view this content.

Video 4: A comprehensive demonstration of the vacuum's powerful suction and versatility for home cleaning.

Your browser does not support the video tag. Please update your browser to view this content.

Video 5: Vertical video showcasing the vacuum's effectiveness in various cleaning scenarios.

5. Maintenance

Regular maintenance ensures the longevity and optimal performance of your BSNAW Cordless Stick Vacuum Cleaner.

5.1 Dust Disposal

The vacuum features a one-touch dust disposal system for hygienic emptying of the dustbin.

- Locate the dustbin release button on the main motor unit.
- Press the button to open the dustbin flap and empty contents into a trash receptacle.



Figure 7: One-touch dust disposal and convenient filter cleaning.

5.2 Filter Cleaning

The advanced filtration system includes a HEPA filter, stainless steel filter, and sponge filter. These should be cleaned regularly to maintain suction power and air quality.

1. Rotate the dustbin to remove it from the main motor.
2. Remove the filter components (HEPA filter, stainless steel filter, sponge filter) from the dustbin.
3. Tap the filters to remove loose dust and debris.
4. Rinse the HEPA and mesh shell under running water.
5. Allow all filter components to dry completely for at least 24 hours before reassembling.
6. Install the dry filter components back into the dustbin and reattach the dustbin to the main motor.

Note: Never immerse the main motor or dustbin in water.

5.3 Roller Brush Cleaning

Periodically check and clean the roller brush to remove tangled hair or debris.

1. Ensure the vacuum is powered off and disconnected from any charging source.
2. Open the side cover of the motorized brush head.
3. Carefully remove the inside roller brush.
4. Use the provided hair cleaning tool or scissors to remove any tangled hair or fibers.
5. Replace the clean roller brush, ensuring it clicks into place.
6. Close the side cover.

Note: Never immerse the Motorized Brush in water.




Figure 8: Step-by-step guide for filter and roller brush maintenance.

6. Troubleshooting

If you encounter issues with your BSNAW Cordless Stick Vacuum Cleaner, refer to the following common solutions:

- **No Power/Not Turning On:** Ensure the battery is fully charged. Check if the battery is securely attached to the main motor.
- **Reduced Suction Power:** Empty the dustbin. Clean all filters (HEPA, stainless steel, sponge) and ensure they are completely dry before reinstallation. Check the roller brush for any blockages or tangled hair. Inspect the metal tube and attachments for obstructions.
- **Short Battery Runtime:** Ensure the battery is fully charged. Operating in Max mode will consume battery faster than Standard mode. Battery performance may decrease over time with extensive use.
- **Roller Brush Not Spinning:** Check for tangled hair or debris obstructing the brush. Ensure the brush head is properly attached and the side cover is closed.

For persistent issues not covered here, please contact customer support.

7. Specifications

Feature	Specification
Brand	BSNAW
Model Name	XL-638A
Special Feature	Cordless, Lightweight, Power Suction, Headlight, HEPA Filtration, Adjustable Telescoping Tube, Pet Hair, Cyclonic, Washable Filter
Filter Type	HEPA Filter
Is Cordless?	Yes
Capacity	1 Kilogram (Dustbin)

Recommended Uses	Car, Carpets, Floors, Room, Sofa
Form Factor	Stick
Product Dimensions	43.31"L x 9.45"W x 9.06"H
Item Weight	6.93 pounds
Batteries	1 Lithium Ion battery required (included)
Surface Recommendation	All floors
Power Source	Battery Powered

8. Warranty and Support

BSNAW prioritizes customer satisfaction and offers a lifetime customer service guarantee and exchange service. Enjoy a long-term warranty to maximize your satisfaction. For any issues with the vacuum cleaner, we are here to assist you.

Optional Protection Plans

Additional protection plans are available for purchase to extend coverage:

- **2-Year Protection Plan:** Provides coverage for 24 months.
- **3-Year Protection Plan:** Provides coverage for 36 months.
- **Complete Protect:** A monthly plan covering all eligible past and future purchases.

For detailed information on warranty claims or to purchase an extended protection plan, please refer to the product's purchase platform or contact BSNAW customer service directly.

© 2026 BSNAW. All rights reserved.