

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [OMOTON](#) /

› [OMOTON Illuminated Keyboard Instruction Manual](#)

OMOTON Illuminated Keyboard

OMOTON Illuminated Keyboard User Manual

Model: Illuminated Keyboard

INTRODUCTION

This manual provides instructions for the OMOTON Illuminated Keyboard. Designed with extra-large fonts, this keyboard offers enhanced visibility, making it suitable for users who benefit from clearer visual experiences, including seniors, students, and office workers. It aims to reduce eye fatigue and typing errors. The keyboard features a wired 2-in-1 USB-A/C interface for broad compatibility and includes multimedia keys for efficient control of various functions.

PRODUCT FEATURES

- **Large Font Keys:** Keys feature oversized characters for improved readability, minimizing typing errors.
- **Multimedia Functionality:** Dedicated multimedia keys provide quick access to functions such as music, video playback, and volume control.
- **Dual USB A/C Compatibility:** Equipped with a 2-in-1 USB-A/C cable, allowing connection to a wide range of devices.
- **Ergonomic Design:** Features a user-friendly, ergonomic design with an adjustable kickstand for comfortable typing positions, reducing strain during extended use.
- **Windows Compatibility:** Specifically designed for seamless operation with Windows operating systems.

SETUP

The OMOTON Illuminated Keyboard is designed for simple plug-and-play setup.

1. **Connect the Keyboard:** Locate an available USB-A or USB-C port on your computer.
2. **Plug In:** Connect the keyboard's 2-in-1 USB cable to the chosen port. The keyboard will be automatically recognized by your operating system (Windows).
3. **Verify Connection:** Once connected, the keyboard should be ready for use. The backlight will illuminate.

Einfache Kabelgebundene Verbindung



Image: The keyboard features a versatile 2-in-1 USB-A/C cable for easy connection to various devices, including laptops and desktop PCs.

OPERATING INSTRUCTIONS

Backlight Control

The keyboard features an adjustable white backlight. Use the following key combinations to control it:



Image: Visual guide for backlight control functions.

Fn + Print Screen (Druck): Toggles the backlight on or off.

Fn + Scroll Lock (Rollen): Switches between constant illumination mode and 'breathing' mode.

In Constant Illumination Mode:

- **Fn + Up Arrow:** Increases backlight brightness.
- **Fn + Down Arrow:** Decreases backlight brightness.

In 'Breathing' Mode:

- **Fn + Left Arrow:** Adjusts breathing frequency (slower).
- **Fn + Right Arrow:** Adjusts breathing frequency (faster).

Multimedia Keys

The keyboard includes dedicated multimedia keys (F1-F12) that provide quick access to various functions when pressed in combination with the **Fn** key.

Praktische Multimedia-Tasten

Multimedia-Tasten werden für Windows verwendet
(z. B. Lautstärkeregelung, Arbeitsplatz,
Taschenrechner usw.).



Image: The multimedia keys (F1-F12) offer convenient shortcuts for common tasks.

- **Fn + F1-F12:** Access functions such as volume control, media playback, email, web browser, and calculator. Refer to the icons on the F-keys for specific functions.

MAINTENANCE

To ensure the longevity and optimal performance of your OMOTON Illuminated Keyboard, follow these maintenance guidelines:

- **Cleaning:** Regularly clean the keyboard with a soft, dry, lint-free cloth. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid harsh chemicals or abrasive materials.
- **Dust Removal:** Use compressed air to remove dust and debris from between the keys.

- **Liquid Spills:** In case of a liquid spill, immediately disconnect the keyboard from your computer. Turn it upside down to drain any liquid and allow it to dry completely before reconnecting.
- **Storage:** Store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

If you encounter issues with your OMOTON Illuminated Keyboard, refer to the following common troubleshooting steps:

- **Keyboard Not Responding:**
 - Ensure the USB cable is securely plugged into both the keyboard and the computer.
 - Try connecting the keyboard to a different USB port on your computer.
 - Restart your computer.
 - If using a USB hub, try connecting the keyboard directly to the computer.
- **Backlight Not Working:**
 - Press **Fn + Print Screen** to ensure the backlight is not turned off.
 - Adjust brightness using **Fn + Up/Down Arrow** keys.
- **Keys Not Functioning Correctly:**
 - Check for any physical obstructions or debris under the keys.
 - Ensure your operating system drivers are up to date (though typically plug-and-play for keyboards).

SPECIFICATIONS

Brand	OMOTON
Compatible Devices	PC
Connectivity Technology	USB-A/C
Keyboard Description	Multimedia
Recommended Uses For Product	Everyday Use

WARRANTY AND SUPPORT

OMOTON products are designed for reliability and performance. For specific warranty details regarding your Illuminated Keyboard, please refer to the warranty card included with your purchase or visit the official OMOTON website.

If you require technical assistance or have questions not covered in this manual, please contact OMOTON customer support through their official channels. Contact information can typically be found on the product packaging or the brand's website.