

[Manuals.plus](#) /

› [LAUDLIFE](#) /

› LAUDLIFE FUSION 2-in-1 Gas Griddle & Grill Combo Instruction Manual

LAUDLIFE FUSION

LAUDLIFE FUSION 2-in-1 Gas Griddle & Grill Combo Instruction Manual

MODEL: FUSION (GF007BL00NBA-2)

1. Introduction

This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your LAUDLIFE FUSION 2-in-1 Gas Griddle & Grill Combo. Please read this manual thoroughly before using the appliance and retain it for future reference. This appliance is designed for outdoor use only.



Image 1.1: The LAUDLIFE FUSION 2-in-1 Gas Griddle & Grill Combo in operation, showcasing its dual cooking surfaces and side burner.

2. Safety Information

WARNING: Failure to follow these instructions could result in fire, explosion, or burn hazard, which could cause property damage, personal injury, or death.

- For outdoor use only. Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
- Do not store a spare LP cylinder under or near this appliance.
- Always ensure adequate ventilation. Never operate the appliance in an enclosed space.
- Keep children and pets away from the appliance during operation.
- Maintain a minimum clearance of 36 inches (91 cm) from the back and sides of the appliance to combustible materials.
- Perform a leak test on all gas connections before initial use and after any cylinder change.

- Do not attempt to repair or alter the appliance. Contact qualified service personnel for repairs.

3. Package Contents

Verify that all components are present and undamaged before proceeding with assembly:

- LAUDLIFE FUSION 2-in-1 Gas Griddle & Grill Combo Unit (main body, griddle plate, grill grates, side burner)
- Adapter Hose for LP Tank Connection
- Grease Pan
- Preparation Board
- Built-in Thermometer (pre-installed)
- User Manual (this document)
- Assembly Hardware Kit

4. Assembly Instructions

Assembly of the LAUDLIFE FUSION 2-in-1 Gas Griddle & Grill Combo is required. Please refer to the separate detailed assembly guide included with your product for step-by-step instructions. Ensure all parts are present and undamaged before beginning assembly. It is recommended to have two people for assembly.

5. Setup

5.1 Appliance Placement

Place the appliance on a level, stable, non-combustible surface in an outdoor area with good ventilation. Ensure the required clearances from combustible materials are maintained (refer to Section 2: Safety Information).

5.2 Propane (LP) Tank Connection

1. Ensure the LP tank valve is open.
2. Connect the regulator hose to the LP tank valve. Hand-tighten firmly. Do not use tools.
3. Open the LP tank valve slowly, allowing gas to flow into the hose.

5.3 Leak Testing

Perform a leak test before first use and after every LP tank change. Mix a solution of equal parts water and liquid dish soap. With the LP tank valve open and appliance control knobs OFF, apply the solution to all gas connections. Bubbles indicate a leak. If a leak is detected, immediately close the LP tank valve and tighten connections. Repeat the test. If the leak persists, do not use the appliance and contact customer support.

5.4 Initial Burn-Off / Seasoning

Before cooking, perform an initial burn-off to remove manufacturing oils and residues. Light all main burners to their highest setting for 10-15 minutes. For the griddle surface, apply a thin layer of high-smoke-point cooking oil (e.g., flaxseed, grapeseed) and heat until it smokes, then let it cool. Repeat this process 3-4 times to create a non-stick seasoned surface.

6. Operating Instructions

6.1 Lighting the Main Burners (Grill/Griddle)

1. Ensure the LP tank valve is open.
2. Push and turn a main burner control knob to the HIGH position.

3. The integrated piezo ignition should ignite the burner. If not, turn the knob to OFF and wait 5 minutes before attempting again.
4. Once lit, adjust the flame intensity using the 360° control knob.

6.2 Lighting the Side Burner

1. Ensure the LP tank valve is open.
2. Push and turn the side burner control knob to the HIGH position.
3. The integrated piezo ignition should ignite the burner. If not, turn the knob to OFF and wait 5 minutes before attempting again.
4. Once lit, adjust the flame intensity using the control knob.

6.3 Using the Griddle and Grill Surfaces

The LAUDLIFE FUSION offers a dual-zone cooking experience. The griddle side is ideal for flat-top cooking such as eggs, pancakes, bacon, and stir-fries. The grill side provides open-flame cooking for searing meats, vegetables, and other grilled items. Utilize the individual control knobs to set different temperatures for each cooking zone.



Image 6.1: The LAUDLIFE FUSION cooking various items on both the griddle and grill surfaces.

7. Maintenance and Cleaning

7.1 After Each Use

- Allow the appliance to cool completely.
- **Griddle Surface:** Scrape off food residue with a griddle scraper. Wipe clean with a paper towel. For stubborn residue, use warm soapy water and a non-abrasive pad, then re-season lightly with cooking oil.
- **Grill Grates:** Brush off food residue with a grill brush. For deeper cleaning, wash with warm soapy water.
- **Grease Tray:** Empty and clean the slide-out grease tray regularly to prevent grease fires.

7.2 Exterior Cleaning

Wipe exterior surfaces with a damp cloth and mild detergent. Avoid abrasive cleaners or pads that can scratch the finish. Ensure all surfaces are dry before storing.

7.3 Storage

When not in use, store the appliance in a dry, protected area. Disconnect the LP tank and store it outdoors in a well-ventilated area, away from direct sunlight or heat sources. Consider using a weather-resistant cover to protect the appliance from the elements.

8. Troubleshooting

Problem	Possible Cause	Solution
Burner does not light	No gas flow; clogged burner port; faulty igniter	Check LP tank connection and gas level; clean burner ports; check igniter electrode and wire.
Uneven heating	Clogged burner ports; low gas pressure	Clean burner ports; ensure LP tank is not low and regulator is functioning correctly.
Low flame, even on HIGH setting	Low gas in tank; regulator bypass activated	Replace or refill LP tank; reset regulator by turning off all knobs, closing tank valve, disconnecting and reconnecting regulator, then slowly opening tank valve.
Gas odor	Gas leak	Immediately turn off gas supply. Perform leak test (Section 5.3). If leak persists, do not use and contact customer support.

9. Specifications

Feature	Detail
Brand	LAUDLIFE
Model Name	FUSION
Item Model Number	GF007BL00NBA-2
Product Dimensions	22.44"D x 41.14"W x 18.7"H
Fuel Type	Gas (Propane)
Total Heating Power	50,000 BTU
Cooking Surface Area	702 Square Inches
Main Burner Count	5
Side Burner Count	1
Material	Cast Iron, Porcelain, Stainless Steel
Finish Type	Non-Stick (Enamel-coated)
Special Features	Built-In Thermometer, Heat-Resistant Handle, Heavy Duty, Rust Resistant, Weather Resistant
Assembly Required	Yes

Feature	Detail
Item Weight	91.8 pounds
Indoor/Outdoor Usage	Outdoor

10. Warranty and Support

The LAUDLIFE FUSION 2-in-1 Gas Griddle & Grill Combo is covered by a **10-year warranty**. For warranty claims, technical assistance, or replacement parts, please contact LAUDLIFE customer support. Refer to the contact information provided in your product packaging or on the official LAUDLIFE website. Please have your model number (FUSION / GF007BL00NBA-2) and purchase date available when contacting support.

Manufacturer: LAUDLIFE GRILLS

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question