

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [DOGLinsen](#) /

› [DOGLinsen Bark Collar with Remote \(Model: Bark Collar with Remote-PD 523-TIO-1\) User Manual](#)

DOGLinsen Bark Collar with Remote-PD 523-TIO-1

DOGLinsen Bark Collar with Remote (Model: Bark Collar with Remote-PD 523-TIO-1) User Manual

Your comprehensive guide to effective and humane dog training.

1. PRODUCT OVERVIEW

The DOGLinsen Bark Collar with Remote is a versatile training device designed to assist in correcting unwanted dog behaviors such as excessive barking, jumping, and other obedience issues. It features multiple training modes including beep, vibration, and static shock, along with an automatic bark detection mode. This collar is suitable for small, medium, and large dogs, offering adjustable settings to match your dog's needs.



Image 1.1: The DOGLinsen Bark Collar with Remote and its receiver unit.

2. WHAT'S INCLUDED

The package contains all necessary components for immediate use and training:

- Remote Control (1)
- Receiver (1)
- Collar Strap (1)
- Lanyard (1)
- USB Charging Cable (1)
- User Manual (1)
- Box (1)

- Metal Contact Points (4)
- Black Rubber Sleeves (4)
- Test Lamp (1)

Package Included



Image 2.1: All items included in the DOGLinsen Bark Collar package.

Video: What's included in the package of the Shock and Bark Collar?

Your browser does not support the video tag.

Video 2.1: This video demonstrates the unboxing and shows all components included in the DOGLinsen Bark Collar package.

3. SAFETY INFORMATION

- Do not leave the collar on your dog for more than 12 hours per day.
- Regularly check your dog's neck for signs of irritation or sores. If found, discontinue use until the skin heals.
- Ensure the collar fits snugly but not too tightly. You should be able to fit two fingers comfortably under the collar.
- The static shock feature should be used responsibly and only after other training methods have been attempted.
- Keep the remote control away from water, as it is not waterproof. The receiver is IP67 waterproof.
- This device is intended for dogs weighing between 10 to 110 lbs and with neck sizes from 8 to 27 inches.

4. SETUP

4.1 Charging the Device

Before first use, fully charge both the remote control and the receiver. Use the provided 2-in-1 USB-C charging cable.

- Connect the charging cable to the charging ports on both the remote and receiver.
- Plug the USB end into a compatible power source (e.g., USB wall adapter, computer, power bank).
- The indicator lights will show charging status (refer to the manual for specific light indications).
- A full charge typically provides up to 30 days of use for the remote and 90 days for the receiver in auto mode.

Long Battery Life



Image 4.1: Charging the remote and receiver, highlighting the long battery life.

4.2 Attaching the Collar

Proper fit is crucial for comfort and effectiveness:

- Thread the collar strap through the receiver unit.
- Place the collar around your dog's neck, ensuring the contact points touch the skin.
- Adjust the strap so it is snug but not tight. You should be able to slide two fingers between the collar and your

dog's neck.

- Trim any excess strap length if necessary.



Image 4.2: The adjustable collar strap fits various dog sizes from 10 to 110 lbs.

4.3 Pairing the Remote Control with the Receiver

To ensure the remote and receiver communicate correctly, they must be paired:

1. Ensure both the remote and receiver are charged.

2. Turn on the remote control.
3. Press and hold the power switch button on the receiver until the indicator light starts flashing.
4. While the receiver's light is flashing, press the vibration button on the remote. The receiver should vibrate, indicating it received the signal.
5. Immediately after, press the tone button on the remote. The receiver should beep, confirming successful pairing.

Video: Here's how to Pair the Remote Control with the Receiver

Your browser does not support the video tag.

Video 4.3: This video provides a step-by-step guide on how to pair the remote control with the receiver unit.

5. OPERATING INSTRUCTIONS

5.1 Understanding the Modes

The DOGLinsen collar offers three primary operational modes:

- **Bark Control Mode:** The receiver automatically detects and responds to your dog's barking with corrective stimuli (beep, vibration, or static shock) based on sensitivity settings.
- **Dog Training Mode:** You manually control the stimuli (beep, vibration, static shock) via the remote control to correct specific behaviors.
- **All-Inclusive Mode:** Combines both Bark Control and Dog Training modes, allowing for both automatic bark correction and manual training.

3 Collar Modes

Bark Control
Mode

Dog Training
Mode

All Mode



Image 5.1: The three distinct operational modes of the DOGLinsen collar.

5.2 Adjusting Sensitivity (Auto Mode)

The automatic bark control mode has 5 levels of sensitivity. A higher sensitivity level means the device is more easily triggered by barking.

1. Ensure the receiver is in Auto Mode (see section 5.3).
2. Press the power button on the receiver three times in a row to cycle through sensitivity levels.

3. Each beep indicates a sensitivity level: 1 beep for level 1 (lowest), up to 5 beeps for level 5 (highest).
4. Choose the appropriate sensitivity for your dog's barking habits.

Video: Here's How to Adjust the Sensitivity of the Auto Mode

Your browser does not support the video tag.

Video 5.2: This video demonstrates how to adjust the sensitivity levels for the automatic bark control mode.

5.3 Turning Auto Mode On or Off

You can activate or deactivate the automatic bark control mode as needed:

1. Ensure the remote and receiver are paired.
2. Press and hold the power button on the remote for approximately 3 seconds.
3. If you hear a single beep from the receiver, Auto Mode is turned ON.
4. If you hear two beeps from the receiver, Auto Mode is turned OFF.

Video: How to turn Auto Mode On or Off?

Your browser does not support the video tag.

Video 5.3: This video illustrates the process of enabling and disabling the automatic bark detection mode on the receiver.

5.4 Testing Receiver Power/Battery Level

You can check the receiver's battery level at any time:

1. Press the power button on the receiver twice in a row.
2. The number of beeps indicates the battery level:
 - 5 Beeps: Above 80%
 - 4 Beeps: Above 60%
 - 3 Beeps: Above 40%
 - 2 Beeps: Above 20%
 - 1 Beep: Below 20%

Video: Here's how to Test the Power of the Receiver

Your browser does not support the video tag.

Video 5.4: This video demonstrates how to check the battery level of the receiver unit.


5.5 Remote Control Range

The remote control offers an extended range of up to 2800 feet, allowing for flexible training indoors and outdoors.

Adjustable for All Size Dogs



Quick Release



Reflective



10 lbs



110 lbs

Image 5.5: The remote control provides a wide operational range for training.

5.6 Waterproof Feature

The receiver unit is IP67 waterproof, making it suitable for use in various weather conditions and even during swimming. The remote control is not waterproof and should be kept dry.

100% IP67 Waterproof

Waterproof



Dust-proof



IP67



Seaside



Rainy



Swimming

Image 5.6: The receiver's IP67 waterproof rating allows for use in wet conditions.

6. MAINTENANCE

- **Cleaning:** Hand wash the collar strap regularly with mild soap and water. Wipe the receiver and remote with a damp cloth. Ensure the charging ports are dry before charging.
- **Contact Points:** Periodically check the metal contact points for corrosion or buildup. Clean them gently if necessary.

- **Storage:** Store the device in a cool, dry place when not in use.
- **Battery Care:** For optimal battery life, avoid fully discharging the device frequently. Charge it when the battery level is low.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Collar not responding to remote	Not paired, low battery, out of range	Re-pair the devices (Section 4.3), charge both units, ensure within 2800ft range.
Auto bark mode not activating	Auto mode off, low sensitivity, improper fit	Turn on auto mode (Section 5.3), increase sensitivity (Section 5.2), adjust collar fit.
Stimulation seems too weak/strong	Incorrect intensity level, improper contact	Adjust vibration/static shock levels on remote, ensure contact points touch skin.
Battery drains quickly	Frequent use, old battery	Reduce usage frequency, ensure full charge, contact support if battery life significantly degrades.
Skin irritation on dog's neck	Collar too tight, worn too long, allergic reaction	Loosen collar, reduce wear time, clean neck and collar, consult a vet if irritation persists.



8. SPECIFICATIONS

Feature	Detail
Brand	DOGLinsen
Model Name	Bark Collar with Remote-PD 523-TIO-1
ASIN	B0FPXB2F7L
Target Audience	Dogs (All Breed Sizes)
Neck Size Range	8 to 27 inches
Weight Range	10 to 110 lbs
Material	Nylon, Polyester
Waterproof Rating (Receiver)	IP67
Remote Range	Up to 2800 feet
Battery Type	Lithium Polymer (2 required, included)
Charging Cable	USB Type-C (2-in-1)
Training Modes	Beep, Vibration (1-100 levels), Static Shock (1-100 levels), Auto Bark Mode (5 sensitivity levels)
Product Care Instructions	Hand Wash

9. WARRANTY AND SUPPORT

- Warranty:** This product comes with a 2-Year Manufacturer Warranty. Please retain your proof of purchase for warranty claims.
- Customer Support:** For any questions, troubleshooting assistance, or warranty inquiries, please contact DOGLinsen customer service. Refer to the contact information provided in the product packaging or on the official DOGLinsen website.

Related Documents - Bark Collar with Remote-PD 523-TIO-1

	<p>DOGLinsen PD 523-TIO Dog Training Collar User Guide Instructions & FAQ</p> <p>Comprehensive user guide for the DOGLinsen PD 523-TIO Dog Training Collar. Learn about safety, operation, automatic anti-bark function, pairing, maintenance, and troubleshooting. Includes specifications and warranty information.</p>
	<p>PetJoy PD 523-TIO Dog Training Collar User Guide</p> <p>Comprehensive user guide for the PetJoy PD 523-TIO Dog Training Collar, covering setup, operation, safety instructions, features, troubleshooting, and warranty information.</p>
	<p>PaiPaitek PD 526-TIO Dog Training Collar User Guide</p> <p>Comprehensive user guide for the PaiPaitek PD 526-TIO dog training collar, covering setup, operation, safety instructions, auto anti-barking function, maintenance, specifications, pairing, testing, and troubleshooting.</p>
	<p>2-in-1 Remote Dog Training & Auto Anti-Bark Collar Operating and Training Guide</p> <p>This guide provides comprehensive instructions and tips for using the 2-in-1 Remote Dog Training and Auto Anti-Bark Collar. Learn about its features, operation, safety precautions, and effective training methods for your dog.</p>
	<p>PetJoy PD 525-TIO Dog Training Collar User Guide</p> <p>Comprehensive user guide for the PetJoy PD 525-TIO Dog Training Collar, covering setup, operation, safety instructions, maintenance, and troubleshooting for effective dog training.</p>

