

[Manuals.plus](#) /

› [Bushnell Golf](#) /

› Bushnell Golf A1-Slope Laser Rangefinder Instruction Manual

Bushnell Golf A1-Slope (Model 202510S)

Bushnell Golf A1-Slope Laser Rangefinder Instruction Manual

Model: A1-Slope (202510S)

Brand: Bushnell Golf

1. INTRODUCTION

The Bushnell Golf A1-Slope is an ultra-compact laser rangefinder designed for golf. It integrates patented Slope Technology for compensated distances, PinSeeker with Jolt for target acquisition, and a BITE magnetic mount for convenient attachment. The device features a rechargeable battery and is built with IPX6 water resistance.



Image 1.1: The Bushnell Golf A1-Slope Laser Rangefinder.

2. WHAT'S INCLUDED

The A1-Slope package includes the following items:

- Bushnell Golf A1-Slope Laser Rangefinder
- Magnetic Protective Skin (pre-installed or separate)
- Premium Carry Case
- USB Charging Cable
- Cleaning Cloth
- Quick Start Guide
- Vice Drive Golf Balls (1 Dozen, Blue)
- Signature Series Magnetic Golf Towel



WHAT'S INCLUDED WITH THE A1-SLOPE

Image 2.1: All items included with the A1-Slope Laser Rangefinder bundle.



BITE MAGNETIC SKIN

A1-SLOPE

Image 2.2: The Bushnell Golf A1-Slope Rangefinder and accompanying accessories.

3. SETUP

3.1 Battery Charging

The A1-Slope features an integrated rechargeable Lithium-Ion battery. Before first use, fully charge the device. A full charge can provide power for over 50 rounds of golf.

1. Locate the charging port on the device.
2. Connect the provided USB charging cable to the rangefinder and a compatible USB power source.
3. The charging indicator will show the charging status. Once fully charged, disconnect the cable.

RECHARGEABLE INTEGRATED BATTERY



LASTS 50+ ROUNDS ON A SINGLE CHARGE

Image 3.1: The A1-Slope Rangefinder being charged via its USB port.

3.2 Attaching the Magnetic Skin (if not pre-installed)

The A1-Slope comes with a magnetic protective skin that enables the BITE magnetic mount feature.

1. Carefully slide the protective skin onto the rangefinder, ensuring it fits snugly.
2. Verify that the magnetic plate on the side of the rangefinder is exposed and functional.




Image 3.2: The BITE Magnetic Skin feature, allowing the rangefinder to attach to metal surfaces.

4. OPERATING INSTRUCTIONS

The A1-Slope is designed for ease of use. Familiarize yourself with its features for optimal performance on the golf course.



A1-SLOPE FEATURES

Image 4.1: Overview of the A1-Slope's key features.

4.1 Power On/Off and Ranging

To power on the device, press the Power/Fire button. To range a target, aim the reticle at the desired object and press the Power/Fire button. The distance will be displayed in the viewfinder.

4.2 PinSeeker with Jolt Technology

PinSeeker with Jolt provides confirmation when the rangefinder has locked onto the flagstick, filtering out background objects. When the flag is acquired, the device will vibrate briefly (Jolt) and a flashing red ring will appear in the display.



Image 4.2: View through the rangefinder demonstrating PinSeeker with Jolt technology.

4.3 Slope Compensation

The A1-Slope calculates and displays slope-compensated distances, adjusting for elevation changes between you and the target. This provides a 'play as' distance for more accurate club selection.

SLOPE

COMPENSATION



Image 4.3: Visual explanation of slope compensation in golf.

4.4 Tournament Legal Mode

The Slope feature can be toggled on or off using the Mode button. When Slope is off, the device provides line-of-sight distances only, making it legal for tournament play where slope features are prohibited.

4.5 BITE Magnetic Mount

The integrated BITE magnetic mount allows for easy attachment of the rangefinder to a golf cart bar or other metal surfaces, keeping it accessible during play.



Image 4.4: The A1-Slope Rangefinder utilizing its BITE magnetic mount on a golf cart.

4.6 Magnification and Range

The A1-Slope provides 6x magnification for clear viewing of targets. It can range distances from 5 to 1,300 yards, with flag acquisition up to 350 yards.

MAGNIFICATION

6x

RANGE

5-1,300yds

RANGE TO FLAG

5-350yds



Image 4.5: Details on the A1-Slope's magnification and ranging specifications.

4.7 Product Video

Your browser does not support the video tag.

Video 4.1: An official overview and demonstration of the Bushnell Golf A1-Slope Rangefinder's features and operation.

5. MAINTENANCE

Proper care and maintenance will ensure the longevity and performance of your A1-Slope rangefinder.

- **Cleaning Lenses:** Use the provided cleaning cloth to gently wipe the lenses. Avoid abrasive materials that could scratch the optics.
- **Cleaning Body:** Wipe the body of the rangefinder with a soft, damp cloth. Do not use harsh chemicals or solvents.
- **Water Resistance:** The device has an IPX6 water resistance rating, meaning it is protected against powerful water jets. However, it is not designed for submersion. Dry the device thoroughly if it gets wet.

- **Storage:** Store the rangefinder in its premium carry case when not in use to protect it from dust, dirt, and impacts. Store in a cool, dry place.



Image 5.1: Storing the A1-Slope Rangefinder in its protective case.

6. TROUBLESHOOTING

If you encounter issues with your A1-Slope rangefinder, refer to the following common solutions:

- **Device not powering on:** Ensure the battery is fully charged. Connect the device to the charger and allow it to charge for at least 30 minutes before attempting to power on again.
- **Inaccurate readings:** Ensure the lenses are clean and free from smudges or debris. Make sure you are ranging a clear target and not an obstruction. Check if Slope Compensation is enabled or disabled as desired.
- **Display issues:** If the display is dim or flickering, the battery may be low. Recharge the device. If the issue persists, contact customer support.
- **No Jolt feedback:** Ensure PinSeeker mode is active. If the target is very close or very far, Jolt feedback may be less pronounced.

For further assistance, please refer to the support section.

7. SPECIFICATIONS

Feature	Specification
Model Number	202510S
Magnification	6x
Measuring Range	5 - 1300 yards
Range to Flag	Up to 350 yards
Battery Type	Rechargeable Lithium-Ion
Water Resistance	IPX6
Weight	5.1 Ounces
Material	Plastic
UPC	840454612752

8. WARRANTY INFORMATION

The Bushnell Golf A1-Slope Laser Rangefinder is covered by a Limited Warranty. For specific details regarding the terms and conditions of your warranty, please refer to the documentation included with your product or visit the official Bushnell Golf website.

Additionally, the product typically includes a 30-day return/replacement policy from the point of purchase. Please check with your retailer for their specific return policies.

9. SUPPORT

For technical support, service, or additional information regarding your Bushnell Golf A1-Slope Laser Rangefinder, please contact Bushnell Golf customer service. Contact details can typically be found on the official Bushnell Golf website or in the Quick Start Guide provided with your product.

You can also visit the [Certified Brands Store on Amazon](#) for product information and support resources.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question