

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Guide Gear](#) /

› [Guide Gear 6-Foot Tripod Hunting Tower Blind \(Model TS305\) Instruction Manual](#)

## Guide Gear TS305

# Guide Gear 6-Foot Tripod Hunting Tower Blind (Model TS305) Instruction Manual

Brand: Guide Gear

## 1. INTRODUCTION

This manual provides essential instructions for the safe assembly, operation, and maintenance of your Guide Gear 6-Foot Tripod Hunting Tower Blind, Model TS305. This elevated hunting stand is designed to provide a stable and concealed position for up to two hunters, offering an improved field of view and protection from the elements.



Image 1.1: The Guide Gear 6-Foot Tripod Hunting Tower Blind, fully assembled with its camouflage blind enclosure.

## 2. SAFETY INFORMATION

---

**WARNING: Failure to follow these safety instructions may result in serious injury or death.**

- Always read and understand all instructions before assembly and use.
- Ensure all components are present and undamaged before beginning assembly.
- Assemble the tripod tower on level ground.
- Always have at least two adults for assembly and setup.
- Do not exceed the maximum weight capacity of 500 lbs (226.8 kg).
- Regularly inspect all bolts, nuts, and structural components for tightness and wear.
- Do not use the blind during severe weather conditions, including high winds, lightning, or heavy snow.
- Always maintain three points of contact when ascending or descending the ladder.
- Securely anchor the tripod tower to the ground using appropriate stakes or tie-downs to prevent tipping.
- Be aware of your surroundings and local hunting regulations.

### 3. PACKAGE CONTENTS

---

Verify that all parts are present before beginning assembly. Refer to the parts list provided in your product packaging for detailed component identification.

- Tripod Tower Frame Components
- Ladder Sections
- Platform Sections
- Blind Enclosure (Water-resistant 210D polyester shell)
- Hardware (bolts, nuts, washers, pins)
- Instruction Manual

### 4. SPECIFICATIONS

---

<b>Model Name</b>	Tripod Hunting Tower
<b>Part Number</b>	TS305
<b>Height to Platform</b>	6 feet (1.83 m)
<b>Platform Dimensions</b>	48 inches L x 48 inches W (121.9 cm x 121.9 cm)
<b>Blind Dimensions</b>	48 inches L x 48 inches W x 64 inches H (121.9 cm x 121.9 cm x 162.6 cm)
<b>Weight Capacity</b>	500 lbs (226.8 kg)
<b>Material (Frame)</b>	Durable Steel Construction
<b>Material (Blind)</b>	Water-resistant 210D Polyester Shell, Black PU-coated fabric interior
<b>Item Package Dimensions</b>	49.41 x 31.5 x 6.89 inches (125.5 x 80 x 17.5 cm)
<b>Package Weight</b>	118.8 Pounds (53.9 kg)

## 5. SETUP AND ASSEMBLY INSTRUCTIONS

---

Assembly requires careful attention to detail. It is recommended to have at least two people for assembly. Tools required: 11mm socket and ratchet, 11mm wrench.

1. **Unpack and Organize:** Lay out all components on a clean, flat, and level surface. Verify all parts against the included parts list. Hardware for each step is typically packaged separately.
2. **Assemble Tripod Legs:** Connect the individual leg sections according to the diagrams in your specific assembly guide. Ensure all bolts are securely fastened but do not fully tighten until the frame is upright.
3. **Attach Platform:** Secure the platform sections to the top of the tripod legs. Ensure the platform is level and stable.



Image 5.1: Rear view of the tripod tower frame, showing the ladder and platform structure.

4. **Install Ladder:** Attach the adjustable ladder to the designated points on the tripod tower. Ensure it is firmly secured and provides safe access to the platform.



Image 5.2: A hand gripping the ladder rail, illustrating the secure access point to the elevated platform.

5. **Erect the Tower:** With assistance, carefully raise the assembled tripod tower to its upright position. Ensure it is stable and level.
6. **Anchor the Tower:** Securely anchor the base of the tripod legs to the ground using appropriate stakes or tie-downs to prevent movement or tipping.
7. **Install Blind Enclosure:** Drape and secure the water-resistant 210D polyester blind enclosure over the platform frame. Ensure all attachment points are fastened to prevent flapping in the wind. The black PU-coated fabric interior should face inwards.
8. **Final Inspection:** Double-check all bolts and connections for tightness. Ensure the ladder is stable and the blind is properly secured.

## 6. OPERATING INSTRUCTIONS

---

The Guide Gear Tripod Hunting Tower Blind is designed for comfortable and concealed hunting.

- **Access:** Use the adjustable ladder and the triangle zippered door for easy and quiet entry and exit.
- **Visibility:** The LookOut 1-way mesh windows allow you to see outside clearly while preventing game from seeing inside. Position yourself to maximize your field of view through the various windows.



Image 6.1: A hunter inside the blind, positioned with a bow, demonstrating the clear view through the mesh windows.

- **Concealment:** The black PU-coated fabric interior helps eliminate scent, shine, and noise, enhancing your concealment.
- **Shooting:** Utilize the multiple windows for lining up your shot. The 26-inch height from the platform to the shooting rail provides a stable rest.




Image 6.2: Two hunters inside the blind, with one aiming a rifle through an open window, illustrating the shooting capability.

- **Interior Space:** The 4' x 4' platform provides ample space for two hunters and their gear.




Image 6.3: The spacious interior of the blind, featuring a chair and additional hunting gear, demonstrating comfort and utility.

## 7. MAINTENANCE

- **Cleaning:** Clean the blind enclosure with mild soap and water. Avoid harsh chemicals that may damage the fabric or camouflage pattern. Ensure it is completely dry before storage.
- **Frame Inspection:** Periodically inspect the steel frame for any signs of rust, bending, or damage. Tighten any loose bolts.
- **Fabric Inspection:** Check the blind fabric for tears, holes, or excessive wear. Repair minor damage promptly to maintain its integrity.
- **Storage:** When not in use, disassemble the blind and store it in a dry, protected area to prolong its lifespan.

## 8. TROUBLESHOOTING

- **Difficulty Assembling:** Ensure all parts are correctly oriented according to the diagrams. Do not overtighten bolts until the entire section is aligned. Refer to the step-by-step instructions carefully.
- **Instability:** Verify that the tripod tower is on level ground and all anchoring points are securely fastened. Check all frame connections for tightness.
- **Blind Not Fitting:** Ensure the blind enclosure is oriented correctly and all attachment straps or clips are properly engaged with the frame.

For issues not covered here, please contact customer support.

## 9. WARRANTY INFORMATION

This Guide Gear Tripod Hunting Tower Blind is covered by a 30-day warranty from the date of purchase. This

warranty covers manufacturing defects. Please retain your proof of purchase for any warranty claims.

## 10. CUSTOMER SUPPORT

For further assistance, replacement parts, or to report any issues, please contact Guide Gear customer support through their official website or the retailer where the product was purchased.

### Related Documents - TS305

	<p><b><a href="#">Guide Gear 4x4 6' Tripod Tower &amp; Blind: Assembly and Use Manual</a></b></p> <p>This comprehensive manual details the safe assembly and use of the Guide Gear 4x4 6' Tripod Tower &amp; Blind. It includes a full parts list, step-by-step assembly instructions, crucial safety warnings, weight limits, and maintenance schedules for optimal performance and user safety.</p>
	<p><b><a href="#">Guide Gear 10' x 10' Teepee Tent: Setup, Warnings, and Storage Guide</a></b></p> <p>Comprehensive guide for the Guide Gear 10' x 10' Teepee Tent, covering essential safety warnings, helpful setup tips, package contents, and proper disassembly and storage instructions.</p>
	<p><b><a href="#">Guide Gear 704573 ATV/UTV Utility Trailer Assembly and Use Manual</a></b></p> <p>This manual provides essential assembly instructions, safety warnings, and care guidelines for the Guide Gear 704573 ATV/UTV Utility Trailer. Learn how to properly assemble, use, and maintain your trailer for off-road applications.</p>
	<p><b><a href="#">Guide Gear 10'x10' Teepee Tent Instruction and Safety Manual</a></b></p> <p>Instruction and safety manual for the Guide Gear 10'x10' Teepee Tent, including package contents, general guidelines, warnings, and setup instructions.</p>

 <p>Guide Gear 18'x18' Deluxe Teepee Tent Item #510001 For assistance with your product, please contact Sportsman's Guide customer service at 800-447-1900 or visit <a href="http://www.sportmansguide.com">www.sportmansguide.com</a>. SG SPORTSMAN'S GUIDE</p>	<p><a href="#"><u>Guide Gear 18'x18' Deluxe Teepee Tent: Instruction and Safety Manual</u></a> Comprehensive instruction and safety manual for the Guide Gear 18'x18' Deluxe Teepee Tent. Includes package contents, setup guides, important warnings regarding flammability and safe usage, and care instructions.</p>
---	---

## Documents - Guide Gear – TS305



### [Guide Gear 80LB ATV Receiver Mount Spreader Owner's Manual and Operating Instructions](#)

This manual provides operating instructions, assembly steps, safety precautions, and a parts list for the Guide Gear 80LB ATV Receiver Mount Spreader (Item# 583375). Learn how to safely assemble, operate, and maintain your spreader for optimal performance.

1 of 1

### [Guide Gear 4x4 6' Tripod Tower & Blind: Assembly and Use Manual](#)

This comprehensive manual details the safe assembly and use of the Guide Gear 4x4 6' Tripod Tower & Blind. It includes a full parts list, step-by-step assembly instructions, crucial safety warnings, weight limits, and maintenance schedules for optimal performance and user safety.

lang:en score:26 filesize: 1.09 M page\_count: 15 document date: 2021-06-02

1 of 1