VINGLI BL0GCM4

VINGLI Fireplace TV Stand with 23-inch Electric Fireplace and Sliding Barn Doors

Model: BL0GCM4 | Color: Gray Oak

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your VINGLI Fireplace TV Stand. This farmhouse-style entertainment center features sliding barn doors, ample storage, and an integrated 23-inch electric fireplace with adjustable flame colors and heat settings. Please read this manual thoroughly before assembly and use to ensure safe and proper operation.

Image: The VINGLI Fireplace TV Stand in Gray Oak, featuring sliding barn doors and a central electric fireplace, supporting a television.

Safety Information

WARNING: To reduce the risk of fire, electric shock, or injury, read all instructions before using this appliance.

- Always supervise children and pets when the fireplace is in use.
- Keep flammable materials such as furniture, bedding, papers, clothes, and curtains at least 3 feet (0.9 meters) away from the front of the fireplace.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped, or damaged in any manner.
- Ensure the power cord is not pinched or routed under carpets or other coverings.

Package Contents

Your VINGLI Fireplace TV Stand is typically delivered in two separate packages, which may arrive at different times. Please ensure you have received both packages and all components before beginning assembly.

Expected Components:

- TV Stand Panels and Hardware
- 23-inch Electric Fireplace Insert
- Remote Control for Fireplace
- Assembly Instructions Manual

Image: The 23-inch electric fireplace insert and its remote control, alongside an illustration indicating delivery in two packages.

Assembly and Setup

Assembly of the VINGLI Fireplace TV Stand requires following the provided step-by-step instructions. It is recommended to have two people for assembly. Ensure you have a clear, spacious area to work in.

General Assembly Steps:

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out and compare them against the parts list in your separate assembly manual to ensure all pieces are present and undamaged.
2. **Assemble the TV Stand Frame:** Follow the diagrams and instructions to connect the main panels of the TV stand using the provided hardware.
3. **Install Shelving and Barn Doors:** Attach the adjustable shelves and install the sliding barn door mechanism according to the manual.
4. **Insert the Electric Fireplace:** Once the TV stand frame is complete, carefully slide the 23-inch electric fireplace insert into its designated opening. Ensure it is securely seated.
5. **Cable Management:** Utilize the integrated cable management holes to organize power cords and media device cables.

Image: Detailed views of the TV stand's features, including the smooth barn door rail, adjustable shelves, spacious storage, and a cable management cutout.

Operating Instructions (Electric Fireplace)

The 23-inch electric fireplace provides both aesthetic flame effects and supplemental heating. It can be operated via the control panel on the unit or the included remote control.

Features:

- **Power On/Off:** Press the power button to turn the fireplace on or off.
- **Flame Colors:** Cycle through seven captivating flame colors to match your mood or decor.
- **Temperature Control:** Adjust the heat output with a customizable temperature range from 62°F to 82°F (17°C to 28°C). The heater can be used independently of the flame effect.
- **Timer Function:** Set an automatic shut-off timer for 0.5 to 6 hours.
- **Safety:** Equipped with overheating protection and CSA certification for safe operation.

Maintenance

Regular maintenance ensures the longevity and optimal performance of your TV stand and electric fireplace.

TV Stand:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Dusting:** Regularly dust all surfaces to prevent buildup.
- **Hardware Check:** Periodically check and tighten any loose screws or fasteners.

Electric Fireplace:

- **Ventilation:** Ensure the air intake and exhaust vents are clear of obstructions.
- **Cleaning:** Gently wipe the exterior with a soft, dry cloth. Do not spray liquids directly onto the unit.
- **Bulb Replacement:** Refer to the fireplace insert's specific manual for instructions on replacing flame effect bulbs, if applicable.

Troubleshooting

If you encounter issues with your VINGLI Fireplace TV Stand or electric fireplace, refer to the following common solutions:

Problem	Possible Cause	Solution
Fireplace does not turn on.	No power, tripped circuit breaker, loose connection.	Check power cord connection, ensure outlet is functional, reset circuit breaker.
No heat output.	Heater function off, temperature setting too low, overheating protection activated.	Ensure heater is enabled, increase temperature setting, allow unit to cool down if overheated.
Remote control not working.	Dead batteries, obstruction, remote out of range.	Replace batteries, remove obstructions, operate remote within recommended range.
Sliding doors are stiff.	Dust or debris in the rail, misaligned.	Clean the rail, check for proper alignment of the doors.

Specifications

Brand: VINGLI

Model Number: BL0GCM4

Color: Gray Oak

Material: Engineered Wood

Overall Dimensions (W x D x H): 58.07 inches x 15.75 inches x 29.68 inches

Item Weight: Approximately 76.3 pounds

Fireplace Insert Size: 23 inches

TV Size Compatibility: Up to 70 inches

Special Features: Sliding barn doors, 7 flame colors, adjustable thermostat (62°F-82°F), 0.5-6 hour timer, overheating protection, CSA certified.



Image: Visual representation of the TV stand's dimensions and its capacity to hold various TV sizes up to 70 inches.

Warranty and Support

VINGLI is committed to providing quality products and customer satisfaction. Your product is backed by a 1-year quality service guarantee.

Customer Support:

For any questions, concerns, or assistance with assembly, operation, or parts, please contact VINGLI-Direct customer support. They offer 24/7 professional quality service to ensure a convenient and worry-free experience.
Please refer to your purchase documentation or the VINGLI store page on Amazon for the most current contact information.

Image: A graphic highlighting VINGLI's commitment to product quality and customer service, including a 1-year warranty and 24/7 support.

© 2025 VINGLI. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question