

Lightdot 47x24 Inches Computer Desk with Power Outlets & USB

Lightdot 47x24 Inches Computer Desk with Power Outlets & USB Instruction Manual

Model: 47x24 Inches Computer Desk with Power Outlets & USB

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Lightdot 47x24 Inches Computer Desk. Please read thoroughly before use to ensure proper setup and safe operation.

SAFETY INFORMATION

- Always assemble the desk on a stable, level surface.
- Do not overload the desk beyond its weight capacity.
- Keep the work area clear of obstacles to prevent tripping hazards.
- Ensure all electrical connections are secure and comply with local safety standards.

SETUP AND ASSEMBLY

The Lightdot computer desk is designed for easy assembly. Follow these steps for a quick and secure setup. An assembly video is provided below for visual guidance.

Video: Assembly instructions for the Lightdot 47x24 Inches Computer Desk, demonstrating step-by-step setup including attaching legs, securing the desktop, and installing the power outlet module.


Step 1: Unpack Components. Carefully remove all parts from the packaging. Verify all components are present against the included parts list. Lay out the parts on a soft, clean surface to prevent scratches.

Desk Dimensions



Image: All desk components, including the desktop, metal frame parts, and hardware, laid out for assembly. Key dimensions are indicated.

Step 2: Assemble the Frame. Attach the metal legs to the crossbars using the provided screws and tools. Ensure all connections are firm and stable. The X-shaped leg design provides enhanced stability.




Oversized Desktop



Premium Waterproof Surface



Hassle-free Assemble



Prevent Scratches

Image: Detailed view of a desk leg being secured with a screw, illustrating the assembly process. Also shows the adjustable leveling feet.

Step 3: Attach the Desktop. Carefully place the desktop onto the assembled frame. Align the pre-drilled holes and secure the desktop with the remaining screws. Ensure the baffle is correctly oriented.

Step 4: Install Power Outlets. Insert the power strip module into the designated slot on the desktop. Secure it with the provided screws. Connect the desk's power cord to a functional wall outlet.



3 AC Outlets
125V/12A



1 USB Port
5V-2A

Image: The integrated power strip with 3 AC outlets and 2 USB ports, demonstrating device charging capabilities.

OPERATING INSTRUCTIONS

Your Lightdot computer desk is designed for versatile use in various environments, providing a functional and stable workspace.

Power Outlets and USB Ports

The integrated power strip provides 3 AC outlets and 2 USB ports for convenient charging of your electronic devices. Simply plug in your devices to power them. The power strip can be easily installed on either the left or right side of the desk to suit your setup preferences.

Versatile Use

This desk is suitable for various activities and settings:

- **Home Office:** Ideal for computers, monitors, and essential office supplies, providing an organized workspace.
- **Gaming:** Offers a stable and spacious surface for gaming setups, including monitors, keyboards, and consoles.
- **Study:** Provides a comfortable and focused environment for reading, writing, and academic tasks.
- **Bedroom:** Functions as a compact workstation, vanity, or personal desk, fitting well into smaller spaces.



Image: The Lightdot desk configured as a home office workstation with a laptop and accessories, showcasing its functional design.



Image: The Lightdot desk used as a gaming station, complete with a monitor, keyboard, mouse, and gaming accessories, highlighting its suitability for entertainment.

MAINTENANCE

To maintain the appearance and longevity of your Lightdot computer desk, follow these simple care instructions:

- Wipe the desk surface with a dry, soft cloth to remove dust and debris.
- Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the finish.
- Protect the surface from excessive moisture, spills, and direct heat sources to prevent warping or discoloration.
- Regularly check and tighten all screws and fasteners to ensure the desk remains stable.

TROUBLESHOOTING

If you encounter any issues with your Lightdot computer desk, refer to the following common troubleshooting tips:

Desk Wobbles

If the desk feels unstable or wobbles, first ensure all assembly screws are securely tightened. Then, adjust

the leveling feet located at the bottom of each leg. Rotate them clockwise or counter-clockwise until the desk is stable on uneven floors.

Power Outlets Not Working

Verify that the desk's main power cord is securely plugged into a functional wall outlet. Check if the integrated power strip module is properly seated and connected within its slot on the desktop. If issues persist, ensure the wall outlet itself is receiving power.

SPECIFICATIONS

Detailed specifications for the Lightdot 47x24 Inches Computer Desk:

Feature	Detail
Brand	Lightdot
Model Name	47x24 Inches Computer Desk with Power Outlets & USB
Product Dimensions (D x W x H)	24"D x 47"W x 29.5"H
Color	Rustic Brown
Top Material Type	Wood
Frame Material Type	Metal
Power Outlets	3 AC Outlets (125V/12A)
USB Ports	2 USB Ports (5V-2A)
Assembly Required	Yes

Desk Dimensions



Image: Detailed diagram illustrating the dimensions of the desk and its components, including the power cord length.

WARRANTY INFORMATION

This Lightdot product comes with a limited warranty. For specific details regarding warranty coverage, duration, and terms, please refer to the warranty documentation included with your purchase. Keep your proof of purchase for warranty claims.

CUSTOMER SUPPORT

For further assistance, questions, or to report any issues with your Lightdot 47x24 Inches Computer Desk, please contact Lightdot customer support.

Manufacturer: Lightdot

Online Store: [Visit the Lightdot Store on Amazon](#)