

SEDETA 63" L Shaped Desk

SEDETA 63" L Shaped Desk Instruction Manual

Brand: SEDETA | Model: 63" L Shaped Desk

PRODUCT OVERVIEW

The SEDETA 63" L Shaped Desk is a versatile furniture piece designed for home office environments. It features a convertible L-shaped or long two-person desk configuration, integrated storage solutions including a drawer and cabinet, and a built-in power strip for convenience. This manual provides essential information for assembly, usage, and maintenance to ensure optimal performance and longevity of your desk.



Image: The SEDETA 63" L Shaped Desk configured in an L-shape, showcasing its spacious work surface, integrated drawer, storage cabinet, and power strip. The desk is grey with black metal legs, set in a modern home office with two computer monitors.

KEY FEATURES

- **Convertible Design:** The desk can be assembled as a 63" x 43.3" L-shaped corner desk or an 86.6" long two-person desk, adapting to various room layouts and user needs.
- **Integrated Storage:** Includes a wooden drawer and a storage cabinet, providing space for books, files, and office supplies. A fabric storage bag is also included for additional organization.
- **Built-in Power Strip:** Features a charging station with 4 AC outlets and 2 USB ports, allowing simultaneous power for up to 6 devices. An on-off switch enhances safety.
- **Durable Construction:** Constructed with P2 Particle Board and a metal base, ensuring stability and durability.
- **Adjustable Feet:** Equipped with adjustable feet to protect floors and ensure stability on uneven surfaces.

ASSEMBLY INSTRUCTIONS

To ensure a smooth assembly process, please follow these general guidelines. Refer to the detailed instructions provided in your product packaging for step-by-step visual guides and numbered parts.

1. **Unpack and Verify:** Carefully unpack all components and verify against the parts list in your manual. Ensure all parts are present and undamaged.
2. **Prepare Workspace:** Clear a spacious area for assembly. It is recommended to assemble the desk on a soft, clean surface to prevent scratches.
3. **Follow Step-by-Step Guide:** Adhere strictly to the numbered steps in the provided instruction manual. Pay close attention to diagrams and part orientations.
4. **Secure Connections:** Ensure all screws, bolts, and connectors are tightened securely. Periodically check and re-tighten fasteners to maintain desk stability.
5. **Adjust Leveling Feet:** Once assembled, adjust the leveling feet at the bottom of the desk legs to ensure the desk is stable and level on your floor.

Important Safety Note: Always assemble the desk according to the provided instructions. Ensure all screws are tightened securely after leveling the table top to maintain stability and prevent accidents.



Image: A detailed diagram illustrating the dimensions of the SEDETA desk in both its L-shaped (63.0" x 43.3" x 29.6") and straight (86.6" x 19.7" x 29.6") configurations, along with the drawer's internal dimensions (13.4" x 12.2" x 6.7").

OPERATING INSTRUCTIONS

Using the Built-in Power Strip

The desk includes a power strip for convenient device charging and power access.

- **Connection:** Plug the desk's power cord into a standard wall outlet.
- **Power On/Off:** Use the integrated on-off switch on the power strip to control power to all connected devices. This allows for one-button power management and enhances electrical safety.
- **Charging:** Connect your devices (e.g., cell phones, tablets, laptops) to the 4 AC outlets or 2 USB ports. The USB ports provide 5V/2A output.



Image: A close-up view of the desk's integrated charging station, featuring four AC outlets, two USB ports, and a safety switch. Multiple electronic devices are depicted connected for charging.

Utilizing Storage Features

- **Drawer:** Use the smooth-gliding wooden drawer for storing smaller office items, documents, or personal belongings.
- **Storage Cabinet:** The cabinet provides enclosed storage for larger items, offering a tidy and private space for your essentials.
- **Fabric Storage Bag:** Attach the fabric storage bag to the side of the desk for easy access to magazines, notebooks, or other frequently used items.



Image: The desk's wooden drawer, shown open and containing various items like headphones, books, and a tablet, demonstrating its practical storage space.



Image: The desk's storage cabinet, shown with its door open, revealing books, a backpack, and a camera, emphasizing its capacity for larger items.



Image: A fabric storage bag attached to the side of the desk, providing convenient access to magazines, a smartphone, and other small office supplies.

CARE AND MAINTENANCE

- **Cleaning:** Wipe the desk surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Spills:** Promptly clean any spills to prevent staining, especially on the engineered wood surfaces.
- **Heat and Moisture:** Avoid placing hot items directly on the desk surface. Use coasters or protective pads. Protect the desk from excessive moisture.
- **Fastener Checks:** Periodically inspect all fasteners and re-tighten them as needed to ensure the desk remains stable and secure.
- **Power Strip Care:** Ensure the power strip is kept dry. Do not overload the outlets. Disconnect from the wall outlet when not in use for extended periods.

TROUBLESHOOTING

- **Desk Wobbles:** Check if the adjustable feet are properly set. Adjust each foot individually until the desk is stable on all four corners. Ensure all assembly screws are tight.
- **Drawer Sticks:** Verify that the drawer slides are correctly installed and aligned. Ensure no foreign objects are obstructing the drawer's movement.
- **Power Strip Not Working:** Check if the desk's main power cord is securely plugged into a functional wall outlet. Ensure the power strip's on-off switch is in the "on" position. Test with different devices to rule out device-specific issues.
- **Missing Parts/Damage:** If your item arrives damaged, scratched, or with missing parts, please contact SEDETA customer service for assistance.

SPECIFICATIONS

Brand	SEDETA
Model Number	63" L shaped desk
Product Dimensions (L-Shape)	19.7"D x 63"W x 29.6"H
Product Dimensions (Long Desk)	86.6"W x 19.7"D x 29.6"H
Color	Grey
Style	Industrial

Material	Engineered Wood (P2 Particle Board), Metal
Item Weight	59 Pounds
Special Features	Built-In USB Outlet (4 AC, 2 USB), Drawer, Storage Cabinet, Fabric Storage Bag, Adjustable Feet
Assembly Required	Yes

WARRANTY AND SUPPORT

For warranty information, replacement parts, or any product-related inquiries, please contact SEDETA customer service directly. Refer to the contact details provided in your product packaging or on the official SEDETA website.

If your item arrives damaged, scratched, or with missing parts, please contact us for a free replacement or partial refund.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question