

[Manuals.plus](#) /

> [ZYHKON](#) /

> ZYHKON Z9pro Wireless Earbuds Instruction Manual

ZYHKON Z9pro

ZYHKON Z9pro Wireless Earbuds Instruction Manual

Model: Z9pro

INTRODUCTION

This manual provides detailed instructions for the ZYHKON Z9pro Wireless Earbuds. Please read this manual thoroughly before using the product to ensure proper operation and to maximize your listening experience.

PACKAGE CONTENTS

Verify that all items are present in your package:

- Headphones (Left/Right) x 2
- USB-C Charging Cable x 1
- Portable Charging Box x 1
- User Manual x 1
- Eartips (S/M/L)



PRODUCT OVERVIEW

The ZYHKON Z9pro Wireless Earbuds offer advanced audio features and convenient controls. Key features include:

- **Hybrid Active Noise Cancelling (ANC) & Environmental Noise Cancellation (ENC):** Reduces ambient noise by up to 38dB and filters background chatter during calls.
- **48-Hour Playtime:** Up to 6-8 hours on a single charge, extended to 48 hours with the charging case.
- **Revolutionary Touchscreen Case:** Allows direct control over volume, track skipping, calls, alarms, and earbud location.
- **Hi-Fi Sound Quality:** Equipped with 14.2mm diaphragm speaker drivers for clear audio.
- **5 EQ Modes:** Standard, Rock, Jazz, Pop, and Classic, selectable via the charging case.
- **Bluetooth 5.4:** Provides faster and more reliable wireless connectivity.
- **IPX7 Waterproof:** Resistant to sweat and light rain.
- **Ergonomic Design:** Lightweight with three sizes of soft silicone ear tips for a comfortable fit.

SETUP

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

1. Place the earbuds into the charging case.
2. Connect the USB-C charging cable to the charging port on the case and to a power source.
3. The touchscreen display on the case will show the charging status and battery levels. A full charge takes approximately 1.5 hours.



Figure 2: Charging the Earbuds and Case




Figure 3: Playtime and Charging Overview

2. Bluetooth Pairing

The earbuds support one-step auto pairing.

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "Z9pro" from the list of devices to connect.
4. Once connected, the earbuds are ready for use.



Figure 4: One-Step Auto Pairing

OPERATING INSTRUCTIONS

1. Smart Touch Control

The earbuds feature touch-sensitive controls for managing music and calls.

Action	Function
Click 1 time	Play/Pause music, Answer/End calls
Click 2 times	Next Song (Right earbud), Previous Song (Left earbud)
Click 3 times	Switch ANC modes (ANC/Transparency/Normal)
Click 4 times	Hang up call
Long press 2 seconds	Activate Voice Assistant



Figure 5: Earbud Touch Controls

2. Touchscreen Case Functions

The charging case features a full-color LED touchscreen for direct control and access to various functions without needing your phone. Swipe left or right on the screen to navigate interfaces.

- **Time Display:** Shows current time and date.
- **Battery Display:** Indicates battery levels for both earbuds (L/R) and the charging case.
- **Noise Reduction Control:** Switch between ANC, Transparency, and Normal modes.
- **EQ Modes:** Select from 5 preset equalizer modes (Standard, Rock, Jazz, Pop, Classic).
- **Volume Control:** Adjust playback volume directly.
- **Find My Earphone:** Activates a sound on the earbuds to help locate them.
- **Camera Control:** Use the case to trigger your phone's camera shutter.
- **Flashlight:** Activates a built-in flashlight function.
- **Alarms:** Set alarms.

Superior **Hi-Fi** Stereo Sound Quality

14.2MM

speakers for an immersive experience

Bluetooth 5.4




Figure 6: Touchscreen Case Functions

5 EQ Modes Redefine Your Music!




Figure 7: Selecting EQ Modes via Touchscreen



Figure 8: Full-Color Multi-Function LED Touch Screen




Figure 9: Additional Smart Functions

3. Active Noise Cancellation (ANC) & Environmental Noise Cancellation (ENC)

The Z9pro earbuds feature advanced noise cancellation technologies.

- **ANC (Active Noise Cancelling):** Blocks up to 38dB of ambient noise, ideal for noisy environments like public transport or offices.
- **ENC (Environmental Noise Cancellation):** Filters out up to 90% of background noise during phone calls, ensuring clear voice transmission.
- **Transparency Mode:** Allows you to hear your surroundings while listening to audio, useful for awareness in urban environments.

Switch between ANC, Transparency, and Normal modes using the touch controls on the earbuds (3 clicks) or via the touchscreen on the charging case.



Figure 10: ANC and ENC Noise Cancellation

Your browser does not support the video tag.

Video 1: Demonstrating the Z9pro Wireless Earbuds' features, including the multifunctional touch screen, Hi-Fi stereo sound, Bluetooth 5.4, ANC noise reduction, and ENC clear calls.

MAINTENANCE

To ensure the longevity and optimal performance of your ZYHKON Z9pro Wireless Earbuds, follow these maintenance guidelines:

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use abrasive cleaners or solvents.
- **Eartips:** Remove and clean the silicone eartips periodically with water and mild soap. Ensure they are completely dry before reattaching.
- **Charging Port:** Keep the USB-C charging port free of dust and debris.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged.

- **Avoid Extreme Conditions:** Do not expose the earbuds to extreme temperatures, humidity, or direct sunlight for extended periods.
- **Water Resistance:** While IPX7 waterproof, avoid submerging the earbuds in water. Dry them thoroughly if they get wet.

TROUBLESHOOTING

If you encounter issues with your ZYHKON Z9pro Wireless Earbuds, refer to the following common problems and solutions:

Problem	Solution
Earbuds not pairing or connecting	<ul style="list-style-type: none"> ◦ Ensure earbuds are charged. ◦ Turn off and on Bluetooth on your device. ◦ Delete "Z9pro" from your device's Bluetooth list and re-pair. ◦ Place earbuds back in the case, close, then open again to reset pairing mode.
Only one earbud working	<ul style="list-style-type: none"> ◦ Ensure both earbuds are charged. ◦ Place both earbuds back in the charging case, close the lid, wait a few seconds, then open again. ◦ Try resetting the earbuds (refer to the "Reset" function on the touchscreen case if available, or consult manufacturer support).
Poor sound quality or intermittent connection	<ul style="list-style-type: none"> ◦ Ensure earbuds are fully charged. ◦ Move closer to your connected device to avoid interference. ◦ Ensure there are no physical obstructions between the earbuds and your device. ◦ Clean the earbud mesh if sound is muffled.
Touch controls not responding	<ul style="list-style-type: none"> ◦ Ensure your fingers are clean and dry. ◦ Try restarting the earbuds by placing them in the case and taking them out. ◦ Ensure the earbuds are properly seated in your ears.
Charging case touchscreen unresponsive	<ul style="list-style-type: none"> ◦ Ensure the case is charged. ◦ Try connecting the case to a power source. ◦ If the issue persists, contact customer support.

SPECIFICATIONS

Feature	Detail
Model Name	Z9pro

Feature	Detail
Connectivity Technology	Wireless (Bluetooth 5.4)
Audio Driver Type	Dynamic Driver (14.2mm)
Noise Control Features	Hybrid Active Noise Cancellation (ANC), Environmental Noise Cancellation (ENC)
Battery Life (Earbuds)	6-8 Hours
Total Playtime with Case	Up to 48 Hours
Charging Time	1.5 Hours
Control Method	Touch (Earbuds), Touchscreen (Case)
Water Resistance Level	IPX7 Waterproof
Material	Acrylonitrile Butadiene Styrene (ABS), Silicone
Item Weight	3.52 ounces
Manufacturer	ZYHKON

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official ZYHKON website. Keep your proof of purchase for warranty claims.

