Conyat X5S

Conyat X5S Open-Ear Wireless Earphones User Manual

Model: X5S | Brand: Conyat

1. Introduction

Thank you for choosing the Conyat X5S Open-Ear Wireless Earphones. These earphones are designed to provide a comfortable and safe listening experience by allowing you to stay aware of your surroundings while enjoying high-quality audio. Featuring advanced Bluetooth 6.0 technology, 14.2mm dynamic drivers, ENC noise-canceling microphones, and an IPX7 waterproof rating, the X5S is perfect for various activities from daily commutes to intense workouts.

2. Package Contents

Please check the package for the following items:

- Charging Case x 1
- X5S Wireless Earphones x 2 (Left and Right)
- Type-C Charging Cable x 1
- User Manual x 1



Image: Contents of the Conyat X5S earphone package, including the charging case, two earphones, a Type-C cable, and the user manual.

3. Wearing Instructions

For optimal sound and comfort, ensure the earphones are worn correctly.

1. Hook the tip of the earphone onto the ear bone.
2. Rotate the earphone and slide it behind the ear.
3. Adjust the ear hook, pulling down slightly to ensure a secure and comfortable fit.



Image: A visual guide demonstrating the three steps to correctly wear the open-ear earphones for a secure and comfortable fit.

The open-ear design ensures excellent breathability and comfort, with each earbud weighing only 6.7g, providing an ultra-lightweight feel.




Image: A person wearing the Conyat X5S earphones, highlighting the open-ear design, breathability, and lightweight nature (6.7g per earbud) for comfortable, interference-free use.

4. Charging

To ensure continuous use, keep your earphones and charging case adequately charged.

4.1 Charging the Earphones and Case

- Place the earphones into the charging case. They will begin charging automatically.
- Connect the Type-C charging cable to the charging case and a power source to charge the case.

4.2 Battery Life and Indicators

- **Earphone Playback:** Approximately 8-10 hours on a single charge.
- **Total Playback with Charging Case:** Up to 40 hours.
- **Fast Charging:** Approximately 1.5 hours for a full charge of the case.
- **LED Display:** The charging case features an LED indicator to show the remaining battery level.



Image: Illustration of the Conyat X5S earphones and charging case, highlighting the 40-hour total battery life, 8-10 hours per earbud charge, and the LED battery display on the case.



Image: Close-up of the charging case showing the LED battery status display and the Type-C charging port.

5. Pairing

The Conyat X5S earphones utilize Bluetooth 6.0 for a stable and quick connection.

5.1 Initial Pairing

1. Open the charging case. The earphones will automatically enter pairing mode.
2. On your device (smartphone, PC, tablet), enable Bluetooth and search for available devices.
3. Select "X5S" from the list of devices to connect.
4. Once connected, the earphones are ready for use.

5.2 Automatic Reconnection

After the initial pairing, the earphones will automatically reconnect to the last paired device when taken out of the charging case.



Image: A visual representation of the Conyat X5S earphones and charging case, illustrating the Bluetooth 6.0 chip and the one-step pairing process with a smartphone.



Image: A smartphone screen showing the Bluetooth settings with "X5S" connected, demonstrating the instant pairing capability of the earphones.

6. Operating Instructions (Touch Controls)

The Conyat X5S earphones feature intuitive touch controls for easy management of music, calls, and voice assistants.

Function	Action (Left/Right Earbud)
Play/Pause Music	Double tap
Volume Up	Single tap (Right)
Volume Down	Single tap (Left)
Next Track	Long press for 2 seconds (Right)
Previous Track	Long press for 2 seconds (Left)
Answer/End Call	Double tap
Reject Call	Long press for 2 seconds
Activate Voice Assistant (Siri)	Triple tap



Image: A diagram illustrating the various touch control gestures for music playback, call management, and voice assistant activation on the Conyat X5S earphones.




Image: A detailed graphic showing the touch control functions for the Conyat X5S, including double tap for play/pause and answer/end call, long press for reject call and track skipping, and triple tap for voice assistant.

7. Sound Quality

The Conyat X5S earphones are equipped with 14.2mm dynamic drivers to deliver a powerful and balanced audio experience.

- **14.2mm Dynamic Drivers:** Experience rich, detailed sound across all frequencies, from deep bass to clear highs.
- **Hi-Fi Stereo Sound:** Enjoy an immersive listening experience with vibrant and lively audio reproduction.
- **Minimal Sound Leakage:** Proprietary directional sound transmission technology minimizes sound leakage, allowing you to enjoy high-quality audio without disturbing others.



Image: An exploded view of the earphone highlighting the internal 14.2mm graphene diaphragm driver, illustrating its role in producing rich, detailed Hi-Fi stereo sound.



Image: A graphic showing two large dynamic drivers, emphasizing the 14.2mm size and their contribution to high-quality stereo sound with a wide frequency range.

8. Call Functionality

The X5S earphones are equipped with high-performance ENC (Environmental Noise Cancellation) microphones for clear communication.

- **ENC Noise-Canceling Microphone:** Accurately eliminates ambient noise, ensuring your voice is transmitted clearly to the other party.
- **Clear Calls Anywhere:** Ideal for noisy environments such as crowded trains, cafes, or offices, providing natural and clear voice reproduction for telework, online meetings, and phone calls.



Image: A woman making a call with the Conyat X5S earphones, illustrating the clear call quality enabled by ENC technology that filters background noise.



Image: A man wearing the Conyat X5S earphones, with a graphic overlay showing sound waves and the concept of ENC noise cancellation for clear calls in any environment.

9. Waterproof Rating

The Conyat X5S earphones are built to withstand various conditions.

- **IPX7 Waterproof:** With an IPX7 rating, the earphones are resistant to sweat and rain, making them suitable for both indoor and outdoor workouts.
- **Ideal for Sports:** Perfect for fitness gyms, hiking, and other active outdoor scenarios.




Image: The Conyat X5S earphones being splashed with water, demonstrating their IPX7 waterproof and sweatproof capabilities against light rain, accidental splashes, and sweat.

10. Maintenance

Proper maintenance ensures the longevity and optimal performance of your Conyat X5S earphones.

- **Cleaning:** Gently wipe the earphones and charging case with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the earphones in their charging case to protect them from dust and damage. Keep them in a cool, dry place away from extreme temperatures.
- **Charging Port:** Ensure the Type-C charging port is clean and free of debris to maintain proper charging connection.

11. Troubleshooting

If you encounter any issues with your Conyat X5S earphones, please refer to the following common solutions:

11.1 Pairing Issues

- **Earphones not pairing:** Ensure both earphones are in the charging case, then take them out to activate pairing mode. Check if Bluetooth is enabled on your device.
- **"X5S" not appearing in Bluetooth list:** Turn off and on your device's Bluetooth. If the issue persists, try restarting your device.

11.2 No Sound or Intermittent Sound

- **No sound:** Check the volume level on both your earphones and your connected device. Ensure the earphones are properly paired.
- **Intermittent sound:** Move closer to your connected device to avoid signal interference. Ensure there are no physical obstructions between the earphones and the device.

11.3 Charging Issues

- **Earphones not charging:** Ensure the charging contacts on the earphones and inside the case are clean and dry. Make sure the charging case has sufficient battery.
- **Charging case not charging:** Verify the Type-C cable is securely connected to both the case and the power source. Try using a different Type-C cable or power adapter.

11.4 Call Quality Issues

- **Unclear calls:** Ensure the microphone is not obstructed. Try moving to a quieter environment to reduce background noise.

If these steps do not resolve your issue, please contact customer support.

12. Specifications

Feature	Detail
Brand	Conyat
Model Number	X5S
Color	Black
Bluetooth Version	6.0
Driver Size	14.2mm Dynamic Driver
Noise Cancellation	ENC (Environmental Noise Cancellation) for calls
Playback Time (Earbuds)	8-10 hours
Total Playback Time (with Case)	Up to 40 hours
Charging Port	USB-C
Charging Time	Approx. 1.5 hours (case)
Waterproof Rating	IPX7
Earbud Weight	Approx. 6.7g (per earbud)
Package Dimensions	9.8 x 9.5 x 3.2 cm
Package Weight	100 g

13. Safety Information

Please read and follow these safety guidelines to prevent injury or damage to your device:

- Do not disassemble, repair, or modify the product.
- Keep the product away from extreme temperatures, direct sunlight, and open flames.
- Avoid exposing the product to excessive moisture or liquids beyond its IPX7 rating.
- Do not use the product at high volume for extended periods to prevent hearing damage.
- Exercise caution when using earphones in situations requiring awareness of your surroundings, such as driving or cycling.
- Keep out of reach of children and pets.

14. Warranty and Support

Your Conyat X5S earphones come with a standard manufacturer's warranty. For specific warranty details, please refer to the warranty card included in your package or contact your retailer.

14.1 Customer Support

If you have any questions, concerns, or require technical assistance, please contact our customer support team through the platform where you purchased the product. Please have your product model number (X5S) and purchase details ready when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question