

Fanbulous F-TY72OB-1D02

Fanbulous 72 Inch Walnut Ceiling Fan Instruction Manual

Model: F-TY72OB-1D02

1. INTRODUCTION AND SAFETY INFORMATION

This manual provides detailed instructions for the installation, operation, and maintenance of your Fanbulous 72 Inch Walnut Ceiling Fan. Please read this manual thoroughly before installation and use to ensure safe and efficient operation. Keep this manual for future reference.

Important Safety Instructions:

- Always disconnect power at the circuit breaker before installing, cleaning, or servicing the fan.
- All electrical wiring must be performed by a qualified electrician and comply with all local and national electrical codes.
- Ensure the installation site can support the fan's weight.
- Do not bend the blade holders during installation or cleaning.
- Ensure all connections are secure and properly grounded.
- Do not operate the fan if any part is damaged.

2. PACKAGE CONTENTS

Carefully unpack your Fanbulous ceiling fan and ensure all components are present and undamaged. If any parts are missing or damaged, contact customer support immediately.

- Ceiling Fan Motor Housing
- Fan Blades (8 total, reversible walnut/light wood finish)
- Downrods (6-inch, 12-inch, and 20-inch options)
- Mounting Bracket
- Remote Control with Wall Cradle
- Hardware Bags (screws, washers, wire nuts, etc.)
- Instruction Manual

3. SETUP AND INSTALLATION

Proper installation is crucial for the safe and efficient operation of your ceiling fan. It is recommended that a qualified electrician perform the electrical wiring.

3.1 Choosing a Mounting Location

This 72-inch ceiling fan is designed for large rooms up to 20ft x 20ft, suitable for living rooms, great rooms, covered patios, and porches. Ensure the location provides at least 7 feet of clearance from the floor to the fan blades and 18 inches from the blades to any walls or obstructions.

3.2 Downrod Selection and Installation

The fan includes three downrod options: 6-inch, 12-inch, and 20-inch. Select the appropriate downrod based on your ceiling height. The 6-inch downrod is suitable for ceilings up to 8 feet, while the 20-inch downrod is ideal for 10-foot ceilings or to enhance air circulation in higher rooms. The fan can also be angle-mounted on sloped ceilings up to a maximum of 15 degrees.



Image: Diagram showing the 72-inch ceiling fan with its dimensions and the three available downrod lengths (6", 12", 20"). It also illustrates mounting options for low, high, and slanted ceilings (max 15 degrees).

Quiet Enjoyment

Timer Setting 1/4/8 Hours



10dB



Flower Sound

25dB



Library

35dB



Our Fan

45dB



Whisper

55dB



Crowded Street

Image: Close-up view of the three downrod options (6-inch, 12-inch, 20-inch) and the mounting canopy, demonstrating how they connect to the fan motor for different ceiling heights.

3.3 Blade Assembly

The fan blades feature a reversible design with a rustic walnut finish on one side and a light wood tone on the other. Choose the desired finish before attaching the blades. The blades are designed to slide into a slot for easier attachment before securing them with screws.

Reversible 6-Speed Adjustable Fan



1-2 LOW WIND
Soft Wind



3-4 MID WIND
Natural Wind



5-6 HIGH WIND
Cool Wind



Image: Illustration showing the two-sided fan blades, one side with a dark walnut color for a rustic style and the other with a light wood tone for a farmhouse style.

3.4 Remote Control Setup

The remote control allows for convenient operation of your fan. It can be used as a handheld remote or mounted to a wall using the included wall cradle.



Image: Depicts the remote control being used handheld and also mounted in a wall cradle, illustrating the two usage options.

4. OPERATING INSTRUCTIONS

Your Fanbulous ceiling fan is operated using the included remote control. The fan requires the remote control for all functions, including turning it on and off.

Fanbulous



72 Inch Ceiling Fan Without Light

Image: A detailed view of the remote control, highlighting its functions: 6 wind speeds, reversible DC motor, 1/4/8-hour timer, and natural wind mode.

4.1 Power On/Off and Speed Control

- Press the power button on the remote to turn the fan on or off.
- Use the speed buttons (1-6) to adjust the fan's airflow. Speed 1-2 provides a soft wind, 3-4 offers natural wind, and 5-6 delivers a strong cool wind.

Fanbulous

6-Speed Reversible

Cool in summer, Warm in winter



Image: Illustrates the 6-speed reversible function, showing downward airflow for summer mode and upward airflow for winter mode, with corresponding icons for cool and warm air circulation.

4.2 Reversible Mode (Summer/Winter)

The fan features a quiet reversible DC motor for year-round comfort:

- **Summer Mode:** The fan blades rotate counter-clockwise, pushing air downwards to create a cooling breeze.
- **Winter Mode:** The fan blades rotate clockwise, drawing air upwards to circulate warm air trapped near the ceiling, helping to distribute heat more evenly.

Activate the reversible mode using the dedicated button on the remote control.

4.3 Timer Function

Set the fan to automatically turn off after a specified period using the timer function. Options include 1-hour, 4-hour, and 8-hour settings. This feature provides convenience and energy savings.

Variety Decoration Styles

It's time to update your fan lights



Large Room Size
20 x 20FT



Image: Illustrates the quiet operation of the fan (35dB) compared to other sounds, and highlights the 1-hour, 4-hour, and 8-hour timer settings available on the remote control.

4.4 Mute Function

The remote control includes a mute function to silence any beeping sounds, ensuring quiet operation without disturbing your environment.

5. MAINTENANCE

Regular maintenance helps prolong the life and performance of your Fanbulous ceiling fan.

- **Cleaning:** To clean the fan, wipe the motor housing and blades with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these can damage the finish.
- **Blade Inspection:** Periodically check the fan blades for any dust buildup. Excessive dust can affect balance and performance.
- **Tighten Screws:** Over time, some screws may become loose. Periodically check and tighten all screws on the motor housing and blade attachments.

- **No Lubrication Required:** The DC motor is permanently lubricated and does not require additional oiling.

6. TROUBLESHOOTING

If you encounter issues with your Fanbulous ceiling fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Remote control not paired or faulty.	Check circuit breaker and wall switch. Ensure all wiring connections are secure. Re-pair the remote control according to instructions. Replace remote batteries.
Fan makes noise	Loose screws on motor housing or blades; Blades unbalanced; Downrod not securely fastened.	Tighten all screws. Check blade balance and adjust if necessary. Ensure downrod is firmly attached to the mounting bracket and motor.
Remote control not working	Dead batteries; Remote not paired; Obstruction between remote and receiver.	Replace batteries. Re-pair the remote with the fan. Ensure clear line of sight to the fan's receiver.
Fan wobbles excessively	Loose blades or blade holders; Unbalanced blades; Improper mounting.	Ensure all blade screws are tight. Use a blade balancing kit if needed. Verify the mounting bracket is securely installed to the ceiling junction box.

If these steps do not resolve the issue, please contact Fanbulous customer support.

7. SPECIFICATIONS

Feature	Detail
Brand	Fanbulous
Model Number	F-TY72OB-1D02
Size	72 Inch Diameter
Color	Walnut (reversible blades with light wood tone)
Material	Wood blades
Motor Type	DC Motor
Number of Speeds	6
Control Method	Remote Control
Wattage	38.5 watts

Feature	Detail
Indoor/Outdoor Usage	Indoor, Outdoor (covered patios/porches, not exposed to direct rain)
Product Dimensions (D x W x H)	72"D x 72"W x 22"H
Downrod Lengths Included	6 inches, 12 inches, 20 inches
Max Angle Mount	15 degrees
Noise Level	Below 35dB

8. WARRANTY AND SUPPORT

Fanbulous provides a **5-year warranty on the motor** and **2-year service on other parts** for your ceiling fan. This warranty covers defects in materials and workmanship under normal use.

For warranty claims, technical assistance, or any questions regarding your product, please contact Fanbulous customer support through the retailer where the product was purchased or visit the official Fanbulous website for contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

