Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

hosabely B0FQ5GNRTY

hosabely SK9 Handheld Voice Changer Set Instruction Manual

Model: SK9 (B0FQ5GNRTY)

1. Introduction

The hosabely SK9 Handheld Voice Changer Set is an all-in-one audio solution designed for various applications including karaoke, broadcasting, live streaming, singing, recording, and gaming. This device offers multiple voice-changing options, reverb settings, and ambiance sound effects to enhance your audio experience. This manual provides detailed instructions for setting up, operating, and maintaining your SK9 device.

2. Package Contents

Before you begin, please ensure all items listed below are present in your package:

- SK9 Handheld Voice Changer Device
- Mini Microphone
- Lapel Microphone
- Earphones
- 3.5mm Audio Cable
- USB-A to USB-C Cable
- USB-C to USB-C Cable
- Three-way Adapter
- English Manual (this document)



Image: The SK9 Handheld Voice Changer device shown with its complete set of accessories, including microphones, cables, and earphones.

3. Setup and Connections

3.1 Important Compatibility Notes

Please review the following compatibility information before connecting your device:

- The SK9 sound card is compatible with various models of phones, computers, tablets, and speakers (via 3.5mm audio cable only, NOT via Bluetooth), as well as PS5.
- It is **NOT** compatible with Xbox (only usable as input, not output) / VR (requires a USB-C adapter for Quest usage) / USB microphones / PS4.
- This device is **NOT** a phone and cannot make calls or utilize voice-changing features during a call. Voice-changing effects will not function with live calls.
- This product is **NOT** compatible with USB microphones or headsets.




Image: A visual representation of the compatibility notes, highlighting devices that are supported and those that are not.

3.2 Connecting Your Device

Follow these steps to connect your SK9 voice changer to your desired device:

1. **Power On:** Ensure the device is charged. If it does not power on, charge it using the provided USB-C cable.
2. **Microphone Connection:** Connect the mini microphone or lapel microphone to the 'MIC' port on the SK9 device.
3. **Earphone Connection:** Connect your earphones to the 'Earphone' port for monitoring your audio.
4. **Live Output (Phone/Tablet):** Use the 3.5mm audio cable to connect the 'Live' port on the SK9 to the audio input of your phone or tablet.
5. **PC/PS5 Connection:** Use the USB-A to USB-C cable or USB-C to USB-C cable to connect the 'Power/PC/OTG' port on the SK9 to your computer or PS5.




Image: A diagram illustrating how to connect the microphone, earphones, and live output/PC to the SK9 device.

3.3 Video Guide: Connecting to Phone/PC/PS5

For a visual guide on connecting your SK9 device, please watch the following video:

Your browser does not support the video tag.

Video: This video demonstrates the process of connecting the hosabely SK9 Handheld Voice Changer to a phone, PC, or PS5, providing clear visual instructions for setup.

4. Operating Instructions

The SK9 device features a user-friendly interface with various buttons and controls for voice modification and sound effects.



Image: The main interface of the SK9 device, showing buttons for noise reduction, volume adjustment, various atmosphere effects, and Bluetooth connectivity.

4.1 Voice Changing Options

The SK9 offers six distinct voice-changing modes:

- Male
- Female
- Child
- Girl
- Monster
- Robot

Select your desired voice mode by pressing the corresponding button on the device. Adjustments can be made to fine-tune the effect.



Image: A visual display of the six voice-changing options available on the SK9 device, including Male, Girl, Child, Females, Monsters, and Robot.

4.2 Reverb Options

Choose from six reverb settings to enhance your audio, especially for singing and karaoke:

- Voice
- KTV1
- KTV2
- KTV3
- KTV4
- MC

Press the dedicated reverb buttons to cycle through or select your preferred effect.

4.3 Ambiance Sound Effects

The sound board includes 14 preset ambiance effects and a 12-step electronic music effect. These can be used to add atmosphere and dynamism to your live streams and performances. Activate these effects by pressing the

corresponding buttons.

4.4 Live Streaming Features

The SK9 simplifies live streaming with the following features:

- **One-click Noise Reduction:** Reduces background noise for clearer audio.
- **Sound Bypass:** Allows original audio to pass through without effects.
- **Original Sound Options:** Restores your natural voice.

4.5 Volume Adjustment

The device features controls for adjusting the volume of various inputs and outputs. Use the dedicated volume adjusters to set the desired audio levels.

4.6 Bluetooth Connection

The SK9 supports Bluetooth connectivity for certain functions. Refer to the device's display for Bluetooth pairing status and controls.



Image: Examples of the SK9 voice changer being used in different scenarios such as singing, live broadcasting, interviews, and recording sessions.

5. Maintenance

To ensure the longevity and optimal performance of your hosabely SK9 Handheld Voice Changer Set, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the device. Avoid using liquid cleaners or abrasive materials.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Handle the device with care to prevent drops or impacts that could damage internal components.
- **Cables:** Ensure all cables are connected and disconnected gently to avoid damaging the ports.

6. Troubleshooting

If you encounter issues with your SK9 device, refer to the following troubleshooting tips:

6.1 Device Does Not Power On

If the device does not power on, the battery may be drained due to shipping conditions. Please charge the device fully using the provided USB-C cable before attempting to use it.

6.2 No Sound Output/Input

- Check all cable connections to ensure they are secure and plugged into the correct ports.
- Verify that the volume levels on both the SK9 device and your connected device (phone, PC, PS5) are adequately adjusted.
- Ensure you are using compatible devices as outlined in the 'Important Compatibility Notes' section (e.g., not compatible with USB microphones or Xbox output).
- If connecting to a PC, ensure the SK9 is selected as the input/output audio device in your computer's sound settings.

6.3 Voice Changing Effects Not Working

- Confirm that you have selected a voice-changing mode on the device.
- Remember that voice-changing features do not function during live calls.

6.4 Poor Audio Quality / Noise

- Activate the one-click noise reduction feature on the SK9 device.
- Ensure the microphone is positioned correctly and not too far from the sound source.
- Check for any interference from other electronic devices.

7. Specifications

Feature	Detail
Brand	hosabely
Model Number	B0FQ5GNRTY (SK9)

Compatible Devices	Personal Computer, Laptop, Gaming Console (PS5), Smartphone, Tablet, Speaker, Headphone
Hardware Interface	USB
Audio Output Mode	Stereo
Platform Compatibility	Linux, Mac OS X, Windows
Item Highlight	All-in-one Kit, 6 Voice Changers, For Karaoke, Broadcasting, Living, Singing, Recording, Gaming
Number of Items in Set	8



Image: The physical dimensions of the SK9 device, showing its length, width, and thickness.

8. Warranty and Support

8.1 Warranty Information

This hosabely SK9 Handheld Voice Changer Set comes with a**1 Year Free Replacement Warranty**. Please retain your proof of purchase for warranty claims.

8.2 Customer Support

For any questions, assistance, or warranty claims, please contact the seller, Pegasa, through the Amazon platform or refer to the contact information provided with your purchase. You can typically find seller contact details on your Amazon order page.

© 2026 hosabely. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FQ5GNRTY

More documents and user manuals: **https://manuals.plus/**