

- Manuals.plus /
- › GROWNSY /
- › GROWNSY 8-in-1 Bottle Warmer N1T 1 Instruction Manual

GROWNSY N1T 1

GROWNSY 8-in-1 Bottle Warmer N1T 1 Instruction Manual

Model: N1T 1 | Brand: GROWNSY

INTRODUCTION

The GROWNSY 8-in-1 Bottle Warmer N1T 1 is a versatile appliance designed to simplify infant feeding. It offers multiple functions including quick warming, sterilization, food warming, defrosting, and a 24-hour keep warm feature. This manual provides detailed instructions for safe and effective use of your bottle warmer.



Ultimative 10-in-1-Lösung

vom Flaschenwärmer bis zur
Sterilisation, alles in einem Gerät!



Schnelles
Erwärmen



Auftauen



24 Stunden
Warmhalten



Dämpfen



Genaue Temperatur
regelung



Essen erwärmen



Timer



Einstellbare
Temperatur



Anti-Verbrüh-Korb



Sterilisation

Image: The GROWNSY 8-in-1 Bottle Warmer N1T 1, showcasing its compact design and intuitive control panel with various function buttons.

IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using the appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Electrical Safety:** Ensure the voltage matches your power supply. Do not immerse the appliance, cord, or plug in

water or other liquids. Unplug from outlet when not in use and before cleaning.

- **Child Safety:** This appliance is not intended for use by children. Keep the appliance and its cord out of reach of children. Hot steam can cause burns.
- **Temperature Control:** Always check the temperature of the milk or food before feeding your baby. Overheating can destroy nutrients and cause burns.
- **Water Usage:** Use distilled or purified water to prevent mineral buildup. Do not operate without water. The anti-dry heating system will automatically shut off if water runs out.
- **Placement:** Place the appliance on a stable, heat-resistant surface, away from edges and heat sources.
- **Maintenance:** Regularly clean the appliance to prevent bacterial growth.

PRODUCT COMPONENTS

Familiarize yourself with the parts of your GROWNSY Bottle Warmer:

- Main Unit with Heating Plate
- Control Panel with Digital Display
- Bottle Basket/Lift-out Basket
- Lid
- Power Cord



GROWNSY 10-in-1 Flaschenwärmer



Andere

Funktionen	☒ 10-in-1 Alleskönner: Erwärmen, Auftauen, Sterilisieren, Warmhalten, Babynahrung erhitzen, Timer, Speicher &	☒ 3-in-1: Erwärmen, Auftauen, Warmhalten
Heizgeschwindigkeit	☒ Schnell & präzise: 2-7 Minuten auf 37 °C	☒ 3 Minuten
Temperaturkontrolle	☒ 37°C ±1° mit Timer + Speicherfunktion	☒ Automatische Abschaltung
Sterilisation	☒ Hochtemperatur-Dampfsterilisation (99,9 % Bakterienentfernung)	☒ Nicht verfügbar
Warmhaltezeit	☒ 24 Stunden konstante Wärme	☒ Bis zu 60 Minuten
Bedienkomfort	☒ LED-Display, Nachlicht, Erinnerung an letzte Einstellung	☒ Einfach, aber kein Speicher
Materialqualität	☒ BPA-frei & lebensmittelechtes PP-Material	☒ BPA-frei
Reinigung & Pflege	☒ Abnehmbarer Korb, leicht zu reinigen	☒ Standardaufbau

Image: A visual representation of the GROWNSY bottle warmer's features, including its multi-functionality, fast heating, precise temperature control, sterilization, 24-hour keep warm, LED display, BPA-free material, and easy-to-clean basket.

SETUP AND FIRST USE

- Unpack:** Carefully remove all components from the packaging.
- Clean:** Before first use, wash the bottle basket and lid with warm soapy water. Wipe the main unit with a damp cloth. Do not immerse the main unit in water.

3. **Placement:** Place the warmer on a flat, stable, and heat-resistant surface.
4. **Connect:** Plug the power cord into a suitable electrical outlet. The display will light up.

OPERATING INSTRUCTIONS

The GROWNSY 8-in-1 Bottle Warmer offers several modes for different needs. Always ensure the bottle basket is in place before adding bottles or food jars.

1. Quick Warming Mode (Fast)

This mode rapidly heats milk or formula to the desired temperature.

1. Place the bottle with milk/formula into the bottle basket.
2. Add approximately 30ml of distilled water into the heating chamber (around the bottle).
3. Place the lid on the warmer.
4. Press the "Fast" button on the control panel.
5. Use the "+" and "-" buttons to adjust the target temperature if needed.
6. The warmer will start heating. It typically takes 2-7 minutes depending on the volume and initial temperature.
7. Once complete, the warmer will beep 3 times and automatically shut off. Remove the bottle promptly to prevent overheating.
8. **Always check the milk temperature before feeding.**

Schnelles Erwärmen in nur 2–7 Minuten

beruhigt Ihr Baby sofort



Einfache Bedienung (999+) 

Höchste Qualität (999+) 

Hygienische Reinigung (999+) 



Image: A mother feeding her baby, with the GROWNSY bottle warmer visible, highlighting its quick warming capability (2-7 minutes).

2. Sterilization Mode (Sterilize)

This mode uses high-temperature steam to sterilize bottles and accessories, eliminating up to 99.9% of bacteria.

1. Place clean bottles, nipples, or small accessories upside down in the bottle basket.
2. Add approximately 100ml of distilled water into the heating chamber.
3. Place the lid on the warmer.

4. Press the "Sterilize" button.
5. The warmer will generate steam at approximately 100°C (212°F).
6. Once the cycle is complete, the warmer will beep and shut off. Allow items to cool before handling.

Effektives Dampfen bis zu 99,9%



Image: The GROWNSY bottle warmer with its lid on, showing steam inside, indicating the effective sterilization process.

3. Food Warming Mode (Food)

This mode gently warms baby food jars or pouches.

1. Place the baby food jar or pouch into the bottle basket.
2. Add water to the heating chamber, ensuring it reaches the level of the food in the jar/pouch.
3. Place the lid on the warmer.
4. Press the "Food" button.
5. Adjust the target temperature using the "+" and "-" buttons.
6. The warmer will maintain the set temperature. Stir the food and check its temperature before feeding.

4. Defrosting Mode

This mode gently thaws frozen breast milk or baby food, preserving nutrients.

1. Place the frozen breast milk bag or food container into the bottle basket.
2. Add water to the heating chamber, ensuring it reaches the level of the frozen item.
3. Place the lid on the warmer.
4. Select the defrost function (often integrated with a warming mode or a dedicated defrost setting if available, refer to display icons).
5. The warmer will gradually thaw the contents.
6. Once thawed, proceed to warm if necessary, and always check the temperature before feeding.

Schnelles & schonendes Auftauen

Muttermilch zügig auftauen
und Nährstoffe bewahren



Image: The GROWNSY bottle warmer with a breast milk storage bag inside, demonstrating its gentle defrosting capability.

Muttermilch schnell auftauen



Image: The GROWNSY bottle warmer displaying the defrosting process, showing a breast milk bag being thawed from -10°C (14°F) to 37°C (98.6°F).

5. 24-Hour Keep Warm Mode (24H)

This mode maintains milk, water, or food at a desired temperature for up to 24 hours, ideal for night feedings.

1. Place the bottle with pre-warmed milk/water into the bottle basket.
2. Add water to the heating chamber, ensuring it reaches the level of the liquid in the bottle.

3. Place the lid on the warmer.
4. Press the "24H" button.
5. Adjust the target temperature using the "+" and "-" buttons.
6. The warmer will maintain this temperature for up to 24 hours.
7. **Always check the temperature before feeding.**

24H Warmhalten

Ihr Schutzengel für nächtliches Füttern



The GROWNSY bottle warmer is shown in a close-up, with its digital display showing 38°C. The 24H button is highlighted, indicating the 24-hour keep warm function. The warmer is placed on a wooden bedside table. In the background, a baby is sleeping peacefully in a bed, emphasizing the product's role in ensuring a good night's sleep for both the baby and the parent.

-  Süßer Schlaf fürs Baby
-  Erholende Ruhe für Mama
-  Gesundes Wachstum

Image: The GROWNSY bottle warmer positioned on a bedside table during nighttime, emphasizing its 24-hour keep warm function for

convenient night feedings.

Precise Temperature Control

The warmer features precise digital temperature control, allowing you to set the exact temperature for your baby's milk or food. The intelligent memory function remembers your last setting for convenience.

Intelligent und genau Temperaturkontrolle



Image: A close-up of the GROWNSY bottle warmer's digital display, showing a precise temperature setting, indicating its intelligent temperature control capabilities.

MAINTENANCE AND CLEANING

Regular cleaning ensures hygiene and extends the life of your appliance.

1. **Unplug:** Always unplug the warmer and allow it to cool completely before cleaning.
2. **Main Unit:** Wipe the exterior of the main unit with a damp cloth. Do not use abrasive cleaners or immerse the unit in water.
3. **Bottle Basket & Lid:** Wash the bottle basket and lid with warm soapy water and rinse thoroughly. They are typically dishwasher safe (top rack only), but hand washing is recommended for longevity.
4. **Descaling:** Mineral deposits (limescale) may build up on the heating plate over time, especially with hard water.
 - Mix 50ml of white vinegar with 100ml of cold water.
 - Pour the solution into the heating chamber.
 - Let it stand for 30 minutes to 1 hour (or longer for heavy buildup).
 - Pour out the solution and rinse the heating chamber thoroughly with clean water.
 - Repeat if necessary.
5. **Storage:** Store the clean and dry appliance in a cool, dry place.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet issue; appliance malfunction.	Check power connection; try a different outlet; contact customer support.
Milk/food not warming.	Insufficient water; incorrect mode selected; heating element issue.	Ensure adequate water level; select correct mode; descale if necessary; contact support.
Overheating/Burning smell.	No water in heating chamber; mineral buildup.	Immediately unplug. Add water. Perform descaling. If problem persists, discontinue use and contact support.
Sterilization not effective.	Insufficient water; items not properly placed; lid not sealed.	Ensure correct water level; arrange items to allow steam circulation; ensure lid is securely closed.

SPECIFICATIONS

- **Model:** N1T 1
- **Dimensions:** 22.2 x 13.3 x 13.3 cm (8.74 x 5.24 x 5.24 inches)
- **Weight:** 690 g (1.52 lbs)
- **Material Composition:** Polypropylene (PP) - Food Grade
- **Recommended Age:** 0 months and up
- **Functions:** Quick Warming, Sterilization, Food Warming, Defrosting, 24-Hour Keep Warm, Timer, Automatic Shut-off, Night Mode (implied by 24H mode and bright screen description).
- **Heating Time:** 2-7 minutes (depending on volume and initial temperature)
- **Temperature Control:** Adjustable / Precise Digital Control, approx. 100°C for sterilization.

WARRANTY AND SUPPORT

GROWNSY products are manufactured with quality and care. For warranty information, product support, or any inquiries,

please refer to the contact information provided with your purchase or visit the official GROWNSY website. Please retain your proof of purchase for warranty claims.

© 2026 GROWNSY. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question