

PAXA Ctbuds

PAXA Ctbuds 3-in-1 Wireless Earbuds Instruction Manual

Brand: PAXA | Model: Ctbuds

INTRODUCTION

The PAXA Ctbuds series offers a versatile 3-in-1 design, combining clip-on open-ear earbuds, wireless in-ear earbuds, and detachable butterfly ear clips. This manual provides essential information for setting up, operating, and maintaining your Ctbuds to ensure optimal performance and comfort. The design allows for effortless switching between styles to suit various scenarios, from daily wear to workouts.

WHAT'S IN THE BOX

- Clip-on Earbuds x2
- In-Ear Earbuds x2
- Charging Case x1
- User Manual x1
- Type-C Charging Cable x1

PRODUCT FEATURES

- **3-in-1 Versatility:** Easily switch between clip-on open-ear, in-ear, and jewelry-style with detachable butterfly clips.
- **Extended Playtime:** Up to 140 hours of total playtime with the charging case, and 4 hours on a single earbud charge.
- **Bluetooth 6.0:** Ensures faster, more stable pairing and clear audio with a range of up to 10 meters.
- **Lightweight Comfort:** Each earbud weighs approximately 5.3g, designed for all-day wear without discomfort.
- **Water Resistant:** IPX5 rating protects against rain and sweat, suitable for workouts and outdoor activities.
- **Immersive Sound:** 13mm drivers deliver rich, powerful sound.
- **Touch Controls:** Manage music playback, calls, and voice assistant directly from the earbuds.
- **Fidget Toy Charging Case:** The unique metal ring design allows for 360° rotation, providing a stress-relief function.

SETUP

1. Charging the Case and Earbuds

Before first use, fully charge the charging case and earbuds. Connect the provided Type-C charging cable to the charging port on the case and a power source. The charging time for the case is approximately 2 hours.

2. Pairing with Your Device

1. Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. On your device (smartphone, laptop, tablet), enable Bluetooth.
3. Search for "PAXA Ctbuds" in the list of available Bluetooth devices and select it to connect.
4. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.

The earbuds support automatic fast pairing and will reconnect to the last paired device when removed from the case.

WEARING INSTRUCTIONS

For In-Ear Earbuds

Gently insert the in-ear earbuds into your ear canal. Adjust for a snug and comfortable fit. These earbuds are designed to sit securely without blocking the ear canal entirely, allowing for some ambient sound awareness.

Light Comfort, All-Day Wear



Soft & Flexible Fit



Flexible C-Bridge Design



Ultra-Light 5.3g



Image: PAXA Ctbuds in-ear earbuds being worn, demonstrating a soft and flexible fit within the ear.

For Clip-on Open-Ear Earbuds

The clip-on earbuds feature a non-slip ergonomic clip. Position the earbud so the sound emitter rests against the bone in your ear (cochlea), and gently clip the earbud onto your outer ear. This open-ear design allows you to hear your audio while remaining aware of your surroundings, which is beneficial for activities like running or driving. The clip ensures a secure fit during movement.

One Pair, Three Ways to wear

Your all-day wear, transforming effortlessly into earrings.



Image: A model wearing the PAXA CtBuds clip-on open-ear earbuds, highlighting the versatile design.

Attaching Detachable Butterfly Ear Clips

To attach the butterfly ear clips, open the ear cuff and clip it onto the stem of the earbud. Ensure it is securely fastened. This transforms your earbuds into a stylish accessory.

Let Your Charisma Shine




Image: Step-by-step guide on attaching the crystal butterfly ear clips to the earbuds.

OPERATING INSTRUCTIONS

The PAXA Ct buds feature intuitive touch controls on the earbuds. The specific actions are:

- **Answer/End Call:** Double-click either earbud.
- **Reject Call:** Press and hold either earbud for 2 seconds.
- **Voice Assistant:** Hold both earbuds for 2 seconds.
- **Play/Pause:** Double-click either earbud.
- **Previous Song:** Triple-click the left (L) earbud.
- **Next Song:** Triple-click the right (R) earbud.
- **Power On:** Press and hold for 3 seconds.
- **Factory Reset:** Click left (L) or right (R) earbud 5 times.

Volume adjustments are typically managed through your connected device.

Video: Demonstration of PAXA Wireless Earbuds with Touch Screen Headphones, showcasing various touch controls and features. This video is provided by QLM Audio (Seller).

MAINTENANCE

- **Cleaning:** Regularly wipe the earbuds and charging case with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the earbuds in their charging case when not in use to protect them and keep them charged.
- **Avoid Extreme Conditions:** Do not expose the earbuds to extreme temperatures, humidity, or direct sunlight for prolonged periods.

TROUBLESHOOTING

- **Earbuds not pairing:** Ensure both earbuds are charged and removed from the case. Turn off Bluetooth on your device and turn it back on. If issues persist, perform a factory reset.
- **No sound from one earbud:** Place both earbuds back into the charging case, close it, and then reopen it. Re-pair with your device.
- **Charging issues:** Check the Type-C cable and charging port for any damage. Ensure the charging case has sufficient power.

- **Poor sound quality:** Ensure the earbuds are properly seated in your ears (for in-ear) or correctly clipped (for open-ear). Check your device's volume and audio settings.

SPECIFICATIONS

Model Name	Ctbuds
Connectivity Technology	Wireless (Bluetooth 6.0)
Bluetooth Range	10 Meters
Battery Life (Single Earbud)	4 Hours
Total Playtime (with Charging Case)	Up to 140 Hours
Charging Time	2 Hours
Water Resistance Level	IPX5 (Water Resistant)
Control Type	App, Touch
Item Weight (per earbud)	5.3g
Driver Size	13mm

WARRANTY AND SUPPORT

For warranty information, technical support, or any product-related inquiries, please refer to the contact details provided on the product packaging or visit the official PAXA website. Keep your purchase receipt for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question