

[manuals.plus](#) /

› [YESHOMY](#) /

› [YESHOMY Farmhouse 7-Drawer Dresser \(Model YH-0947-0WT\) Instruction Manual](#)

YESHOMY YH-0947-0WT

YESHOMY Farmhouse 7-Drawer Dresser (Model YH-0947-0WT) Instruction Manual

Comprehensive Guide for Assembly, Operation, and Maintenance

1. PRODUCT OVERVIEW

Thank you for choosing the YESHOMY Farmhouse 7-Drawer Dresser. This multi-tier clothing storage cabinet is designed to provide practical and organized storage for your bedroom or dressing area. Its farmhouse aesthetic, featuring a white and black finish, complements various interior styles.

This manual provides essential information to ensure safe assembly, proper use, and long-term care of your dresser. Please read all instructions carefully before beginning assembly or use.



Image 1.1: The YESHOMY Farmhouse 7-Drawer Dresser, featuring a white body and black top, with black metal handles.

2. SAFETY INFORMATION

To prevent injury and damage to the product, adhere to the following safety guidelines:

- **Anti-Tipping Device:** Always install the included anti-tipping strap to secure the dresser to a wall. This is crucial to prevent accidental tipping, especially in households with children or pets.
- **Weight Distribution:** Distribute weight evenly across drawers. Avoid placing excessively heavy items in upper drawers, as this can affect stability.
- **Surface Placement:** Place the dresser on a flat, level, and stable surface. Uneven surfaces can compromise stability.
- **Assembly:** Follow all assembly instructions precisely. Do not skip steps or use unauthorized parts.
- **Children:** Do not allow children to climb on or play with the dresser. Keep small parts away from children during assembly.



Image 2.1: Illustration of the anti-tipping strap installation and the L-shaped feet design for enhanced stability.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

- Dresser Components (panels, drawer parts)
- Assembly Hardware (screws, dowels, cam locks, etc.)
- Instruction Manual
- Anti-Tipping Strap and Hardware

4. ASSEMBLY INSTRUCTIONS

Assembly of the YESHOMY Farmhouse 7-Drawer Dresser requires careful attention to detail. Please follow the step-by-step instructions provided in the separate printed assembly manual included in your package. A tool kit is typically provided for convenience.

1. **Unpack:** Carefully unpack all components and lay them out on a clean, soft surface to prevent scratches.

- 2. Identify Parts:** Refer to the parts list in the assembly manual to identify each component.
- 3. Follow Steps:** Assemble the dresser frame first, then the drawers, following the numerical sequence in the manual.
- 4. Secure Anti-Tipping Device:** Once the dresser is fully assembled and in its final position, install the anti-tipping strap to a wall stud using the provided hardware. This step is critical for safety.

Note: Two people are recommended for assembly to ensure stability and ease of handling larger components.

5. OPERATING INSTRUCTIONS

The YESHOMY dresser features seven drawers designed for smooth operation and organized storage.

- Drawer Operation:** Each drawer is equipped with smooth-gliding rails and metal handles for easy opening and closing. Pull the handle gently and evenly to open, and push firmly to close until it sits flush with the dresser frame.
- Storage Capacity:** Utilize the multi-zone design to categorize and store clothing, bedding, or daily sundries. Avoid overloading drawers, which can strain the rails and affect their longevity.
- Top Surface:** The exquisite tabletop can be used for decorative items, lamps, or other lightweight personal belongings. Ensure items are placed stably to prevent falling.



6. MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your dresser.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals, which can damage the finish. Dry immediately with a clean cloth.
- **Spills:** Clean up spills immediately to prevent staining or damage to the wood material.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they are tight. Retighten if necessary, but do not overtighten.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration.

7. TROUBLESHOOTING

If you encounter issues with your dresser, refer to the following common solutions:

- **Drawers Stick or Don't Close Smoothly:**
 - Check if the drawer is overloaded or if items are obstructing the rails.
 - Ensure the drawer rails are properly aligned and free of debris.
 - Verify that all assembly screws for the drawer and its rails are securely tightened.
- **Dresser Feels Unstable:**
 - Confirm the dresser is placed on a level surface. Adjust if necessary.
 - Ensure the anti-tipping strap is correctly installed and securely fastened to both the dresser and the wall.
 - Check all main frame assembly screws for tightness.
- **Missing Parts or Damaged Components:**
 - Do not attempt to force assembly with incorrect or damaged parts.
 - Contact YESHOMY customer support immediately for replacement parts.

8. SPECIFICATIONS

Feature	Detail
Brand	YESHOMY
Model Name	Dresser for Bedroom
Item Model Number	YH-0947-0WT
Product Dimensions (D x W x H)	15.6"D x 52"W x 29.6"H
Color	White and Black
Material Type	Wood

Feature	Detail
Number of Drawers	7
Item Weight	95.9 pounds
Assembly Required	Yes



Image 8.1: Diagram illustrating the overall dimensions of the dresser and individual drawer sizes.

9. WARRANTY AND SUPPORT

For warranty information, specific return policies, or technical support, please refer to the documentation included with your purchase or contact YESHOMY customer service directly. Contact details can typically be found on the manufacturer's website or within the original packaging materials.

When contacting support, please have your model number (YH-0947-0WT) and purchase date readily available.

