

2-in-1 Electric Nail Clipper

Generic 2-in-1 Electric Nail Clipper Instruction Manual

Model: 2-in-1 Electric Nail Clipper

PRODUCT OVERVIEW

Discover the ultimate solution for stress-free nail care with the Smart 2-in-1 Electric Nail Clipper. Designed for the entire family, this innovative tool makes trimming nails safer, easier, and more convenient than ever. The curved plastic blade gently shapes nails without the risk of cuts, making it especially safe for babies and kids while still powerful enough for adult nails. Its 2-in-1 design combines precise trimming with smooth finishing, giving you salon-quality results in minutes. Crafted with durable, lightweight materials, the ergonomic design ensures comfort when handling both fingers and toes—even thick nails. Compact and portable, it easily fits into your bag, making it the perfect grooming tool for everyday use or family travel.



Figure 1: Generic 2-in-1 Electric Nail Clipper (Orange)



Figure 2: Two Generic 2-in-1 Electric Nail Clippers in different colors (Orange and White)

SAFETY INFORMATION

- Keep out of reach of children when not in use.
- Do not disassemble or modify the device.
- Avoid contact with water or excessive moisture.
- Use only for its intended purpose of nail trimming and polishing.
- If the device malfunctions or is damaged, discontinue use immediately.

PACKAGE CONTENTS

- 1 x 2-in-1 Electric Nail Clipper
- 1 x USB Charging Cable (Type-C)
- 1 x Cleaning Brush
- 1 x User Manual

PRODUCT FEATURES

- **SAFE & FAMILY-FRIENDLY:** Designed with a curved plastic blade, this smart electric nail clipper trims safely and gently, making it ideal for babies, kids, and adults without risk of cuts or scratches.
- **2-IN-1 EFFICIENCY:** Combines clipping and smoothing functions in one device, giving you salon-quality nail care at home. Perfect for busy parents or anyone who wants quick, professional results.
- **CORDLESS & RECHARGEABLE:** Powered by a 400mAh rechargeable battery with USB charging, enjoy up to hours of cordless use—no cords, no hassle, just convenient grooming anytime.
- **DURABLE & STYLISH:** Built from high-quality plastic and available in 4 modern colors (white, black, blue, orange) to match your style and last for years of use.
- **COMPACT & TRAVEL-READY:** Lightweight (0.146 kg) and portable (10×12×4 cm), it fits easily into bags, making it the perfect nail care companion at home or on-the-go.

SETUP

1. **Charging the Device:** Before first use, fully charge the electric nail clipper. Connect the provided USB Type-C cable to the charging port on the device and a suitable USB power source (e.g., computer, wall adapter). The charging indicator will show progress.




Figure 3: Charging the Electric Nail Clipper

Your browser does not support the video tag.

Video 1: Demonstration of the electric nail clipper being charged via USB Type-C.

OPERATING INSTRUCTIONS

1. **Power On/Off:** Press and hold the power button for 3 seconds to turn the device on or off. The LED display will illuminate.
2. **Using the Nail Trimmer:** Gently insert your fingernail or toenail into the trimming slot. The device features a curved plastic blade for safe trimming. Move your finger slowly to allow the rotating blade to trim the nail to the desired length. The device has multiple speed settings; press the power button briefly to cycle through them (e.g., low, medium, high).



Figure 4: Using the Nail Trimming Function

Your browser does not support the video tag.

Video 2: Demonstration of using the electric nail clipper to trim nails, highlighting the different speed settings and built-in light.

3. **Using the Nail Polisher/Buffer:** For smoothing and polishing, use the integrated polishing disc. Gently press your nail against the rotating disc. Move your nail around the disc to achieve a smooth finish. The device's built-in auxiliary lighting helps ensure precision, even in low light conditions.

Auxiliary lighting

Can be used safely at night



Figure 5: Auxiliary Lighting for Polishing



Figure 6: Integrated Shearing and Grinding Function

4. **Low Noise Operation:** The electric nail clipper is designed for quiet operation, making it suitable for use around babies and children without causing disturbance.



Figure 7: Quiet Operation for Undisturbed Use

MAINTENANCE

1. **Cleaning the Device:** After each use, empty the nail debris collection compartment. Push the 'PUSH' button to release the compartment and discard the collected nail clippings. Use the provided cleaning brush to remove any remaining debris from the trimming and polishing areas.

Automatic storage of nail crumbs

Cleaning is easier.

Using the cutter head centrifugal force, easy nail scraps do not splash more clean



Figure 8: Nail Debris Collection Compartment

Your browser does not support the video tag.

Video 3: Demonstration of cleaning the electric nail clipper, including emptying the debris compartment and using the cleaning brush.

2. **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

- **Device not turning on:** Ensure the battery is fully charged. If the issue persists, contact customer support.
- **Nails not trimming effectively:** Ensure the nail is properly inserted into the trimming slot. Check if the blades are clean and free of debris.
- **Device making unusual noise:** Discontinue use and check for any obstructions in the trimming or polishing areas. Clean thoroughly. If the noise continues, contact customer support.

SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Product Dimensions	3.94 x 4.72 x 1.57 inches; 5.15 ounces
Battery	1 Lithium Ion (400mAh) (included)
Material	Plastic (body), Stainless Steel (blade)
Blade Edge	Curved
Manufacturer	Hwtco

WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. For warranty claims, technical support, or any inquiries, please contact the seller directly through your purchase platform. Please retain your proof of purchase for all warranty-related services.