

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Samsonite](#) /

› [Samsonite Paralux Carry-On Spinner Luggage User Manual](#)

## Samsonite 156524-1633

# Samsonite Paralux Carry-On Spinner Luggage User Manual

Model: 156524-1633

## 1. INTRODUCTION

The Samsonite Paralux Carry-On Spinner Luggage is engineered for modern travelers, combining innovative design with practical features. This hardside carry-on offers dual access to its main compartment, including a unique quick-access front pocket that does not compromise internal packing space. Constructed with sustainable materials, it features dual suspension wheels for smooth mobility, a RightHeight adjustable pull handle, a TSA-approved lock for security, and includes removable packing cubes for enhanced organization. This manual provides essential information for the proper use and care of your Paralux luggage.

## 2. KEY FEATURES

### 2.1 Dual Access Innovation

The Paralux luggage offers two ways to access your belongings: a traditional middle-split opening and an innovative quick-access front pocket. This front pocket is designed to provide immediate access to items like laptops, tablets, or travel documents without disturbing the main compartment's contents. It includes an inner airmesh slip pocket and a secure zipper pocket for smaller essentials.



Image: Quick-access front pocket for easy retrieval of travel essentials.

# PACKING, PERFECTED

## Easy Access Front Pocket

Enjoy plenty of pocket space without sacrificing the main compartment.



Image: Illustration of the easy access front pocket design.

## 2.2 Organized Packing System

The interior features a compression panel and two removable packing cubes, allowing for efficient organization and maximizing packing capacity. A built-in AirTag holder provides a dedicated space for tracking your luggage.



Image: Main compartment with included packing cubes and compression straps.



Image: Removable packing cubes for organized storage.

## ENGINEERED TO GO



Image: Integrated AirTag holder for luggage tracking.

### 2.3 Lightweight, Expandable Design

Weighing approximately 7.4 lbs, this carry-on is designed to be lightweight. It also features a 1-inch expansion capability, providing additional packing space when needed.

### 2.4 Smooth Mobility and Comfort

Equipped with dual suspension wheel technology, the luggage glides smoothly across various surfaces. The RightHeight adjustable pull handle allows for customized comfort, and an integrated Eazy Hook provides a convenient way to secure an additional bag on top.

# PACKED WITH INNOVATION

**RightHeight™ Handle:**  
Adjust to your comfort

**Eazy Hook™:**  
Carry an extra bag  
with ease

**TSA Dual Lock:**  
Travel safe and  
worry-free

**Suspension Wheels:**  
Smooth roll on any surface

**1" Expansion:**  
Extra room when you need it

Image: Overview of key features including handle, wheels, and expansion.

## 2.5 TSA-Approved Security

A dual TSA-approved combination lock is integrated into the luggage, ensuring your belongings are secure while complying with airport security regulations.

Video: An official Samsonite video demonstrating the innovative features of the Paralux luggage, including the TSA lock and dual access.

## 3. SETUP

### 3.1 Setting the TSA Combination Lock

Your luggage comes with a TSA-approved combination lock preset to 0-0-0. To set your personal combination:

1. Ensure the lock is set to the default combination (0-0-0) and the zippers are disengaged.
2. Locate the small reset button (usually a small hole) next to the dials. Use a pen or a pointed object to press and hold

this button until you hear a click.

3. While holding the reset button, set your desired 3-digit combination by turning the dials.
4. Release the reset button. Your new combination is now set.
5. Test your new combination by scrambling the dials and then entering your set combination to open the lock.

**Important:** Remember your combination. There is no master key for personal combinations, and Samsonite cannot assist in opening locked luggage if the combination is forgotten.

## 4. OPERATING INSTRUCTIONS

### 4.1 Packing Your Luggage

- **Main Compartment:** Open the luggage fully using the traditional middle-split opening. Utilize the compression panel and removable packing cubes to organize clothing and other items efficiently.
- **Quick-Access Front Pocket:** For items you need to access frequently or quickly, such as laptops (up to 15.6 inches), tablets, travel documents, or small personal items, use the front pocket. This allows for easy retrieval without fully opening the main case.

### 4.2 Expanding the Luggage

To expand the luggage, locate the expansion zipper around the perimeter of the main compartment. Unzip this zipper to gain an additional 1 inch of packing depth. Zip it back up to return to its original size.

### 4.3 Using the Pull Handle

The RightHeight pull handle can be adjusted to multiple heights for ergonomic comfort. Press the button on the handle grip and extend or retract the handle to your preferred height. Ensure it clicks securely into place.

### 4.4 Maneuvering with Suspension Wheels

The dual suspension spinner wheels are designed for smooth, multi-directional rolling. Push or pull the luggage in any direction with minimal effort, even over uneven surfaces.

### 4.5 Attaching Additional Bags (Eazy Hook)

To attach an additional bag, locate the Eazy Hook on the top of the luggage. Extend the hook and secure the handle or strap of your extra bag onto it. Ensure the additional bag is stable and does not impede the luggage's balance or mobility.

## 5. MAINTENANCE AND CARE

- **Exterior Cleaning:** Wipe the hardside exterior with a soft cloth dampened with mild soap and water. Avoid abrasive cleaners or solvents.
- **Interior Cleaning:** Spot clean the interior lining with a damp cloth and mild detergent. Allow to air dry completely before closing.
- **Wheel Maintenance:** Periodically check the wheels for debris. Clean any dirt or hair from the wheel axles to ensure smooth rolling.
- **Handle Care:** Ensure the pull handle extends and retracts smoothly. Avoid forcing it if it gets stuck.
- **Storage:** Store your luggage in a cool, dry place away from direct sunlight when not in use.

## 6. TROUBLESHOOTING

- **Lock Not Opening:** Double-check your set combination. If forgotten, contact Samsonite customer service for assistance with TSA-approved locks (note: they cannot reset personal combinations).
- **Stuck Pull Handle:** Ensure no items are obstructing the handle mechanism inside the lining. Gently wiggle the handle while pressing the release button.
- **Wheels Not Rolling Smoothly:** Inspect wheels for trapped debris (hair, lint, dirt) and clean as necessary.
- **Zippers Sticking:** Apply a small amount of zipper lubricant or a graphite pencil to the zipper teeth.

## 7. SPECIFICATIONS

Feature	Detail
Product Dimensions	15 x 10 x 23 inches
Interior Packing Dimensions	20.8in H x 14.5in L x 10in W
Exterior Dimensions (with wheels)	23in H x 15in L x 10in W
Item Weight	7.4 lbs (9.78 pounds / 4.45 Kilograms)
Expansion	1 inch
Lock Type	Dual TSA-Approved Combination Lock
Wheels	Dual Suspension Spinner Wheels
Handle	RightHeight Adjustable Pull Handle
Included Accessories	Removable Packing Cubes, Eazy Hook, AirTag Holder
Manufacturer	Samsonite
Item Model Number	156524-1633

## 8. WARRANTY AND SUPPORT

### 8.1 Limited Warranty

The Samsonite Paralux Carry-On Spinner Luggage is backed by a 10-year limited warranty. This warranty covers manufacturing defects in materials and workmanship. It does not cover damage caused by misuse, neglect, accidents, abrasion, extreme temperatures, solvents, acids, water, normal wear and tear, or transport damage (e.g., by airlines). For full details and terms, please refer to the official Samsonite warranty policy or contact customer service.

### 8.2 Customer Support

For any questions, concerns, or warranty claims, please contact Samsonite customer service through their official website or

the contact information provided with your purchase. When contacting support, please have your model number (156524-1633) and proof of purchase available.