

[Manuals.plus](#) /

› [Samsonite](#) /

› Samsonite Paralux Medium Checked Luggage Instruction Manual

Samsonite 156525-1041

Samsonite Paralux Medium Checked Luggage Instruction Manual

Model: 156525-1041

1. INTRODUCTION

Thank you for choosing the Samsonite Paralux Medium Checked Luggage. This innovative hardside spinner is designed for convenience and durability, offering dual access to your belongings and advanced features for a seamless travel experience. This manual provides essential information on setting up, operating, maintaining, and troubleshooting your luggage.





A full view of the Samsonite Paralux Medium Checked Luggage in black, showcasing its hardside design and overall aesthetic.

2. KEY FEATURES

- **Dual Access Innovation:** Features both a traditional middle opening and a quick-access front pocket, allowing for flexible packing and unpacking, especially in confined spaces.
- **Organized Packing:** Includes removable packing cubes and a compression panel to keep your items neatly organized. A built-in AirTag holder provides peace of mind for tracking.
- **Lightweight & Expandable:** Weighing just 9.6 lbs, this medium-sized suitcase offers 1-inch expansion to maximize packing capacity without excessive weight.

- **Smooth Mobility:** Equipped with dual suspension wheel technology for effortless gliding over various surfaces and a RightHeight adjustable pull handle for customized comfort. An Eazy Hook is included for attaching an additional bag.
- **TSA-Approved Security:** A dual TSA-approved lock secures both the front and main compartments, ensuring your belongings are protected while complying with security standards.

PACKED WITH INNOVATION

RightHeight™ Handle:
Adjust to your comfort

Eazy Hook™:
Carry an extra bag
with ease

TSA Dual Lock:
Travel safe and
worry-free

Suspension Wheels:
Smooth roll on any surface

1" Expansion:
Extra room when you need it

An angled view of the luggage with its handle extended, pointing out features like the RightHeight handle, Eazy Hook, TSA Dual Lock, 1-inch expansion, and Suspension Wheels.

3. SETUP AND FIRST USE

3.1. Setting Your TSA Combination Lock

Your luggage is equipped with a TSA-approved combination lock. The factory preset combination is 0-0-0. To set your personal combination:

1. Ensure the lock is set to the factory preset (0-0-0) and unlocked.
2. Locate the reset button (usually a small, recessed button) next to the dials.
3. Using a pen or a pointed object, press and hold the reset button until you hear a click.
4. While holding the reset button, set your desired 3-digit combination by turning the dials.
5. Release the reset button. Your new combination is now set. Test it by scrambling the numbers and then entering your new combination to unlock.

Video demonstrating how to reset a Samsonite combination lock. This process ensures your luggage is secured with a personalized code.

3.2. Utilizing Removable Packing Cubes

Your Paralux luggage includes two removable packing cubes of different sizes. These are designed to help you organize your clothes and accessories, making packing and unpacking more efficient. Simply pack your items into the cubes and place them within the main compartment. The compression panel can be used to further secure your packed items.



Two different sized packing cubes, designed to help organize belongings within the luggage.

4. OPERATING YOUR LUGGAGE

4.1. Dual Access System

The Paralux luggage offers two ways to access your main compartment:

- **Traditional Middle Opening:** Unzip the main zipper around the perimeter of the suitcase to open it like a traditional clamshell.
- **Quick Access Front Pocket:** For smaller items or when space is limited, utilize the front pocket zipper to access the main compartment without fully opening the suitcase. This front access does not reduce the main compartment's packing volume.

4.2. Expandable Feature

To increase your packing capacity, locate the secondary zipper around the perimeter of the luggage. Unzip this section to expand the suitcase by approximately 1 inch, providing additional space for your belongings.

4.3. RightHeight Adjustable Pull Handle

The pull handle is designed for ergonomic comfort. Press the button on the handle grip to extend or retract the handle. Adjust it to your preferred height for comfortable maneuvering. The handle also features an Eazy Hook for attaching an additional bag.

4.4. Dual Suspension Wheel Technology

The luggage is equipped with Aero-Trac Whirl Suspension Wheels. These wheels are engineered to provide smooth, quiet rolling and reduce vibration across various surfaces, enhancing your travel comfort.

Video showcasing the innovative features and design of the Samsonite Paralux luggage, including its dual access, packing cubes, expansion, and suspension wheels.

Video demonstrating the advanced Aero-Trac Whirl Suspension Wheel technology, highlighting its smooth rolling capability and vibration reduction on various urban terrains.

5. CARE AND MAINTENANCE

5.1. Cleaning Instructions

- **Exterior:** Wipe the hardside exterior with a soft cloth dampened with mild soap and water. Avoid abrasive cleaners or solvents.
- **Interior:** The interior lining can be spot cleaned with a damp cloth and mild detergent. Allow to air dry completely before closing.
- **Wheels:** Periodically check and clean the wheels to remove any debris (hair, lint, etc.) that may hinder smooth rolling.

5.2. General Care Tips

- Avoid overpacking to prevent stress on zippers and seams.
- Store your luggage in a cool, dry place when not in use.
- If the luggage gets wet, ensure it is thoroughly dried before storage to prevent mold or mildew.

6. TROUBLESHOOTING

- **Combination Lock Not Working:** Ensure you are entering the correct 3-digit code. If you forgot your code, follow the reset instructions in Section 3.1. If the lock is jammed, do not force it; contact Samsonite customer support.
- **Zippers Sticking:** Apply a small amount of zipper lubricant (e.g., beeswax or a silicone-based spray) to the zipper teeth and gently work the zipper back and forth.

- **Wheels Not Rolling Smoothly:** Check for any debris (hair, lint, dirt) caught in the wheel mechanism. Clean as described in Section 5.1. If the issue persists, the wheels may require professional servicing.
- **Handle Jams:** Ensure no items inside the luggage are obstructing the handle mechanism. Press the release button firmly and try extending/retracting the handle.

7. SPECIFICATIONS

Attribute	Detail
Product Dimensions	18.6 x 11.75 x 26.4 inches
Item Weight	13.12 pounds
Department	Unisex
Manufacturer	Samsonite
Item Model Number	156525-1041
Expansion	1 inch
Lock Type	Dual TSA-Approved Combination Lock
Wheel Type	Dual Suspension Spinner Wheels

8. WARRANTY AND SUPPORT

Samsonite products are rigorously tested to ensure they meet strict standards. This product is covered by Samsonite's limited warranty, which protects against manufacturing defects. For detailed warranty information, service requests, or further assistance, please visit the official Samsonite website or contact their customer support directly.

Online Support: www.samsonite.com