

[Manuals.plus](#) /

› [Aeitto](#) /

› Aeitto 1800W Professional Countertop Blender with 68oz Jar and Grinder Combo Instruction Manual

Aeitto B0FQ9QKZMX

Aeitto 1800W Professional Countertop Blender and Grinder Combo

Model: B0FQ9QKZMX

IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using your Aeitto blender. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the blender is unplugged before assembling, disassembling, or cleaning.
- Do not immerse the motor base in water or other liquids. Clean with a damp cloth only.
- Keep hands and utensils out of the container while blending to reduce the risk of severe injury to persons or damage to the blender. A scraper may be used only when the blender is not running.
- Blades are sharp. Handle with extreme care when cleaning the container and blades.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- Do not use outdoors. This appliance is for household use only.
- Never blend hot liquids in the grinding cup.
- Ensure the lid is securely locked in place before operating the blender.
- Do not overfill the blender jar or grinding cup beyond the maximum fill line.

PRODUCT OVERVIEW

The Aeitto 1800W Professional Countertop Blender and Grinder Combo is designed for efficient blending and grinding tasks in your kitchen.



Image: The Aetto blender base with the large 68oz blending jar and the smaller grinding cup, along with the tamper.

Components

- Blender Base (1800W Motor)
- 68oz Blending Jar with Lid and Tamper
- Grinding Cup with Lid
- Blending Blade Assembly (integrated into blending jar)
- Grinding Blade Assembly (integrated into grinding cup)

Key Features

- **1800W High-Power Motor:** Provides up to 25,000 RPM for efficient processing of ingredients, including ice. Features overheat protection.
- **68oz Extra Large Capacity Jar:** Ideal for preparing large batches, serving 7-8 people.

- **2-in-1 Blender & Grinder Combo:** Includes separate containers and blade types for blending (smoothies, juices) and grinding (coffee beans, nuts, spices).
- **Upgraded 6-Leaf Blades:** Designed for smoother and finer blending results.
- **Four Intelligent Preset Programs:** Dedicated settings for Warm Purees, Smoothies, Ice Crush, and Grains.
- **Easy to Clean:** Self-cleaning function and dishwasher-safe components (jar and cup).
- **User-Friendly Control Panel:** Simple operation with a speed dial and preset program selector.

SETUP

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Clean Components:** Before first use, wash the blending jar, grinding cup, lids, and tamper with warm, soapy water. Rinse thoroughly and dry. The motor base should only be wiped with a damp cloth.
3. **Place Base:** Position the motor base on a clean, dry, flat, and stable surface. Ensure it is away from the edge of the countertop.
4. **Attach Container:** Place either the blending jar or the grinding cup onto the motor base. Ensure it is seated correctly and securely. The blender features a safety lock mechanism that prevents operation if the container is not properly aligned.
5. **Connect Power:** Plug the power cord into a grounded electrical outlet.



Image: Close-up of the safety lock mechanism on the blender base, ensuring proper container placement.


OPERATING INSTRUCTIONS

General Operation

1. Ensure the blender is plugged in and the container is securely placed on the motor base.
2. Add ingredients to the container. Do not exceed the maximum fill line.
3. Secure the lid onto the container. For the blending jar, ensure the lid is locked.
4. Turn the 'OFF/ON' switch to 'ON'.
5. Select your desired speed using the 'SPEED' dial or choose a preset program using the 'START' dial.
6. For quick bursts of power, use the 'PULSE' switch. Hold for desired duration, then release.
7. After blending, turn the 'OFF/ON' switch to 'OFF' and unplug the appliance.

Four Intelligent Preset Programs

Just turn the knob to make your favourite drink



WARM PUREES



SMOOTHIES



ICE CRUSH



CRAINS

Image: The blender's control panel showing the speed dial, pulse switch, and preset program dial for Warm Purees, Smoothies, Ice Crush, and Grains.

Blending (Using 68oz Jar)

- Use for smoothies, milkshakes, juices, frozen drinks, and purees.
- Add liquids first, then soft ingredients, followed by harder ingredients and ice.
- For thick mixtures, use the tamper through the lid opening to push ingredients towards the blades, but only when the blender is running.
- Utilize the 'Smoothies' or 'Ice Crush' preset programs for optimal results with these specific tasks.

Multifunctional Blending



Image: Examples of various blended items such as smoothies, juices, milkshakes, purees, and soups, demonstrating the blender's versatility.

Grinding (Using Grinding Cup)

- Use for grinding coffee beans, nuts, spices, and grains.
- Ensure ingredients are dry. Do not grind wet or oily ingredients in the grinding cup.
- Fill the grinding cup with the desired amount of ingredients, secure the lid, and place it on the motor base.
- Use the 'Grains' preset program or adjust the speed dial for desired consistency. Use short 'PULSE' bursts for coarse grinding.



Image: Examples of various items that can be ground, including coffee beans, nuts, beans, spices, and chilies, highlighting the grinding cup's functionality.

CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and extends the life of your blender.

Self-Cleaning Function

1. After use, rinse the blending jar or grinding cup.
2. Add approximately half the container's capacity with warm water and a few drops of dish soap.
3. Secure the lid and place the container on the motor base.
4. Turn the 'OFF/ON' switch to 'ON', then select a medium speed or use the 'Smoothies' preset for 30-60 seconds.
5. Empty the soapy water, rinse the container thoroughly with clean water, and allow it to air dry.



Image: The blending jar filled with water and soap, demonstrating the self-cleaning process.

Dishwasher Safe Components

- The blending jar, grinding cup, and their respective lids are dishwasher safe.
- Place these components on the top rack of your dishwasher.
- Do not place the motor base in the dishwasher.




Image: The blending jar and grinding cup placed in the top rack of a dishwasher, illustrating their dishwasher-safe feature.

Motor Base Cleaning

- Always unplug the motor base before cleaning.
- Wipe the motor base with a soft, damp cloth. Do not use abrasive cleaners or immerse in water.
- Ensure the motor base is completely dry before storing or next use.

TRUBLESHOOTING

If you encounter issues with your Aeitto blender, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Blender does not turn on.	Not plugged in; container not properly seated; overheat protection activated.	Ensure power cord is securely plugged in. Check that the blending jar or grinding cup is correctly aligned and locked onto the motor base. If the motor is hot, unplug and allow it to cool for 15-20 minutes.
Ingredients are not blending smoothly.	Too little liquid; too many ingredients; ingredients are too large or hard.	Add more liquid. Reduce the amount of ingredients. Cut large or hard ingredients into smaller pieces. Use the tamper to push ingredients towards the blades. Increase speed or use the 'PULSE' function.
Loud noise or burning smell.	Overloading; motor overheating; foreign object.	Immediately turn off and unplug the blender. Reduce ingredients. Allow motor to cool. Check for any foreign objects in the container. If the problem persists, contact customer support.
Lid leaks during operation.	Lid not properly secured; container overfilled.	Ensure the lid is firmly pressed down and locked into place. Do not fill the container above the maximum fill line.

SPECIFICATIONS

Feature	Detail
Brand	Aeitto
Model	B0FQ9QKZMX
Motor Power	1800W
Blending Jar Capacity	68 oz (approximately 2 liters)

Feature	Detail
Grinding Cup Capacity	28 oz (approximately 0.8 liters)
Material	BPA-Free Plastic
Product Dimensions	7.87"D x 9.06"W x 19.29"H
Item Weight	11.43 pounds
Power Source	AC
Special Features	Multiple Attachments, Overheat Protection, Self-Cleaning, Dishwasher Safe Components

WARRANTY AND SUPPORT

Aeitto products are manufactured with quality and durability in mind. For specific warranty details, please refer to the warranty card included with your purchase or visit the official Aeitto website.

If you require technical assistance, have questions about your product, or need to claim warranty service, please contact Aeitto customer support. You can find contact information on the official Aeitto brand store or website.

For more information and to explore other Aeitto products, visit the [Aeitto Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FQ9QKZMX>

More documents and user manuals: <https://manuals.plus/>